

# IEC60730B Safety Example

## Contents

1 Introduction.....	1
2 What is new.....	1
3 Development tools.....	1
4 Known issues.....	2

by: NXP Semiconductors

## 1 Introduction

These release notes describe important release information for the IEC60730B safety example application released together with the SDK v2.8.0.

All information about IEC60730B are at [www.nxp.com/iec60730](http://www.nxp.com/iec60730).

## 2 What is new

In the SDK v2.8.0 release, only certified library are available and they are listed in the following table:

Table 1. Device with available examples

Development board	Version of library
lpcxpresso845max	4.0
lpcxpresso824	4.0
lpcxpresso804	4.0
frdmkv11z	4.0
lpcxpresso55s69	4.0
evkmimxrt1020	3.0
evkmimxrt1060	3.0
evkbimxrt1050	3.0

## 3 Development tools

The safety IEC60730B example application was compiled and tested with the following development tools:

- IAR Embedded Workbench IDE version 8.50.1
- Arm®-MDK - Keil® µVision® version 5.30
- MCUXpresso IDE version 11.2.0

FreeMASTER tool version 3.0 was used for application monitoring.

## 3.1 Debuggers

All projects (IAR, Keil, MCUXpresso) have the following debuggers set in the default configurations:



Table 2. Default board settings

Development board	Default debugger	FreeMASTER communication channel via	Serial communication speed
lpcpresso845max	CMSIS-DAP	external debugger	-
lpcpresso824max	CMSIS-DAP	external debugger	-
lpcpresso804	CMSIS-DAP	external debugger	-
frdmkv11	PE micro	on-board debugger	19200
lpcpresso55s69	CMSIS-DAP	on-board debugger	115200
evkmimxrt1020	CMSIS-DAP	on-board debugger	19200
evkmimxrt1060	CMSIS-DAP	on-board debugger	19200
evkbimxrt1050	CMSIS-DAP	on-board debugger	19200

## 4 Known issues

This chapter contains the description of known issues or non-standard behavior of the released example.

### FreeMASTER over external J-link debugger on LPC8xx

In the safety examples, the LPC8xx device does not use FreeMASTER monitoring over an on-board debugger (via serial line), but it is set to use an external debugger to connect to FreeMASTER.

To use an external Segger J-link, follow these steps:

- Connect the SWD cable to the corresponding connector (connect it to the target MCU and not to the on-board debugger).
- Set the J-link debugger in the project file.
- Download the application example onto the board.
- Open the FreeMASTER \*.pmp file and set the correct connection in "Project-> Options ->Comm":




Figure 1. Setting J-link communication in FreeMASTER

Click "OK" and continue with a serial connection as usual.

## How To Reach Us

### Home Page:

[nxp.com](http://nxp.com)

### Web Support:

[nxp.com/support](http://nxp.com/support)

Information in this document is provided solely to enable system and software implementers to use NXP products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document. NXP reserves the right to make changes without further notice to any products herein.

NXP makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does NXP assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in NXP data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. NXP does not convey any license under its patent rights nor the rights of others. NXP sells products pursuant to standard terms and conditions of sale, which can be found at the following address: [nxp.com/SalesTermsandConditions](http://nxp.com/SalesTermsandConditions).

While NXP has implemented advanced security features, all products may be subject to unidentified vulnerabilities. Customers are responsible for the design and operation of their applications and products to reduce the effect of these vulnerabilities on customer's applications and products, and NXP accepts no liability for any vulnerability that is discovered. Customers should implement appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP, the NXP logo, NXP SECURE CONNECTIONS FOR A SMARTER WORLD, COOLFLUX, EMBRACE, GREENCHIP, HITAG, ICODE, JCOP, LIFE VIBES, MIFARE, MIFARE CLASSIC, MIFARE DESFire, MIFARE PLUS, MIFARE FLEX, MANTIS, MIFARE ULTRALIGHT, MIFARE4MOBILE, MIGLO, NTAG, ROADLINK, SMARTLX, SMARTMX, STARPLUG, TOPFET, TRENCHMOS, UCODE, Freescale, the Freescale logo, Altivec, CodeWarrior, ColdFire, ColdFire+, the Energy Efficient Solutions logo, Kinetis, Layerscape, MagniV, mobileGT, PEG, PowerQUICC, Processor Expert, QorIQ, QorIQ Qonverge, SafeAssure, the SafeAssure logo, StarCore, Symphony, VortiQa, Vybrid, Airfast, BeeKit, BeeStack, CoreNet, Flexis, MXC, Platform in a Package, QUICC Engine, Tower, TurboLink, EdgeScale, EdgeLock, eIQ, and Immersive3D are trademarks of NXP B.V. All other product or service names are the property of their respective owners. AMBA, Arm, Arm7, Arm7TDMI, Arm9, Arm11, Artisan, big.LITTLE, Cordio, CoreLink, CoreSight, Cortex, DesignStart, DynamIQ, Jazelle, Keil, Mali, Mbed, Mbed Enabled, NEON, POP, RealView, SecurCore, Socrates, Thumb, TrustZone, ULINK, ULINK2, ULINK-ME, ULINK-PLUS, ULINKpro, µVision, Versatile are trademarks or registered trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. The related technology may be protected by any or all of patents, copyrights, designs and trade secrets. All rights reserved. Oracle and Java are registered trademarks of Oracle and/or its affiliates. The Power Architecture and Power.org word marks and the Power and Power.org logos and related marks are trademarks and service marks licensed by Power.org.

© NXP B.V. 2020.

All rights reserved.

For more information, please visit: <http://www.nxp.com>

For sales office addresses, please send an email to: [salesaddresses@nxp.com](mailto:salesaddresses@nxp.com)

Date of release: 06/2020

Document Identifier: IEC60730BSERN

