



# Kinetis SDK v.1.3 Demo Applications User's Guide

**Freescale Semiconductor, Inc.**

Document Number: KSDK13DEMOUG

Rev. 0

Sept 2015





# Contents

## Chapter 1 Introduction

## Chapter 2 ADC Hardware Trigger Demo

<b>2.1</b>	<b>Overview</b> . . . . .	<b>3</b>
2.1.1	Trigger by PIT . . . . .	3
2.1.2	Trigger by PDB . . . . .	3
2.1.3	Trigger by LPTMR . . . . .	3
2.1.4	Input signal for ADC . . . . .	4
<b>2.2</b>	<b>Supported Platforms</b> . . . . .	<b>4</b>
<b>2.3</b>	<b>System Requirement</b> . . . . .	<b>6</b>
2.3.1	Hardware requirements . . . . .	6
2.3.2	Software requirements . . . . .	6
<b>2.4</b>	<b>Getting Started</b> . . . . .	<b>6</b>
2.4.1	Hardware configuration . . . . .	6
2.4.2	Prepare the Demo . . . . .	7
<b>2.5</b>	<b>Run the demo</b> . . . . .	<b>7</b>
<b>2.6</b>	<b>Customization Options</b> . . . . .	<b>7</b>
2.6.1	Default configurations . . . . .	7
2.6.1.1	ADC configurations . . . . .	7
2.6.1.2	Sample frequency . . . . .	8
2.6.2	Configure the number of samples . . . . .	8
2.6.3	Configure the signal frequency . . . . .	8
2.6.4	Configure the ADC instance . . . . .	8
2.6.5	Configure the ADC input pin . . . . .	8

Section number	Title	Page
<b>Chapter 3</b>		
<b>ADC Low Power Demo</b>		
<b>3.1</b>	<b>Overview</b> . . . . .	<b>9</b>
<b>3.2</b>	<b>Supported Platforms</b> . . . . .	<b>9</b>
<b>3.3</b>	<b>System Requirement</b> . . . . .	<b>10</b>
3.3.1	Hardware requirements . . . . .	10
3.3.2	Software requirements . . . . .	10
<b>3.4</b>	<b>Getting Started</b> . . . . .	<b>10</b>
3.4.1	Prepare the Demo . . . . .	10
3.4.2	Run the demo . . . . .	10
<b>Chapter 4</b>		
<b>AFE Qtimer Demo</b>		
<b>4.1</b>	<b>Overview</b> . . . . .	<b>13</b>
<b>4.2</b>	<b>Supported Platforms</b> . . . . .	<b>13</b>
<b>4.3</b>	<b>Getting Started</b> . . . . .	<b>13</b>
4.3.1	Hardware Settings . . . . .	13
4.3.2	Prepare the Demo . . . . .	14
4.3.3	Run the demo . . . . .	14
<b>Chapter 5</b>		
<b>BLDC Sensorless Demo</b>		
<b>5.1</b>	<b>Overview</b> . . . . .	<b>17</b>
<b>5.2</b>	<b>Supported Platforms</b> . . . . .	<b>17</b>
<b>5.3</b>	<b>System Requirement</b> . . . . .	<b>17</b>
5.3.1	Hardware requirements . . . . .	17
5.3.2	Software requirements . . . . .	17
<b>5.4</b>	<b>Getting Started</b> . . . . .	<b>18</b>
5.4.1	Prepare the Demo . . . . .	19
5.4.2	Run the demo . . . . .	19

Section number	Title	Page
<b>Chapter 6</b>		
<b>Bubble Level FTM Demo</b>		
<b>6.1</b>	<b>Overview</b> . . . . .	<b>21</b>
<b>6.2</b>	<b>Supported Platforms</b> . . . . .	<b>21</b>
<b>6.3</b>	<b>System Requirement</b> . . . . .	<b>21</b>
6.3.1	Hardware requirements . . . . .	21
6.3.2	Software requirements . . . . .	21
<b>6.4</b>	<b>Getting Started</b> . . . . .	<b>21</b>
6.4.1	Hardware Settings . . . . .	21
6.4.2	Prepare the Demo . . . . .	22
<b>6.5</b>	<b>Run the demo</b> . . . . .	<b>22</b>
<b>Chapter 7</b>		
<b>Bubble Level TPM Demo</b>		
<b>7.1</b>	<b>Overview</b> . . . . .	<b>23</b>
<b>7.2</b>	<b>Supported Platforms</b> . . . . .	<b>23</b>
<b>7.3</b>	<b>System Requirement</b> . . . . .	<b>23</b>
7.3.1	Hardware requirements . . . . .	23
7.3.2	Software requirements . . . . .	23
<b>7.4</b>	<b>Getting Started</b> . . . . .	<b>24</b>
7.4.1	Hardware Settings . . . . .	24
7.4.2	Prepare the Demo . . . . .	24
<b>7.5</b>	<b>Run the demo</b> . . . . .	<b>24</b>
<b>Chapter 8</b>		
<b>DAC ADC Demo</b>		
<b>8.1</b>	<b>Overview</b> . . . . .	<b>25</b>
<b>8.2</b>	<b>Supported Platforms</b> . . . . .	<b>25</b>
<b>8.3</b>	<b>System Requirement</b> . . . . .	<b>25</b>
8.3.1	Hardware requirements . . . . .	25

Section number	Title	Page
8.3.2	Software requirements . . . . .	26
<b>8.4</b>	<b>Getting Started</b> . . . . .	<b>26</b>
8.4.1	Hardware configuration . . . . .	26
8.4.2	Hardware Settings . . . . .	26
8.4.3	Prepare the Demo . . . . .	27
<b>8.5</b>	<b>Run the demo</b> . . . . .	<b>27</b>
<b>8.6</b>	<b>Key Functions</b> . . . . .	<b>28</b>

## Chapter 10 Flash Demo

<b>10.1</b>	<b>Overview</b> . . . . .	<b>35</b>
<b>10.2</b>	<b>Supported Platforms</b> . . . . .	<b>35</b>
<b>10.3</b>	<b>System Requirement</b> . . . . .	<b>36</b>
10.3.1	Hardware requirements . . . . .	36
10.3.2	Software requirements . . . . .	36
<b>10.4</b>	<b>Getting Started</b> . . . . .	<b>37</b>
10.4.1	Prepare the Demo . . . . .	37
<b>10.5</b>	<b>Commands/Directions</b> . . . . .	<b>37</b>

Section number	Title	Page
<b>Chapter 11</b>		
<b>FreeMASTER Demo</b>		
<b>11.1</b>	<b>Overview</b> . . . . .	<b>39</b>
<b>11.2</b>	<b>FreeMASTER Demo Introduction</b> . . . . .	<b>40</b>
11.2.1	System Requirement . . . . .	41
11.2.1.1	Hardware requirements . . . . .	41
<b>11.3</b>	<b>FreeMASTER Demo User's Guide</b> . . . . .	<b>42</b>
<b>Chapter 12</b>		
<b>FTM PDB ADC Demo</b>		
<b>12.1</b>	<b>Overview</b> . . . . .	<b>45</b>
<b>12.2</b>	<b>Supported Platforms</b> . . . . .	<b>45</b>
<b>12.3</b>	<b>System Requirement</b> . . . . .	<b>45</b>
12.3.1	Hardware requirements . . . . .	45
12.3.2	Software requirements . . . . .	45
<b>12.4</b>	<b>Getting Started</b> . . . . .	<b>45</b>
12.4.1	Hardware Settings . . . . .	45
12.4.2	Prepare the Demo . . . . .	46
12.4.3	Run the demo . . . . .	46
<b>Chapter 13</b>		
<b>Hello World Demo</b>		
<b>13.1</b>	<b>Overview</b> . . . . .	<b>47</b>
<b>13.2</b>	<b>Supported Platforms</b> . . . . .	<b>47</b>
<b>13.3</b>	<b>System Requirement</b> . . . . .	<b>48</b>
13.3.1	Hardware requirements . . . . .	48
13.3.2	Software requirements . . . . .	48
<b>13.4</b>	<b>Getting Started</b> . . . . .	<b>48</b>
13.4.1	Hardware Settings . . . . .	48
13.4.2	Prepare the Demo . . . . .	48
<b>13.5</b>	<b>Run the demo</b> . . . . .	<b>48</b>

Section number	Title	Page
13.6	Communication Interface Settings: . . . . .	49

## Chapter 14 Hello World QSPI Demo

14.1	Overview . . . . .	51
14.2	Supported Platforms . . . . .	51
14.3	System Requirement . . . . .	51
14.3.1	Hardware requirements . . . . .	51
14.3.2	Software requirements . . . . .	51
14.4	Getting Started . . . . .	52
14.4.1	Hardware settings . . . . .	52
14.4.2	Prepare the example . . . . .	52
14.4.3	Run the example . . . . .	53

## Chapter 15 Hardware Timer Demo

15.1	Overview . . . . .	55
15.2	Supported Platforms . . . . .	55
15.3	System Requirement . . . . .	56
15.3.1	Hardware requirements . . . . .	56
15.3.2	Software requirements . . . . .	56
15.4	Getting Started . . . . .	56
15.4.1	Prepare the Demo . . . . .	56
15.4.2	Run the demo . . . . .	56
15.5	Customization Options . . . . .	57
15.5.1	Configure the Hardware Timer Used . . . . .	57
15.5.2	Configure which clock is used by the hardware timer . . . . .	57
15.5.3	Configure which instance of the module is used . . . . .	57
15.5.4	Hardware Timer Period . . . . .	57



Section number	Title	Page
<b>Chapter 16</b>		
<b>I2C Communication Demo</b>		
<b>16.1</b>	<b>Overview</b> . . . . .	<b>59</b>
<b>16.2</b>	<b>Supported Platforms</b> . . . . .	<b>59</b>
<b>16.3</b>	<b>System Requirement</b> . . . . .	<b>60</b>
16.3.1	Hardware requirements . . . . .	60
16.3.2	Software requirements . . . . .	60
<b>16.4</b>	<b>Getting Started</b> . . . . .	<b>60</b>
16.4.1	Hardware configuration . . . . .	60
16.4.2	Terminal configuration . . . . .	67
16.4.3	Run the demo . . . . .	67

**Chapter 17**  
**I2C Demo with RTOS**

<b>17.1</b>	<b>Overview</b> . . . . .	<b>69</b>
<b>17.2</b>	<b>Supported RTOS</b> . . . . .	<b>69</b>
<b>17.3</b>	<b>Supported Platforms</b> . . . . .	<b>69</b>
<b>17.4</b>	<b>System Requirement</b> . . . . .	<b>71</b>
17.4.1	Hardware requirements . . . . .	71
17.4.2	Software requirements . . . . .	71
<b>17.5</b>	<b>Getting Started</b> . . . . .	<b>71</b>
17.5.1	Build with different RTOS support . . . . .	71
17.5.2	Hardware configuration . . . . .	72
17.5.3	Prepare the Demo . . . . .	83
<b>17.6</b>	<b>Run the demo</b> . . . . .	<b>83</b>

**Chapter 18**  
**iRTC Comp 1 Hz Demo**

<b>18.1</b>	<b>Overview</b> . . . . .	<b>85</b>
<b>18.2</b>	<b>Supported Platforms</b> . . . . .	<b>85</b>

Section number	Title	Page
<b>18.3</b>	<b>System Requirement</b> . . . . .	<b>85</b>
18.3.1	Hardware requirements . . . . .	85
<b>18.4</b>	<b>Getting Started</b> . . . . .	<b>85</b>
18.4.1	Hardware Settings . . . . .	85
18.4.2	Prepare the Demo . . . . .	86
<b>18.5</b>	<b>Run the demo</b> . . . . .	<b>86</b>

## Chapter 19 HTTP Server Demo on lwIP TCP/IP Stack

<b>19.1</b>	<b>Overview</b> . . . . .	<b>87</b>
<b>19.2</b>	<b>Supported RTOS</b> . . . . .	<b>87</b>
<b>19.3</b>	<b>Supported Hardware</b> . . . . .	<b>87</b>
<b>19.4</b>	<b>System Requirement</b> . . . . .	<b>87</b>
19.4.1	Hardware requirements . . . . .	87
19.4.2	Software requirements . . . . .	88
<b>19.5</b>	<b>Getting Started</b> . . . . .	<b>88</b>
19.5.1	Prepare the Demo . . . . .	88
19.5.2	Network Configuration . . . . .	88
19.5.3	Run the demo . . . . .	88

## Chapter 20 Ping Demo on lwIP TCP/IP Stack

<b>20.1</b>	<b>Overview</b> . . . . .	<b>91</b>
<b>20.2</b>	<b>Supported RTOS</b> . . . . .	<b>91</b>
<b>20.3</b>	<b>Supported Hardware</b> . . . . .	<b>91</b>
<b>20.4</b>	<b>System Requirement</b> . . . . .	<b>91</b>
20.4.1	Hardware requirements . . . . .	91
20.4.2	Software requirements . . . . .	92
<b>20.5</b>	<b>Getting Started</b> . . . . .	<b>92</b>
20.5.1	Prepare the Demo . . . . .	92
20.5.2	Network Configuration . . . . .	92

Section number	Title	Page
<b>20.6</b>	<b>Run the demo</b> . . . . .	<b>92</b>

**Chapter 21**  
**TCP Echo Demo on lwIP TCP/IP Stack**

<b>21.1</b>	<b>Overview</b> . . . . .	<b>93</b>
<b>21.2</b>	<b>Supported RTOS</b> . . . . .	<b>93</b>
<b>21.3</b>	<b>Supported Hardware</b> . . . . .	<b>93</b>
<b>21.4</b>	<b>System Requirement</b> . . . . .	<b>93</b>
21.4.1	Hardware requirements . . . . .	93
21.4.2	Software requirements . . . . .	94
<b>21.5</b>	<b>Getting Started</b> . . . . .	<b>94</b>
21.5.1	Prepare the Demo . . . . .	94
21.5.2	Network Configuration . . . . .	94
<b>21.6</b>	<b>Run the demo</b> . . . . .	<b>94</b>

**Chapter 22**  
**UDP Echo Demo on lwIP TCP/IP Stack**

<b>22.1</b>	<b>Overview</b> . . . . .	<b>97</b>
<b>22.2</b>	<b>Supported RTOS</b> . . . . .	<b>97</b>
<b>22.3</b>	<b>Supported Hardware</b> . . . . .	<b>97</b>
<b>22.4</b>	<b>System Requirement</b> . . . . .	<b>97</b>
22.4.1	Hardware requirements . . . . .	97
22.4.2	Software requirements . . . . .	98
<b>22.5</b>	<b>Getting Started</b> . . . . .	<b>98</b>
22.5.1	Prepare the Demo . . . . .	98
22.5.2	Network Configuration . . . . .	98
<b>22.6</b>	<b>Run the demo</b> . . . . .	<b>98</b>

Section number	Title	Page
<b>Chapter 23</b>		
<b>MMAU Filter Demo</b>		
<b>23.1</b>	<b>Overview</b> . . . . .	<b>101</b>
<b>23.2</b>	<b>Supported Platforms</b> . . . . .	<b>101</b>
<b>23.3</b>	<b>System Requirement</b> . . . . .	<b>101</b>
23.3.1	Hardware requirements . . . . .	101
<b>23.4</b>	<b>Getting Started</b> . . . . .	<b>101</b>
23.4.1	Hardware settings . . . . .	101
23.4.2	Prepare the example . . . . .	101
23.4.3	Run the example . . . . .	102
<b>Chapter 24</b>		
<b>MMDVSQ Demo</b>		
<b>24.1</b>	<b>Overview</b> . . . . .	<b>105</b>
<b>24.2</b>	<b>Supported Platforms</b> . . . . .	<b>105</b>
<b>24.3</b>	<b>System Requirement</b> . . . . .	<b>105</b>
24.3.1	Hardware requirements . . . . .	105
24.3.2	Software requirements . . . . .	105
<b>24.4</b>	<b>Getting Started</b> . . . . .	<b>105</b>
24.4.1	Prepare the Demo . . . . .	105
<b>24.5</b>	<b>Run the demo</b> . . . . .	<b>106</b>
<b>Chapter 25</b>		
<b>Power Manager HAL Demo</b>		
<b>25.1</b>	<b>Overview</b> . . . . .	<b>107</b>
<b>25.2</b>	<b>Supported Hardware</b> . . . . .	<b>107</b>
<b>25.3</b>	<b>System Requirement</b> . . . . .	<b>108</b>
25.3.1	Hardware requirements . . . . .	108
25.3.2	Software requirements . . . . .	108
<b>25.4</b>	<b>Getting Started</b> . . . . .	<b>108</b>

Section number	Title	Page
25.4.1	Hardware Settings . . . . .	108
25.4.2	Prepare the Demo . . . . .	108
25.4.3	Run the demo . . . . .	108
25.4.4	Supported Low Power Modes By Platform . . . . .	110

## Chapter 26 Power Manager RTOS Demo

<b>26.1</b>	<b>Overview . . . . .</b>	<b>113</b>
<b>26.2</b>	<b>Supported RTOS . . . . .</b>	<b>113</b>
<b>26.3</b>	<b>Supported Hardware . . . . .</b>	<b>113</b>
<b>26.4</b>	<b>System Requirements . . . . .</b>	<b>114</b>
26.4.1	Hardware requirements . . . . .	114
26.4.2	Software requirements . . . . .	114
<b>26.5</b>	<b>Getting Started . . . . .</b>	<b>115</b>
26.5.1	Hardware Settings . . . . .	115
26.5.2	Prepare the Demo . . . . .	115
26.5.3	Run the demo . . . . .	115
26.5.4	Supported Low Power Modes By Platform . . . . .	116

## Chapter 27 RTC Function Demo

<b>27.1</b>	<b>Overview . . . . .</b>	<b>119</b>
<b>27.2</b>	<b>Supported Hardware . . . . .</b>	<b>119</b>
<b>27.3</b>	<b>System Requirement . . . . .</b>	<b>120</b>
27.3.1	Hardware requirements . . . . .	120
27.3.2	Software requirements . . . . .	120
<b>27.4</b>	<b>Getting Started . . . . .</b>	<b>120</b>
27.4.1	Prepare the Demo . . . . .	120
<b>27.5</b>	<b>Run the demo . . . . .</b>	<b>121</b>

Section number	Title	Page
<b>Chapter 28</b>		
<b>SAI Demo</b>		
<b>28.1</b>	<b>Overview</b> . . . . .	<b>123</b>
<b>28.2</b>	<b>Supported Hardware</b> . . . . .	<b>123</b>
<b>28.3</b>	<b>System Requirement</b> . . . . .	<b>123</b>
28.3.1	Hardware requirements . . . . .	123
28.3.2	Software requirements . . . . .	123
<b>28.4</b>	<b>Getting Started</b> . . . . .	<b>124</b>
28.4.1	GCC Compiler notes . . . . .	124
28.4.2	Hardware Settings . . . . .	124
28.4.3	Prepare the Demo . . . . .	124
<b>28.5</b>	<b>Run the demo</b> . . . . .	<b>124</b>
<b>28.6</b>	<b>Key Functions</b> . . . . .	<b>127</b>

**Chapter 29**  
**SLCD basic testing and an Guess Number game**

<b>29.1</b>	<b>Overview</b> . . . . .	<b>131</b>
<b>29.2</b>	<b>Supported Platforms</b> . . . . .	<b>131</b>
<b>29.3</b>	<b>Getting Started</b> . . . . .	<b>131</b>
29.3.1	Hardware Settings . . . . .	131
29.3.2	Prepare the Demo . . . . .	131
<b>29.4</b>	<b>Run the demo</b> . . . . .	<b>132</b>
<b>29.5</b>	<b>Communication Interface Settings:</b> . . . . .	<b>132</b>

**Chapter 30**  
**SLCD Low Power Demo**

<b>30.1</b>	<b>Overview</b> . . . . .	<b>133</b>
<b>30.2</b>	<b>Supported Hardware</b> . . . . .	<b>133</b>
<b>30.3</b>	<b>System Requirement</b> . . . . .	<b>133</b>

Section number	Title	Page
30.3.1	Hardware requirements . . . . .	133
<b>30.4</b>	<b>Getting Started . . . . .</b>	<b>133</b>
30.4.1	Prepare the Demo . . . . .	133
<b>30.5</b>	<b>Run the demo . . . . .</b>	<b>134</b>

## Chapter 31 Thermistor Lab Demo

<b>31.1</b>	<b>Overview . . . . .</b>	<b>135</b>
<b>31.2</b>	<b>Supported Hardware . . . . .</b>	<b>135</b>
<b>31.3</b>	<b>System Requirement . . . . .</b>	<b>135</b>
31.3.1	Hardware requirements . . . . .	135
31.3.2	Software requirements . . . . .	135
<b>31.4</b>	<b>Getting Started . . . . .</b>	<b>135</b>
31.4.1	Prepare the Demo . . . . .	135
31.4.2	Demo Code Overview . . . . .	136
31.4.2.1	ADC Differential Mode of Operation . . . . .	137

## Chapter 32 Heating, Ventilating, and Air Conditioning on lwIP TCP/IP Stack

<b>32.1</b>	<b>Overview . . . . .</b>	<b>139</b>
<b>32.2</b>	<b>Supported RTOS . . . . .</b>	<b>139</b>
<b>32.3</b>	<b>Supported Hardware . . . . .</b>	<b>139</b>
<b>32.4</b>	<b>System Requirement . . . . .</b>	<b>139</b>
32.4.1	Hardware requirements . . . . .	139
32.4.2	Software requirements . . . . .	140
32.4.3	Software requirements . . . . .	140
<b>32.5</b>	<b>Getting Started . . . . .</b>	<b>140</b>
32.5.1	Prepare the Demo . . . . .	140
32.5.2	Network Configuration . . . . .	140
32.5.3	Run the demo . . . . .	140

Section number	Title	Page
<b>Chapter 33</b>		
<b>ADC16 Example</b>		
<b>33.1</b>	<b>Overview</b> . . . . .	<b>143</b>
<b>33.2</b>	<b>Supported Platforms</b> . . . . .	<b>143</b>
<b>33.3</b>	<b>System Requirement</b> . . . . .	<b>144</b>
33.3.1	Hardware requirements . . . . .	144
33.3.2	Software requirements . . . . .	144
<b>33.4</b>	<b>Getting Started</b> . . . . .	<b>144</b>
33.4.1	Hardware settings . . . . .	144
33.4.2	Prepare the example . . . . .	144
33.4.3	Run the example . . . . .	144
<b>Chapter 34</b>		
<b>AFE Example</b>		
<b>34.1</b>	<b>Overview</b> . . . . .	<b>147</b>
<b>34.2</b>	<b>Supported Platforms</b> . . . . .	<b>147</b>
<b>34.3</b>	<b>System Requirement</b> . . . . .	<b>147</b>
34.3.1	Hardware requirements . . . . .	147
<b>34.4</b>	<b>Getting Started</b> . . . . .	<b>147</b>
34.4.1	Hardware settings . . . . .	147
34.4.2	Prepare the example . . . . .	148
34.4.3	Run the example . . . . .	148
<b>Chapter 35</b>		
<b>CMP Example</b>		
<b>35.1</b>	<b>Overview</b> . . . . .	<b>149</b>
<b>35.2</b>	<b>Supported Platforms</b> . . . . .	<b>149</b>
<b>35.3</b>	<b>System Requirement</b> . . . . .	<b>149</b>
35.3.1	Hardware requirements . . . . .	149
35.3.2	Software requirements . . . . .	149
<b>35.4</b>	<b>Getting Started</b> . . . . .	<b>150</b>



Section number	Title	Page
35.4.1	Hardware configuration . . . . .	150
35.4.2	Hardware settings . . . . .	150
35.4.3	Prepare the example . . . . .	150
35.4.4	Run the example . . . . .	150

## Chapter 36 CMT Example

<b>36.1</b>	<b>Overview . . . . .</b>	<b>153</b>
<b>36.2</b>	<b>Supported Platforms . . . . .</b>	<b>153</b>
<b>36.3</b>	<b>System Requirement . . . . .</b>	<b>153</b>
36.3.1	Hardware requirements . . . . .	153
36.3.2	Software requirements . . . . .	153
<b>36.4</b>	<b>Getting Started . . . . .</b>	<b>153</b>
36.4.1	Hardware settings . . . . .	153
36.4.2	Prepare the example . . . . .	154
36.4.3	Run the example . . . . .	154

## Chapter 37 COP Example

<b>37.1</b>	<b>Overview . . . . .</b>	<b>155</b>
<b>37.2</b>	<b>Supported Platforms . . . . .</b>	<b>155</b>
<b>37.3</b>	<b>System Requirement . . . . .</b>	<b>155</b>
37.3.1	Hardware requirements . . . . .	155
37.3.2	Software requirements . . . . .	155
<b>37.4</b>	<b>Getting Started . . . . .</b>	<b>156</b>
37.4.1	Hardware settings . . . . .	156
37.4.2	Prepare the example . . . . .	156
37.4.3	Run the example . . . . .	156

## Chapter 38 DAC Example

<b>38.1</b>	<b>Overview . . . . .</b>	<b>157</b>
-------------	---------------------------	------------

Section number	Title	Page
<b>38.2</b>	<b>Supported Platforms</b> . . . . .	<b>157</b>
<b>38.3</b>	<b>System Requirement</b> . . . . .	<b>157</b>
38.3.1	Hardware requirements . . . . .	157
38.3.2	Software requirements . . . . .	158
<b>38.4</b>	<b>Getting Started</b> . . . . .	<b>158</b>
38.4.1	Hardware settings . . . . .	158
38.4.2	Prepare the example . . . . .	158
38.4.3	Run the example . . . . .	158

## Chapter 39 DMA Example

<b>39.1</b>	<b>Overview</b> . . . . .	<b>159</b>
<b>39.2</b>	<b>Supported Platforms</b> . . . . .	<b>159</b>
<b>39.3</b>	<b>System Requirement</b> . . . . .	<b>159</b>
39.3.1	Hardware requirements . . . . .	159
39.3.2	Software requirements . . . . .	160
<b>39.4</b>	<b>Getting Started</b> . . . . .	<b>160</b>
39.4.1	Hardware settings . . . . .	160
39.4.2	Prepare the example . . . . .	160
39.4.3	Run the example . . . . .	160

## Chapter 40 DSPI Example with other methods

<b>40.1</b>	<b>Overview</b> . . . . .	<b>163</b>
<b>40.2</b>	<b>Supported Platforms</b> . . . . .	<b>163</b>
<b>40.3</b>	<b>System Requirement</b> . . . . .	<b>164</b>
40.3.1	Hardware requirements . . . . .	164
40.3.2	Software requirements . . . . .	164
<b>40.4</b>	<b>Getting Started</b> . . . . .	<b>164</b>
40.4.1	Hardware settings . . . . .	164
40.4.2	Prepare the example . . . . .	168
40.4.3	Run the example . . . . .	168

Section number	Title	Page
<b>Chapter 41</b>		
<b>EDMA Example</b>		
<b>41.1</b>	<b>Overview</b> . . . . .	<b>173</b>
<b>41.2</b>	<b>Supported Platforms</b> . . . . .	<b>173</b>
<b>41.3</b>	<b>System Requirement</b> . . . . .	<b>173</b>
41.3.1	Hardware requirements . . . . .	173
41.3.2	Software requirements . . . . .	174
<b>41.4</b>	<b>Getting Started</b> . . . . .	<b>174</b>
41.4.1	Hardware settings . . . . .	174
41.4.2	Prepare the example . . . . .	174
41.4.3	Run the example . . . . .	174
<b>Chapter 42</b>		
<b>EWM Example</b>		
<b>42.1</b>	<b>Overview</b> . . . . .	<b>177</b>
<b>42.2</b>	<b>Supported Platforms</b> . . . . .	<b>177</b>
<b>42.3</b>	<b>System Requirement</b> . . . . .	<b>177</b>
42.3.1	Hardware requirements . . . . .	177
42.3.2	Software requirements . . . . .	178
<b>42.4</b>	<b>Getting Started</b> . . . . .	<b>178</b>
42.4.1	Hardware settings . . . . .	178
42.4.2	Prepare the example . . . . .	178
42.4.3	Run the example . . . . .	178
<b>Chapter 43</b>		
<b>FLASH Example</b>		
<b>43.1</b>	<b>Overview</b> . . . . .	<b>179</b>
<b>43.2</b>	<b>Supported Platforms</b> . . . . .	<b>179</b>
<b>43.3</b>	<b>System Requirement</b> . . . . .	<b>180</b>
43.3.1	Hardware requirements . . . . .	180
43.3.2	Software requirements . . . . .	180

Section number	Title	Page
<b>43.4</b>	<b>Getting Started</b> . . . . .	<b>180</b>
43.4.1	Hardware settings . . . . .	180
43.4.2	Prepare the example . . . . .	180
43.4.3	Run the example . . . . .	181

## Chapter 44 FlexCAN Example

<b>44.1</b>	<b>Overview</b> . . . . .	<b>183</b>
<b>44.2</b>	<b>Supported Platforms</b> . . . . .	<b>183</b>
<b>44.3</b>	<b>System Requirement</b> . . . . .	<b>183</b>
44.3.1	Hardware requirements . . . . .	183
44.3.2	Software requirements . . . . .	183
<b>44.4</b>	<b>Getting Started</b> . . . . .	<b>184</b>
44.4.1	Hardware settings . . . . .	184
44.4.2	Prepare the example . . . . .	184
44.4.3	Run the example . . . . .	184
44.4.3.1	FlexCAN loopback . . . . .	184
44.4.3.2	FlexCAN network . . . . .	185

## Chapter 45 FlexIO simulated I2C Example with other methods

<b>45.1</b>	<b>Overview</b> . . . . .	<b>187</b>
<b>45.2</b>	<b>Supported Platforms</b> . . . . .	<b>187</b>
<b>45.3</b>	<b>System Requirement</b> . . . . .	<b>187</b>
45.3.1	Hardware requirements . . . . .	187
45.3.2	Software requirements . . . . .	187
<b>45.4</b>	<b>Getting Started</b> . . . . .	<b>187</b>
45.4.1	Hardware settings . . . . .	187
45.4.2	Prepare the example . . . . .	189
45.4.3	Run the example . . . . .	189

Section number	Title	Page
<b>Chapter 46</b>		
<b>Flexio I2S Example with other methods</b>		
<b>46.1</b>	<b>Overview</b> . . . . .	<b>191</b>
<b>46.2</b>	<b>Supported Platforms</b> . . . . .	<b>191</b>
<b>46.3</b>	<b>System Requirement</b> . . . . .	<b>191</b>
46.3.1	Hardware requirements . . . . .	191
46.3.2	Software requirements . . . . .	191
<b>46.4</b>	<b>Getting Started</b> . . . . .	<b>191</b>
46.4.1	Hardware settings . . . . .	191
46.4.2	Prepare the example . . . . .	193
46.4.3	Run the example . . . . .	193

**Chapter 47**  
**FlexIO IRDA Example**

<b>47.1</b>	<b>Overview</b> . . . . .	<b>195</b>
<b>47.2</b>	<b>Supported Platforms</b> . . . . .	<b>195</b>
<b>47.3</b>	<b>System Requirement</b> . . . . .	<b>195</b>
47.3.1	Hardware requirements . . . . .	195
<b>47.4</b>	<b>Getting Started</b> . . . . .	<b>195</b>
47.4.1	Hardware Settings . . . . .	195
47.4.2	Prepare the Demo . . . . .	196
<b>47.5</b>	<b>Run the demo</b> . . . . .	<b>197</b>
47.5.1	Customization Options . . . . .	197

**Chapter 48**  
**FlexIO-simulated SPI Example with other methods**

<b>48.1</b>	<b>Overview</b> . . . . .	<b>199</b>
<b>48.2</b>	<b>Supported Platforms</b> . . . . .	<b>199</b>
<b>48.3</b>	<b>System Requirement</b> . . . . .	<b>199</b>
48.3.1	Hardware requirements . . . . .	199
48.3.2	Software requirements . . . . .	199

Section number	Title	Page
<b>48.4</b>	<b>Getting Started</b> . . . . .	<b>200</b>
48.4.1	Hardware settings . . . . .	200
48.4.2	Prepare the example . . . . .	202
48.4.3	Run the example . . . . .	202

## Chapter 49 FlexIO-simulated UART Example with other methods

<b>49.1</b>	<b>Overview</b> . . . . .	<b>205</b>
<b>49.2</b>	<b>Supported Platforms</b> . . . . .	<b>205</b>
<b>49.3</b>	<b>System Requirement</b> . . . . .	<b>205</b>
49.3.1	Hardware requirements . . . . .	205
49.3.2	Software requirements . . . . .	205
<b>49.4</b>	<b>Getting Started</b> . . . . .	<b>206</b>
49.4.1	Hardware settings . . . . .	206
49.4.2	Prepare the example . . . . .	207
49.4.3	Run the example . . . . .	207
49.4.3.1	FLEXIO_UART interrupt way . . . . .	207
49.4.3.2	FLEXIO_UART interrupt way . . . . .	208

## Chapter 50 FTM Example

<b>50.1</b>	<b>Overview</b> . . . . .	<b>209</b>
<b>50.2</b>	<b>Supported Platforms</b> . . . . .	<b>209</b>
<b>50.3</b>	<b>System Requirement</b> . . . . .	<b>209</b>
50.3.1	Hardware requirements . . . . .	209
50.3.2	Software requirements . . . . .	210
<b>50.4</b>	<b>Getting Started</b> . . . . .	<b>210</b>
50.4.1	Hardware settings . . . . .	210
50.4.2	Prepare the example . . . . .	210
50.4.3	Run the example . . . . .	210

Section number	Title	Page
<b>Chapter 51</b>		
<b>GPIO Example</b>		
<b>51.1</b>	<b>Overview</b> . . . . .	<b>211</b>
<b>51.2</b>	<b>Supported Platforms</b> . . . . .	<b>211</b>
<b>51.3</b>	<b>System Requirement</b> . . . . .	<b>212</b>
51.3.1	Hardware requirements . . . . .	212
51.3.2	Software requirements . . . . .	212
<b>51.4</b>	<b>Getting Started</b> . . . . .	<b>212</b>
51.4.1	Hardware settings . . . . .	212
51.4.2	Prepare the example . . . . .	212
51.4.3	Run the example . . . . .	212

**Chapter 52**  
**I2C Example with other methods**

<b>52.1</b>	<b>Overview</b> . . . . .	<b>215</b>
<b>52.2</b>	<b>Supported Platforms</b> . . . . .	<b>215</b>
<b>52.3</b>	<b>System Requirement</b> . . . . .	<b>216</b>
52.3.1	Hardware requirements . . . . .	216
52.3.2	Software requirements . . . . .	216
<b>52.4</b>	<b>Getting Started</b> . . . . .	<b>216</b>
52.4.1	Hardware settings . . . . .	216
52.4.2	Prepare the example . . . . .	222
52.4.3	Run the example . . . . .	223
52.4.3.1	I2C blocking . . . . .	223
52.4.3.2	I2C non-blocking . . . . .	223
52.4.3.3	I2C callback . . . . .	224
52.4.3.4	I2C polling . . . . .	224

**Chapter 53**  
**iRTC Example**

<b>53.1</b>	<b>Overview</b> . . . . .	<b>225</b>
<b>53.2</b>	<b>Supported Platforms</b> . . . . .	<b>225</b>

Section number	Title	Page
<b>53.3</b>	<b>System Requirement</b> . . . . .	<b>225</b>
53.3.1	Hardware requirements . . . . .	225
<b>53.4</b>	<b>Getting Started</b> . . . . .	<b>225</b>
53.4.1	Hardware settings . . . . .	225
53.4.2	Prepare the example . . . . .	225
53.4.3	Run the example . . . . .	226

## Chapter 54 Low Power Serial Communication Interface (LPSCI) Example with Other Methods

<b>54.1</b>	<b>Overview</b> . . . . .	<b>227</b>
<b>54.2</b>	<b>Supported Platforms</b> . . . . .	<b>227</b>
<b>54.3</b>	<b>System Requirement</b> . . . . .	<b>227</b>
54.3.1	Hardware requirements . . . . .	227
54.3.2	Software requirements . . . . .	228
<b>54.4</b>	<b>Getting Started</b> . . . . .	<b>228</b>
54.4.1	Hardware settings . . . . .	228
54.4.2	Prepare the example . . . . .	228
54.4.3	Run the example . . . . .	228
54.4.3.1	LPSCI blocking . . . . .	228
54.4.3.2	LPSCI non-blocking . . . . .	228
54.4.3.3	LPSCI DMA blocking . . . . .	229
54.4.3.4	LPSCI DMA non-blocking . . . . .	229
54.4.3.5	LPSCI polling . . . . .	229

## Chapter 55 LPTMR Example

<b>55.1</b>	<b>Overview</b> . . . . .	<b>231</b>
<b>55.2</b>	<b>Supported Platforms</b> . . . . .	<b>231</b>
<b>55.3</b>	<b>System Requirement</b> . . . . .	<b>232</b>
55.3.1	Hardware requirements . . . . .	232
55.3.2	Software requirements . . . . .	232
<b>55.4</b>	<b>Getting Started</b> . . . . .	<b>232</b>
55.4.1	Hardware settings . . . . .	232



Section number	Title	Page
55.4.2	Prepare the example . . . . .	232
55.4.3	Run the example . . . . .	232

## Chapter 56

### Low Power Universal Asynchronous Receiver/Transmitter (LPUART) Example with other methods

<b>56.1</b>	<b>Overview . . . . .</b>	<b>235</b>
<b>56.2</b>	<b>Supported Platforms . . . . .</b>	<b>235</b>
<b>56.3</b>	<b>System Requirement . . . . .</b>	<b>235</b>
56.3.1	Hardware requirements . . . . .	235
56.3.2	Software requirements . . . . .	236
<b>56.4</b>	<b>Getting Started . . . . .</b>	<b>236</b>
56.4.1	Hardware settings . . . . .	236
56.4.2	Hardware settings . . . . .	236
56.4.3	Prepare the example . . . . .	237
56.4.4	Run the example . . . . .	237
56.4.5	Run the example . . . . .	237
56.4.5.1	FLEXIO_UART interrupt way . . . . .	237
56.4.5.2	LPUART non-blocking . . . . .	238
56.4.5.3	LPUART DMA blocking . . . . .	238
56.4.5.4	LPUART DMA non-blocking . . . . .	238
56.4.5.5	LPUART polling . . . . .	238

## Chapter 57

### LTC AES Example

<b>57.1</b>	<b>Overview . . . . .</b>	<b>239</b>
<b>57.2</b>	<b>Supported Platforms . . . . .</b>	<b>239</b>
<b>57.3</b>	<b>System Requirement . . . . .</b>	<b>239</b>
57.3.1	Hardware requirements . . . . .	239
57.3.2	Software requirements . . . . .	239
<b>57.4</b>	<b>Getting Started . . . . .</b>	<b>239</b>
57.4.1	Hardware settings . . . . .	239
57.4.2	Prepare the example . . . . .	239
57.4.3	Run the example . . . . .	240

Section number	Title	Page
<b>Chapter 58</b>		
<b>MMAU Example</b>		
<b>58.1</b>	<b>Overview</b> . . . . .	<b>243</b>
<b>58.2</b>	<b>Supported Platforms</b> . . . . .	<b>243</b>
<b>58.3</b>	<b>System Requirement</b> . . . . .	<b>243</b>
58.3.1	Hardware requirements . . . . .	243
<b>58.4</b>	<b>Getting Started</b> . . . . .	<b>243</b>
58.4.1	Hardware settings . . . . .	243
58.4.2	Prepare the example . . . . .	243
58.4.3	Run the example . . . . .	244
<b>Chapter 59</b>		
<b>MPU Example</b>		
<b>59.1</b>	<b>Overview</b> . . . . .	<b>245</b>
<b>59.2</b>	<b>Supported Platforms</b> . . . . .	<b>245</b>
<b>59.3</b>	<b>System Requirement</b> . . . . .	<b>245</b>
59.3.1	Hardware requirements . . . . .	245
59.3.2	Software requirements . . . . .	245
<b>59.4</b>	<b>Getting Started</b> . . . . .	<b>246</b>
59.4.1	Hardware settings . . . . .	246
59.4.2	Prepare the example . . . . .	246
59.4.3	Run the example . . . . .	246
<b>Chapter 60</b>		
<b>PDB Example</b>		
<b>60.1</b>	<b>Overview</b> . . . . .	<b>247</b>
<b>60.2</b>	<b>Supported Platforms</b> . . . . .	<b>247</b>
<b>60.3</b>	<b>System Requirement</b> . . . . .	<b>247</b>
60.3.1	Hardware requirements . . . . .	247
60.3.2	Software requirements . . . . .	248
<b>60.4</b>	<b>Getting Started</b> . . . . .	<b>248</b>

Section number	Title	Page
60.4.1	Hardware settings . . . . .	248
60.4.2	Prepare the example . . . . .	248
60.4.3	Run the example . . . . .	248

## Chapter 61 PIT Example

<b>61.1</b>	<b>Overview . . . . .</b>	<b>249</b>
<b>61.2</b>	<b>Supported Platforms . . . . .</b>	<b>249</b>
<b>61.3</b>	<b>System Requirement . . . . .</b>	<b>250</b>
61.3.1	Hardware requirements . . . . .	250
61.3.2	Software requirements . . . . .	250
<b>61.4</b>	<b>Getting Started . . . . .</b>	<b>250</b>
61.4.1	Hardware settings . . . . .	250
61.4.2	Prepare the example . . . . .	250
61.4.3	Run the example . . . . .	250

## Chapter 62 QSPI Example with other methods

<b>62.1</b>	<b>Overview . . . . .</b>	<b>253</b>
<b>62.2</b>	<b>Supported Platforms . . . . .</b>	<b>253</b>
<b>62.3</b>	<b>System Requirement . . . . .</b>	<b>253</b>
62.3.1	Hardware requirements . . . . .	253
62.3.2	Software requirements . . . . .	253
<b>62.4</b>	<b>Getting Started . . . . .</b>	<b>253</b>
62.4.1	Hardware settings . . . . .	253
62.4.2	Prepare the example . . . . .	254
62.4.3	Run the example . . . . .	254

## Chapter 63 QuadTmr Example

<b>63.1</b>	<b>Overview . . . . .</b>	<b>255</b>
<b>63.2</b>	<b>Supported Platforms . . . . .</b>	<b>255</b>

Section number	Title	Page
<b>63.3</b>	<b>System Requirement</b> . . . . .	<b>255</b>
63.3.1	Hardware requirements . . . . .	255
<b>63.4</b>	<b>Getting Started</b> . . . . .	<b>255</b>
63.4.1	Hardware settings . . . . .	255
63.4.2	Prepare the example . . . . .	256
63.4.3	Run the example . . . . .	256

## Chapter 64 RNGA Example

<b>64.1</b>	<b>Overview</b> . . . . .	<b>257</b>
<b>64.2</b>	<b>Supported Platforms</b> . . . . .	<b>257</b>
<b>64.3</b>	<b>System Requirement</b> . . . . .	<b>257</b>
64.3.1	Hardware requirements . . . . .	257
64.3.2	Software requirements . . . . .	258
<b>64.4</b>	<b>Getting Started</b> . . . . .	<b>258</b>
64.4.1	Hardware settings . . . . .	258
64.4.2	Prepare the example . . . . .	258
64.4.3	Run the example . . . . .	258

## Chapter 65 RTC Example

<b>65.1</b>	<b>Overview</b> . . . . .	<b>259</b>
<b>65.2</b>	<b>Supported Platforms</b> . . . . .	<b>259</b>
<b>65.3</b>	<b>System Requirement</b> . . . . .	<b>260</b>
65.3.1	Hardware requirements . . . . .	260
65.3.2	Software requirements . . . . .	260
<b>65.4</b>	<b>Getting Started</b> . . . . .	<b>260</b>
65.4.1	Hardware settings . . . . .	260
65.4.2	Prepare the example . . . . .	260
65.4.3	Run the example . . . . .	260

Section number	Title	Page
<b>Chapter 66</b>		
<b>SDHC SDCard Example</b>		
<b>66.1</b>	<b>Overview</b> . . . . .	<b>263</b>
<b>66.2</b>	<b>Supported Platforms</b> . . . . .	<b>263</b>
<b>66.3</b>	<b>System Requirement</b> . . . . .	<b>263</b>
66.3.1	Hardware requirements . . . . .	263
66.3.2	Software requirements . . . . .	263
<b>66.4</b>	<b>Getting Started</b> . . . . .	<b>264</b>
66.4.1	Hardware settings . . . . .	264
66.4.2	Prepare the example . . . . .	264
66.4.3	Run the example . . . . .	264

**Chapter 67**  
**SDRAMC Example**

<b>67.1</b>	<b>Overview</b> . . . . .	<b>267</b>
<b>67.2</b>	<b>Supported Platforms</b> . . . . .	<b>267</b>
<b>67.3</b>	<b>System Requirement</b> . . . . .	<b>267</b>
67.3.1	Hardware requirements . . . . .	267
67.3.2	Software requirements . . . . .	267
<b>67.4</b>	<b>Getting Started</b> . . . . .	<b>267</b>
67.4.1	Hardware settings . . . . .	267
67.4.2	Prepare the example . . . . .	268
67.4.3	Run the example . . . . .	268

**Chapter 68**  
**SLCD Example**

<b>68.1</b>	<b>Overview</b> . . . . .	<b>269</b>
<b>68.2</b>	<b>Supported Platforms</b> . . . . .	<b>269</b>
<b>68.3</b>	<b>System Requirement</b> . . . . .	<b>269</b>
68.3.1	Hardware requirements . . . . .	269
68.3.2	Software requirements . . . . .	269

Section number	Title	Page
<b>68.4</b>	<b>Getting Started</b> . . . . .	<b>269</b>
68.4.1	Hardware settings . . . . .	269
68.4.2	Prepare the example . . . . .	269
68.4.3	Run the example . . . . .	270

## Chapter 69 Smart Card Example

<b>69.1</b>	<b>Overview</b> . . . . .	<b>271</b>
<b>69.2</b>	<b>Supported Platforms</b> . . . . .	<b>271</b>
<b>69.3</b>	<b>System Requirement</b> . . . . .	<b>271</b>
69.3.1	Hardware requirements . . . . .	271
69.3.2	Software requirements . . . . .	271
<b>69.4</b>	<b>Getting Started</b> . . . . .	<b>272</b>
69.4.1	Hardware settings . . . . .	272
69.4.2	Prepare the example . . . . .	272
69.4.3	Run the example . . . . .	272

## Chapter 70 SPI Example with other methods

<b>70.1</b>	<b>Overview</b> . . . . .	<b>275</b>
<b>70.2</b>	<b>Supported Platforms</b> . . . . .	<b>275</b>
<b>70.3</b>	<b>System Requirement</b> . . . . .	<b>275</b>
70.3.1	Hardware requirements . . . . .	275
70.3.2	Software requirements . . . . .	276
<b>70.4</b>	<b>Getting Started</b> . . . . .	<b>276</b>
70.4.1	Hardware settings . . . . .	276
70.4.2	Prepare the example . . . . .	279
70.4.3	Run the example . . . . .	280
70.4.3.1	SPI blocking Master - Slave . . . . .	280
70.4.3.2	SPI non-blocking Master - Slave . . . . .	280
70.4.3.3	SPI DMA blocking Master - Slave . . . . .	281
70.4.3.4	SPI DMA non-blocking Master - Slave . . . . .	282
70.4.3.5	SPI polling Master - Slave . . . . .	283
70.4.3.6	SPI loopback . . . . .	283

Section number	Title	Page
<b>Chapter 71</b>		
<b>SPI SDCard Example</b>		
<b>71.1</b>	<b>Overview</b> . . . . .	<b>285</b>
<b>71.2</b>	<b>Supported Platforms</b> . . . . .	<b>285</b>
<b>71.3</b>	<b>System Requirement</b> . . . . .	<b>285</b>
71.3.1	Hardware requirements . . . . .	285
71.3.2	Software requirements . . . . .	285
<b>71.4</b>	<b>Getting Started</b> . . . . .	<b>285</b>
71.4.1	Hardware settings . . . . .	285
71.4.2	Prepare the example . . . . .	286
71.4.3	Run the example . . . . .	286
<b>Chapter 72</b>		
<b>TPM Example</b>		
<b>72.1</b>	<b>Overview</b> . . . . .	<b>289</b>
<b>72.2</b>	<b>Supported Platforms</b> . . . . .	<b>289</b>
<b>72.3</b>	<b>System Requirement</b> . . . . .	<b>289</b>
72.3.1	Hardware requirements . . . . .	289
72.3.2	Software requirements . . . . .	289
<b>72.4</b>	<b>Getting Started</b> . . . . .	<b>290</b>
72.4.1	Hardware settings . . . . .	290
72.4.2	Prepare the example . . . . .	290
72.4.3	Run the example . . . . .	290
<b>Chapter 73</b>		
<b>TSI Example</b>		
<b>73.1</b>	<b>Overview</b> . . . . .	<b>291</b>
<b>73.2</b>	<b>Supported Platforms</b> . . . . .	<b>291</b>
<b>73.3</b>	<b>System Requirement</b> . . . . .	<b>291</b>
73.3.1	Hardware requirements . . . . .	291
73.3.2	Software requirements . . . . .	291

Section number	Title	Page
<b>73.4</b>	<b>Getting Started</b> . . . . .	<b>291</b>
73.4.1	Hardware settings . . . . .	291
73.4.2	Prepare the example . . . . .	292
73.4.3	Run the example . . . . .	292

## Chapter 74 Universal Asynchronous Receiver/Transmitter (UART) Example with other methods

<b>74.1</b>	<b>Overview</b> . . . . .	<b>293</b>
<b>74.2</b>	<b>Supported Platforms</b> . . . . .	<b>293</b>
<b>74.3</b>	<b>System Requirement</b> . . . . .	<b>294</b>
74.3.1	Hardware requirements . . . . .	294
74.3.2	Software requirements . . . . .	294
<b>74.4</b>	<b>Getting Started</b> . . . . .	<b>294</b>
74.4.1	Hardware settings . . . . .	294
74.4.2	Prepare the example . . . . .	294
74.4.3	Run the example . . . . .	295
74.4.3.1	UART blocking . . . . .	295
74.4.3.2	UART non-blocking . . . . .	295
74.4.3.3	UART DMA blocking . . . . .	295
74.4.3.4	UART DMA non-blocking . . . . .	295
74.4.3.5	UART polling . . . . .	296

## Chapter 75 WDOG Example

<b>75.1</b>	<b>Overview</b> . . . . .	<b>297</b>
<b>75.2</b>	<b>Supported Platforms</b> . . . . .	<b>297</b>
<b>75.3</b>	<b>System Requirement</b> . . . . .	<b>297</b>
75.3.1	Hardware requirements . . . . .	297
75.3.2	Software requirements . . . . .	298
<b>75.4</b>	<b>Getting Started</b> . . . . .	<b>298</b>
75.4.1	Hardware settings . . . . .	298
75.4.2	Prepare the example . . . . .	298
75.4.3	Run the example . . . . .	298



---

## Chapter 1 Introduction

Kinetis SDK (KSDK) includes applications which provide examples that show how to use KSDK drivers. This document describes the applications and provides instructions to configure each application (if available). The document also describes the required hardware setup and steps to run the applications.

For the latest version of this and other Kinetis SDK documents, see the Kinetis SDK homepage ([www.freescale.com/ksdk](http://www.freescale.com/ksdk)).



## Chapter 2

# ADC Hardware Trigger Demo

This demo application demonstrates how to use the ADC driver with various hardware triggers.

### 2.1 Overview

This is an ADC demo application which shows how to use different hardware trigger sources to handle the ADC hardware trigger function. These trigger sources are supported:

- PIT (Periodic Interrupt Timer)
- PDB (Programmable Delay Block)
- LPTMR (Low Power Timer)
- TPM (Timer PWM Module)

#### 2.1.1 Trigger by PIT

The Periodic Interrupt Timer (PIT) is a period timer source and the ADC hardware trigger event. Because the PIT trigger event can only be used to trigger one of the ADC channels (mux A or B), this demo uses PIT as a trigger source for the ADCx channel 0. The PIT triggers the ADC in a fixed frequency and the demo gets the ADC conversion result in the ADC Conversion Complete (COCO) interrupt. TWR-KV10Z32 and TWR-KV11Z75M does not support PIT trigger, due to no PIT on the silicon.

#### 2.1.2 Trigger by PDB

The Programmable Delay Block (PDB) is a continuous trigger event for ADC. It uses the software trigger as the first trigger input event and turns on the PDB continuous mode to generate a period trigger source. Because the PDB can trigger different channels inside one ADC instance, this demo shows the Ping-Pong triggering which occurs by sampling the channel 0/1 with the PDB Pre-trigger A/B channel. FRDM-KL26Z and MRB-KW01 does not support PDB trigger, because PDB is not present neither on KL26 nor on KW01 silicon.

#### 2.1.3 Trigger by LPTMR

The Low Power Timer (LPTMR) is a period timer source and the ADC hardware trigger event. Because the LPTMR trigger event can only be used to trigger one of the ADC channels (channel 0 or 1), this demo uses the LPTMR as a trigger source for the ADCx channel 0. The LPTMR triggers the ADC in a fixed frequency and the demo gets the ADC conversion result in the ADC Conversion Complete (COCO) interrupt.

## Supported Platforms

### 2.1.4 Input signal for ADC

Use the DAC module to generate a sine wave as the ADC input on the DAC0\_OUT pin. Normally, the DAC0\_OUT is internally connected to the ADC0\_SE23 (DAC0\_OUT is a source of ADC0\_SE23), there is no need to connect any external signals for this demo. For TWR-KV11, ADC1\_SE4 is used

Boards listed below need external sine wave connected either because of lack of the DAC hardware feature support or lack of the SoC/Board signal connection support. For FRDM-KV10Z, use external generator to generate a sine wave on the ADC0\_SE6 pin (J2-1).

- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KW40Z
- MRB-KW01
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32

This demo samples the input digital signal from the ADC0\_SE23 (ADC0\_SE6 on FRDM-KV10Z) pin and records each sample point with the appropriate amplitude. After 2 period samples are complete, it prints out the rough shape of the signal wave on the debug console like a primitive oscilloscope.

## 2.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK ADC Hardware Trigger demo.

The adc\_lptmr\_trigger demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW40Z
- MRB-KW01

- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

The adc\_pdb\_trigger demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

The adc\_pit\_trigger demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV31F
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M

## Getting Started

- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV31F120M

The adc\_tpm\_trigger demo Supported Platforms:

- FRDM-KL03
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- MRB-KW01
- TWR-KL43Z48M

## 2.3 System Requirement

### 2.3.1 Hardware requirements

- J-Link ARM<sup>®</sup>
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 2.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/adc\_hw\_trigger/<hw\_trigger>/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 2.4 Getting Started

### 2.4.1 Hardware configuration

For the MRB-KW01: It is necessary to short jumpers J10 and J11 to connect the ADC references. If the A-DCO\_SE23 or internal DAC connection is used it is necessary to disconnect J7 to open PTE30 connection with the RESET of the RADIO part. Also analog function for PTE30 - DAC output is necessary on the mrb-kw01 (default is GPIO for RADIO part reset).

## 2.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 2.5 Run the demo

1. Select and open one project from the four projects available: `adc_pit_trigger`, `adc_lptmr_trigger` and `adc_pdb_trigger`.
2. Open the UART console on a PC and also connect external sine wave generator to ADC input if necessary.
3. Download and run the program on the target.
4. The signal waveform is displayed on the console.

## 2.6 Customization Options

This demo application is customizable to show different kinds of input signal waves.

### 2.6.1 Default configurations

The configuration macro is located in the `adc_hw_trigger.h` header file.

#### 2.6.1.1 ADC configurations

1. Use ADC0 instance.
2. Use ADC\_SE23 input pin as sample pin. (ADC\_SE6 for FRDM-KV10, ADC1\_SE4 For TWR-K-V11)
3. Use VREFH/L as reference voltage.

For TWR-KM34Z75M

1. Use ADC0 instance.
2. Use ADC\_SE15 input pin as sample pin.
3. Use VREFH/L as reference voltage.

## Customization Options

### 2.6.1.2 Sample frequency

The default sample rate is 1000 Hertz, which enables the demo application to get 100 samples per two periods. To change the sample rate, see the next section.

### 2.6.2 Configure the number of samples

Printing of the signal wave shape depends on the console size. A console can be 100x40. To get the best printing effect, align the number of samples to the console column numbers and convert the amplitude range to the [0, row - 1] range. The console column number should be same as sample numbers. Configuring the number of samples means configuring the console column size:

```
#define CHART_ROWS 30U // chart row for sampled data
#define CHART_COLS 100U // chart column for sampled data
#define NR_SAMPLES 100U // number of samples in one period
```

### 2.6.3 Configure the signal frequency

Change the following macro to configure the desired frequency in Hz units.

```
#define INPUT_SIGNAL_FREQ 20U // in Hz
```

### 2.6.4 Configure the ADC instance

Change the ADC\_INST macro to configure the ADC instance you want to use.

```
#define ADC_INST 0U // ADC instance
```

### 2.6.5 Configure the ADC input pin

If you do not use the DAC0\_OUT as a input signal, disable the macro in the project:

```
// #USE_DAC_OUT_AS_SOURCE
```

After disabling the DAC output, configure one ADC input source pin to get the signal:

```
#define ADC_INPUT_CHAN 23U // default input signal channel
#define ADC_INPUT_CHAN 6U // default input signal channel for FRDM-KV10
#define ADC_INPUT_CHAN 4U // default input signal channel for TWR-KV11
```

For TWR-KM34Z75M

```
#define ADC_INPUT_CHAN 15U // default input signal channel
```



## Chapter 3

# ADC Low Power Demo

This demo application demonstrates how to use the ADC drivers in low power modes.

### 3.1 Overview

The ADC Low Power Demo project is a demonstration program that uses the KSDK software. The microcontroller is set to a very low power stop (VLPS) mode, and every 500 ms an interrupt wakes up the ADC module and takes the current temperature of the microcontroller. While the temperature remains within boundaries, both LEDs are off. If the temperature is higher than average, a red LED comes on. If it is lower, a blue LED (orange LED for TWR-KV10, TWR-KV11Z75M) comes on. This demo provides an example to show how ADC works during a VLPS mode and a simple debugging, "golden" project.

### 3.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis SDK ADC Low Power demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

## Getting Started

- TWR-KW24D512
- USB-KW24D512
- USB-KW40Z

### 3.3 System Requirement

#### 3.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 3.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/adc\_low\_power/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

### 3.4 Getting Started

The ADC Low Power project is designed to work with the Tower System or in a stand alone setting.

#### 3.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

#### 3.4.2 Run the demo

1. Set your target board in a place where the temperature is constant.
2. Press the reset button on your development board.

3. "ADC LOW POWER DEMO" message and some instructions should be displayed on the terminal.
4. Wait until the green or white LED light turns on.
5. Increment or decrement the temperature to see the changes.



## Chapter 4

### AFE Qtimer Demo

This demo application demonstrates two AFE channels sampling external analog signals and one channel can monitor AC signal's frequency.

#### 4.1 Overview

The AFE Qtimer Demo project is a demonstration program that uses the KSDK software. It implements the following features:

- Two AFE channels(channel 2&3) sample external analog signals.
- If the external analog signal is AC signal, with internal CMP1 and Qtimer0, one AFE channel(channel 2) can also monitor the external signal's frequency. This is typical use case to monitor the grid frequency(e.g., 50 Hz) in metering field.
- By default users use debug console to output AFE channel values sampling and frequency monitoring.
- Implement Freemaster interface on this demo, users can use Freemaster GUI to check the result as another option.
- Freemaster download: [http://www.freescale.com/webapp/sps/download/license.-jsp?colCode=FMASW&location=null&fsrch=1&sr=6&pageNum=1&Parent\\_nodeId=&Parent\\_pageType=](http://www.freescale.com/webapp/sps/download/license.-jsp?colCode=FMASW&location=null&fsrch=1&sr=6&pageNum=1&Parent_nodeId=&Parent_pageType=)

#### 4.2 Supported Platforms

This Tower System module is supported by the KSDK AFE Qtimer demo.

- TWR-KM34Z75M

#### 4.3 Getting Started

##### 4.3.1 Hardware Settings

- Use external power supply to input DC analog signals to AFE channel 2&3(J31 pin10/12/14/16), AFE sample can support both single-ended or differential mode;

Board	Connects To	DC Power Supply
AFE Channel 2 EXT_SD_ADP2 J31 pin10	->	DC Power source 1 positive end
AFE Channel 2 EXT_SD_ADM2 J31 pin12	->	DC Power source 1 negative end
AFE Channel 3 EXT_SD_ADP3 J31 pin14	->	DC Power source 2 positive end

## Getting Started

AFE Channel 3 EXT_SD_ADM3 J31 pin16	->	DC Power source 2 negative end
--	----	--------------------------------

- To monitor frequency, use a signal generator to input the AC sine signal to the AFE channel 2(J31 pin10/12).

Board	Connects To	Signal Generator
AFE Channel 2 EXT_SD_ADP2 J31 pin10	->	Signal Generator positive end
AFE Channel 2 EXT_SD_ADM2 J31 pin12	->	Signal Generator negative end

### 4.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 4.3.3 Run the demo

#### 1.AFE two channels voltage sampling

- Use the DC power supply to input the two external signals from 0~500 mV to AFE channel 2&3. The converted values (value\_ch2 and value\_ch3) change with the external input on the debug console.

#### 2.External AC signal frequency monitoring.

- Use a signal generator to input one sine waveform signal (e.g., Amplitude=500 mV,Offset=0 mV, Frequency=50 Hz) to AFE channel 2. The frequency value is captured by the "freq\_tmr" variable on the debug console. The AC signal frequency ranges between about 25 Hz~1000 Hz. The recommended input value is the 50 Hz for the grid frequency simulation.

The printed log is displayed in the terminal window as shown below.

```
value_ch2 = 0xffbe5eb0
value_ch3 = 0x13d28
freq_tmr = 50.0
value_ch2 = 0xffbe56ea
```

```
value_ch3 = 0x15a3e  
freq_tmr = 49.975  
value_ch2 = 0xffbe5567  
value_ch3 = 0x15893  
freq_tmr = 50.1
```





## Chapter 5

# BLDC Sensorless Demo

This demo application demonstrates the software portion (hardware/chip independent) of the 16-bit implementation of a sensorless three phase brushless DC (BLDC) motor control application. The demo supports both IAR and KEIL versions.

### 5.1 Overview

The BLDC sensorless Control Demo project is a demonstration program that uses the KSDK software. The application software uses the concept of an isolated algorithm software and hardware. This software approach enables easy porting of an application to other devices or platforms. The application software is divided in two sections:

- BLDC motor control algorithm process input variables to output variables and flags.
- TWR board hardware and microprocessor serves as a bridge between hardware peripheral modules and BLDC motor control software algorithm.

### 5.2 Supported Platforms

This Tower System module is supported by the Kinetis software development kit.

- TWR-KV10Z32
- TWR-KV11Z75M

### 5.3 System Requirement

#### 5.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 5.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/demo_apps/bldc_demo/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## Getting Started

### 5.4 Getting Started

This table lists the FTM channels and MCU pins and corresponding LEDs for this demo application. This table also lists which connections should be made (if any) to ensure proper demo operation.

#### 1. TWR-MC-LV3PH jumper settings

jumper	position
<b>J2</b>	1-2
<b>J3</b>	1-2
<b>J10</b>	2-3
<b>J11</b>	2-3
<b>J12</b>	2-3
<b>J13</b>	2-3
<b>J14</b>	1-2

#### 2. TWR-KV10Z32 jumper settings

jumper	position	jumper	position	jumper	position
<b>J1</b>	2-3	<b>J10</b>	1-2	<b>J21</b>	3-4
<b>J2</b>	short	<b>J11</b>	open	<b>J22</b>	3-4
<b>J3</b>	2-3	<b>J12</b>	open	<b>J25</b>	open
<b>J4</b>	short	<b>J13</b>	open	<b>J26</b>	short
<b>J5</b>	short	<b>J14</b>	open	<b>J27</b>	short
<b>J7</b>	1-2	<b>J18</b>	2-3	<b>J28</b>	short
<b>J8</b>	1-2	<b>J19</b>	2-3	<b>J29</b>	1-2
<b>J9</b>	1-2	<b>J20</b>	1-2	–	–

#### 1. TWR-KV11Z75M jumper settings

jumper	position	jumper	position	jumper	position
<b>J1</b>	short	<b>J9</b>	1-2, 3-4	<b>J505</b>	3-4
<b>J2</b>	1-2	<b>J10</b>	short	<b>J506</b>	3-4
<b>J4</b>	1-2	<b>J11</b>	1-2	<b>J523</b>	open
<b>J5</b>	5-6, 7-8	<b>J12</b>	short	<b>J512</b>	1-2
<b>J6</b>	1-2, 3-4	<b>J13</b>	1-2	<b>J519</b>	1-2
<b>J7</b>	open	<b>J14</b>	short	<b>J517</b>	2-J518
<b>J8</b>	1-2	<b>J17</b>	2-3	<b>J524</b>	open

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board. Note that, because of board limitations, if the power is not supplied to OpenSDA, the MCU reset pin is in low

level.

### 5.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Connect three phases of the BLDC motor to J5 in the TWR-MC-LV3PH board.
5. Supply 24 V digital power to J1 in the TWR-MC-LV3PH board.
6. Either press the reset button on your board or launch the debugger in the IDE to start running the demo.

For detailed instructions, see the appropriate board User's Guide.

### 5.4.2 Run the demo

The application can be controlled using one interface:

- Up / Down buttons on the TWR board
  1. After the power supply is plugged into the TWR-MC-LV3PH, the motor is ready to run.
  2. Press the reset button on the development board.
  3. Pressing the Up button increases the speed by 500 RPM. The motor starts rotating in the clockwise direction if it is not spinning, or decreases speed if the direction of the rotation is counter-clockwise.
  4. Pressing the Down button decreases the speed by 500 RPM. The motor starts rotating in the counter-clockwise direction if it is not spinning, or decreases speed if the direction of the rotation is clockwise.
  5. Pressing the buttons beyond this point increases or decreases the required speed within the speed limit -5000 to 5000 RPM.
  6. If both buttons are pressed for more than 2 seconds, the demonstration mode is switched on (or demonstration mode is switched off if it is on)



## Chapter 6

### Bubble Level FTM Demo

This demo application utilizes the on-board accelerometer to implement a bubble level.

#### 6.1 Overview

The bubble level application demonstrates basic usage of the on-board accelerometer to implement a bubble level. A bubble level utilizes two axes to visually show deviation from a level plane (0 degrees) on a given access. This demo uses the FTM to modulate the duty cycle of two onboard LEDs to gradually increase LED intensity as the board deviates from a level state.

Optionally, if you would like to observe the raw accelerometer X-Y data, you can connect to the board's virtual COM port.

This application is loaded onto the board at the factory for supported hardware platforms.

#### 6.2 Supported Platforms

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- TWR-K80F150M

#### 6.3 System Requirement

##### 6.3.1 Hardware requirements

- USB A to micro AB cable
- Personal Computer

##### 6.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/bubble\_level\_ftm/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 6.4 Getting Started

##### 6.4.1 Hardware Settings

The bubble level application does not call for any special hardware configuration. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state

## Run the demo

when running this demo.

### 6.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. (Optional) Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the Getting Started with Kinetis SDK document.

### 6.5 Run the demo

When the board is programmed, simply tilt the board to see the LED illuminate. One LED color indicates X-axis variation while another indicates Y-axis variation.

## Chapter 7

### Bubble Level TPM Demo

This demo application utilizes the on-board accelerometer to implement a bubble level.

#### 7.1 Overview

The bubble level application demonstrates basic usage of the on-board accelerometer to implement a bubble level. A bubble level utilizes two axes to visually show deviation from a level plane (0 degrees) on a given axis. This demo uses the TPM to modulate the duty cycle of two onboard LEDs to gradually increase LED intensity as the board deviates from a level state.

Optionally, if you would like to observe the raw accelerometer X-Y data, you can connect to the board's virtual COM port.

This application is loaded onto the board at the factory for supported hardware platforms.

#### 7.2 Supported Platforms

- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z

#### 7.3 System Requirement

##### 7.3.1 Hardware requirements

- USB A to micro AB cable
- Personal Computer

##### 7.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/bubble\_level\_tpm/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## Run the demo

### 7.4 Getting Started

#### 7.4.1 Hardware Settings

The bubble level application does not call for any special hardware configuration. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

#### 7.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. (Optional) Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the Getting Started with Kinetis SDK document.

### 7.5 Run the demo

When the board is programmed, simply tilt the board to see the LED illuminate. One LED color indicates X-axis angle while another indicates Y-axis angle.



## Chapter 8

### DAC ADC Demo

This demo application demonstrates the DAC and ADC demo.

#### 8.1 Overview

This application demonstrates how to configure the DAC and set the output on the DAC using software. It also demonstrates how to configure the ADC in 'Blocking Mode' and read ADC values.

#### 8.2 Supported Platforms

This demo supports these Freescale Freedom development platforms and Tower System modules:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

#### 8.3 System Requirement

##### 8.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal

## Getting Started

- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 8.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/dac\_adc\_demo/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

## 8.4 Getting Started

### 8.4.1 Hardware configuration

For the MRB-KW01 it is necessary: To short jumpers J10 and J11 to connect the ADC references. To disconnect J7 to open PTE30 connection with the RESET of the RADIO part. Also analog function for PTE30 - DAC output is necessary on the mrb-kw01 (default is GPIO for RADIO part reset). This is done in hardware\_init() function.

### 8.4.2 Hardware Settings

This table shows the connections that are required for each of the supported platforms. Not mentioned platforms use the internal connection.

Platform	DAC Out		ADC In	
	Pin Name	Board Location	Pin Name	Board Location
<b>FRDM-K22F</b>	DAC0_OUT	J24-11	PTB0/ADC0_SE8	J24-2
<b>FRDM-KL25Z</b>	PTE30/DAC0_OUT	J10-11	PTE20/ADC0_SE0	J10-1
<b>FRDM-K64F</b>	DAC0_OUT	J4-11	PTB2/ADC0_SE12	J4-2
<b>FRDM-KL43Z</b>	PTE30/DAC0_OUT	J4-11	PTE30/ADC0_SE23	J4-11
<b>FRDM-KL46Z</b>	PTE30/DAC0_OUT	J4-11	PTE20/DIFF_ADC0_DP	J4-1
<b>FRDM-KW40Z</b>	PTB18/DAC0_OUT	J25-11	PTB18/ADC0_SE4	J25-11
<b>TWR-K21D50M</b>	DAC0_OUT	Primary Elevator - A32	PTB3/ADC0_SE13	Primary Elevator - B30
<b>TWR-K22F120M</b>	DAC0_OUT	Primary Elevator - A32	PTB0/ADC0_SE8	Primary Elevator - B27

<b>TWR-K24F120M</b>	DAC0_OUT	Primary Elevator - A32	ADC0_DP3	Primary Elevator - A29
<b>TWR-K60D100M</b>	DAC0_OUT	Primary Elevator - A32	PTB4/ADC1_SE10	Primary Elevator - B30
<b>TWR-K64F120M</b>	DAC0_OUT	Primary Elevator - A32	PTB4/ADC1_SE10	Primary Elevator - B27
<b>TWR-K65F180M</b>	DAC0_OUT	Primary Elevator - A32	ADC1_SE16	J24-1
<b>TWR-KV10Z32</b>	DAC0_OUT	J16-11	PTE17/ADC0_SE5	J16-6
<b>TWR-KV11Z75M</b>	DAC0_OUT	Primary Elevator - A32	PTE30/ADC1_SE4	Primary Elevator - A32
<b>TWR-KV31F120-M</b>	DAC0_OUT	Primary Elevator - A32	PTE2/ADC1_SE6a	Primary Elevator - B27
<b>TWR-K21F120M</b>	DAC0_OUT	Primary Elevator - A23	PTE2/ADC0_SE23	Primary Elevator - B23
<b>FRDM-KV10Z</b>	PTE30/DAC_OUT	J4-11	ADC0_SE6_RC	J2-1

### 8.4.3 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User's Guide for your board.

## 8.5 Run the demo

This example shows how to run the demo:

```
DAC ADC Demo!
```

```
See Kinetis SDK Demo Applications User's Guide document,
Chapter DAC ADC demo, for pins configuration information.
Press space bar to start demo.
```

The user is prompted to enter a voltage to output on the DAC:

## Key Functions

Select DAC output level:

1. 1.0 V
2. 1.5 V
3. 2.0 V
4. 2.5 V
5. 3.0 V

->

After entering a valid input, the ADC captures the voltage set by the DAC and displays the result in the terminal:

Select DAC output level:

1. 1.0 V
2. 1.5 V
3. 2.0 V
4. 2.5 V
5. 3.0 V

->3

ADC Value: 2471

ADC Voltage: 1.99

What next?:

1. Test another DAC output value.
2. Terminate demo.

->

At this point, the user can test another DAC output value or terminate the demo.

This configuration exhibits up to 2% error when reading back voltage.

## 8.6 Key Functions

### `uint8_t demo_start(demo_state_t *prevState)`

Prints out a welcome message and pins required by the demo.

Parameters

---

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

Returns

msg Returns the character entered into the terminal by the user.

**uint8\_t device\_config(demo\_state\_t \*prevState)**

Configures the DAC and the ADC. The DAC is configured for software updates. The ADC is set in 'Blocking Mode'.

Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

Returns

msg Returns 0.

**uint8\_t dac\_set(demo\_state\_t \*prevState)**

Sets output level on the DAC.

Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

Returns

msg Returns the character entered into the terminal by user.

**uint8\_t wait\_state(demo\_state\_t \*prevState)**

Performs a wait and possible state change based on the \*prevState.

Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

Returns

msg Returns 0.

**uint8\_t adc\_get(demo\_state\_t \*prevState)**

Gets ADC values from a channel connected to the DAC output.

## Key Functions

### Parameters

<i>*prevState</i>	Pointer to previous state for state machine.
-------------------	--

### Returns

msg Returns the character entered into the terminal by the user.

### **uint8\_t device\_deinit(demo\_state\_t \*prevState)**

Deinitializes the DAC and the ADC module following a user command to terminate the demo. Also frees allocated memory.

### Parameters

<i>*prevState</i>	Pointer to previous state for the state machine.
-------------------	--

### Returns

msg Returns 0.

### **uint8\_t demo\_end(demo\_state\_t \*prevState)**

Indicates to the user that the demo has been terminated.

### Parameters

<i>*prevState</i>	Pointer to previous state for the state machine.
-------------------	--

### Returns

msg Returns 0.



## Chapter 10

### Flash Demo

This demo application demonstrates how to use the Flash drivers.

#### 10.1 Overview

The Flash demo project shows how to erase, program, and perform swap (if available) on the Flash module.

Note:

1. A target exists for the Flash memory space. Because the demo operates with the two last sectors of the lower half and the whole upper half of program flash memory of the platforms with SWAP feature and the six last sector of the program flash of the platforms without the SWAP feature, the user should not store any program code or data in the above locations.
2. The flash swap demo fails if the tested board has already run swap command with the swap indicator address different from the values defined in the demo. To overcome this issue, erase the chip to uninitialized the swap system and rerun the demo.

- 

features include:

3. Read to non-volatile information memory region
4. Flash Erase by block or sector, including margin read options
5. Programming region defined by user
6. Flash verify support
7. Flash Swap (if supported on the device)
8. To ensure that other demos aren't affected, erase the chip to ensure the successful execution of the demos.

#### 10.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Flash demo.

Platforms with SWAP feature:

- TWR-K21D50M
- TWR-K21F120M
- TWR-K24F120M
- TWR-K60D100M
- FRDM-K64F
- TWR-K64F120M
- TWR-K65F180M

Platforms without SWAP feature:

- FRDM-K22F



## System Requirement

- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K22F120M
- TWR-K60D100M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z

## 10.3 System Requirement

### 10.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 10.3.2 Software requirements

- The project files are in this location: `<SDK_Install>/examples/<board>/demo_apps/flash_demo/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 10.4 Getting Started

The Flash Demo example code shows how to erase and program the Flash content and use the swap feature if it is supported on the device.

### 10.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 (9600 for FRDM-KL03Z48M) for baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

## 10.5 Commands/Directions

1. Select the Debug target from within the IDE and build the project selected for the target hardware. The default Debug target runs from flash and demonstrates the Swap feature for devices that support Swap (e.g. TWR-K64F120M).
2. Connect one end of the USB cable to a PC host and the other end to the OpenSDA connector on the board.
3. Open Terminal program such as TeraTerm, Putty, or Hyperterminal.
4. Configure the Terminal program to select the OpenSDA COMx port for the board using
  - 115200 8N1: 115200 baud, 8 data bits, No parity, 1 Stop bit.
  - Or FRDM-KL03Z48M 9600 8N1: 9600 baud, 8 data bits, No parity, 1 Stop bit.
5. Connect to the board with the debugger (download & debug), run the program, and view the Terminal messages for Flash operations being performed.
6. For devices that support Swap, the Flash\_Debug target copies (programs) the application that is running from the lower half to the upper half and then issues swap commands.
7. Flash memory blocks are swapped at the next reset. Disconnect debug session and hit the reset button on the board. Note: During swap, some memory locations depending on program flash size (e.g. for TWR-K64F120M: 0x7F100 & 0xFF100) are swapped and displayed on the terminal showing how the memory map changes.
8. For devices that do not support swap, view the terminal messages for Flash operations that are occurring for the demo.
9. Terminal displays the message "Flash Demo Complete!" when finished.  
Note: Callback functions are not currently supported during flash erase or program operations  
Note: For K22F and KV31, Flash erase and program operations are not allowed in High-Speed RUN modes. Therefore, the core clock speed is restricted to 80 MHz or less.



## Chapter 11

### FreeMASTER Demo

#### 11.1 Overview

This demo application demonstrates usage of the FreeMASTER graphical visualization tool.

#### Modules

- [FreeMASTER Demo Introduction](#)
- [FreeMASTER Demo User's Guide](#)

## FreeMASTER Demo Introduction

### 11.2 FreeMASTER Demo Introduction

This section provides an introduction to the FreeMASTER Demo application.

#### Overview

The FreeMASTER Demo application project shows how to integrate the Freescale FreeMASTER communication driver into a KSDK-based application. The user should be able to use the FreeMASTER tool running on Host PC and connect it over a serial line, CAN interface, or BDM cable to this demo application. The demo.pmp file can be opened in FreeMASTER tool project for a quick access to selected variables. The variables can be monitored in a text grid or in a graph. The user can also modify the values directly in the variable watch grid.

In addition to the variable monitoring, the FreeMASTER tool can be used to build rich graphical control panels for any embedded application. See more information on the FreeMASTER home page at "<http://www.freescale.com/freemaster>".

#### Supported Platforms

The FreeMASTER tool and the driver are two software packages distributed separately outside of KSDK. This KSDK release contains a copy of FreeMASTER driver version 1.8.1 which supports the whole Kinetis K and Kinetis L families and other platforms.

The KSDK freemaster\_demo application has been tested with these boards:

The freemaster\_demo\_flexcan demo Supported Platforms:

- TWR-K60D100M
- TWR-K64F120M

The freemaster\_demo\_lpuart demo Supported Platforms:

- FRDM-KL03Z (notice: cannot support the clock configuration of CLOCK\_SETUP=2 in kl03)
- TWR-KL43Z48M

The freemaster\_demo\_uart demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- TWR-K21D50M
- TWR-K22F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-KV10Z32
- TWR-KV31F120M

The freemaster\_demo\_usbcdc demo Supported Platforms:

- TWR-K22F120M

- TWR-K60D100M
- TWR-K64F120M
- TWR-KL43Z48M

However, the driver included in the src folder also supports other Kinetis platforms.

Get the FreeMASTER PC Host tool installer from the "<http://www.freescale.com/freemaster>" web site.

## 11.2.1 System Requirement

### 11.2.1.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## FreeMASTER Demo User's Guide

### 11.3 FreeMASTER Demo User's Guide

This chapter provides a user's guide to the FreeMASTER Demo application.

#### Getting Started

Open the demo application project in your favorite development environment. If the application project is not ready out of the box for your particular board, you can create an empty KSDK stationery project or reuse any other demo which works with your hardware. Adding FreeMASTER to an existing project is very easy by adding relevant source files available in the `demos/freemaster_demo/src/driver_v1_8` folder.

#### Connecting with UART (default)

Inspect the `freemaster_cfg.h` file to see the FreeMASTER configuration. The serial line is enabled by default. The default console port is used for communication with FreeMASTER PC Host tool. Do not use the demo with a console terminal tools like with most of the other KSDK examples. There are also other communications options available, such as BDM or CAN interface. See the user documentation for more information.

#### Running the FreeMASTER PC Host Tool

Compile and download the program to a target board. Connect serial cable to the PC host computer and start the FreeMASTER application (installer available at "<http://www.freescale.com/freemaster>"). Use the Start menu in the MS Windows environment to lookup the FreeMASTER launcher item. It is recommended that you also read the FreeMASTER user documentation available also in the Start menu group.

#### Using the FreeMASTER Demo project

In the FreeMASTER tool main window, press the Ctrl+K key first to select the serial COM port which connects your host computer with the target board. Select the 115200 as the default communication speed and press OK. Use the Ctrl+O to open the `demo.pmp` project file. The file is available in the same folder as the `freemaster_demo` application in the KSDK package. If everything goes well, you should see values of several variables in the variable watch grid in the bottom area of the main FreeMASTER window. Click the Oscilloscope item in the project tree on the left side and see the graphical representation of the selected variables.

#### Troubleshooting

If problems exist with the `freemaster_demo` application, try to start with the simplest `hello_world` example and a console terminal application to verify whether the serial line communication works well. The most

typical reason why FreeMASTER cannot communicate with the board is a wrong COM port selected on the host PC, or a wrong UART port selected on the target processor side or a bad communication speed.

### **Getting more information**

The FreeMASTER is a versatile and powerful tool in which you can create your own interactive graphical monitors and control panels for any embedded application. To understand how to use all FreeMASTER features, scripting and communication options, see a User's Guide included with the FreeMASTER installation package. The target-side communication driver is further described in a User Manual included in the official distribution of the FreeMASTER Serial Driver, which is a separately downloadable package available at "<http://www.freescale.com/freemaster>".





## Chapter 12

### FTM PDB ADC Demo

This demo application demonstrates how to use FTM external trigger to start ADC conversion via PDB.

#### 12.1 Overview

This application demonstrates how to use the FTM external trigger to start the ADC conversion using the PDB. The FTM0 is configured as a complementary combined mode. Each channel output frequency is 16 KHz. The complementary channel dead time is 1  $\mu$ s. The PDB pre-trigger works in back-to-back mode. The ADC0 and ADC1 work in single-end mode. The ADC0 uses channel 1 and channel 5. ADC1 uses channel 1 and channel 7.

#### 12.2 Supported Platforms

This Tower System module is supported by the KSDK FTM PDB ADC demo.

- FRDM-KV10Z
- TWR-KV10Z32
- TWR-KV11Z75M

#### 12.3 System Requirement

##### 12.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 12.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/ftm\_pdb\_adc/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 12.4 Getting Started

##### 12.4.1 Hardware Settings

The Hello World project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state

## Getting Started

when running this demo.

### 12.4.2 Prepare the Demo

Use default jumper settings on TWR-KV10Z32. Ensure that the J21(2~3 is short), J22(2~3 is short), J11(1~2 is short, 3~4 is short), J12(1~2 is short, 3~4 is short). On TWR-KV11Z75M: Ensure that the J19(2~3 is short), J20(2~3 is short), J9(1~2 is short, 3~4 is short), J7(1~2 is short, 3~4 is short).

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on the board or launch the debugger in the IDE to begin running the demo.

For detailed instructions, see the appropriate board User's Guide.

### 12.4.3 Run the demo

1. Download and run the `ftm_pdb_adc` code on the board.
2. Terminal prints this message: "Run PDB trig ADC with FlexTimer demo." and "Input any character to start demo."
3. Input a character to the serial terminal, which has 256 lines of information for the ADC conversion result.
4. Input any character to the serial terminal. The process repeats again.

## Chapter 13

### Hello World Demo

This demo application demonstrates the Hello World demo.

#### 13.1 Overview

The Hello World project is a simple demonstration program that uses the KSDK software. It prints the "Hello World" message to the terminal using the KSDK UART drivers. The purpose of this demo is to show how to use the UART and to provide a simple project for debugging and further development.

#### 13.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Hello World demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

## Run the demo

- TWR-KW24D512
- USB-KW24D512
- USB-KW40Z-K22F
- USB-KW40Z

## 13.3 System Requirement

### 13.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 13.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/hello\_world/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 13.4 Getting Started

### 13.4.1 Hardware Settings

### 13.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the appropriate board User's Guide.

## 13.5 Run the demo

This is an example how to run the demo.

Hello World!

### 13.6 Communication Interface Settings:

This part provides the information to customize the Hello World demo. The Hello World demo is configured to use these port pins for the platforms by default. If applicable for the board, jumpers are specified to select between serial output via OpenSDA and serial output via TWR-SER.

Platform	TX MCU Pin (Board Pin)	RX MCU Pin (Board Pin)	Module Instance
FRDM-K22F	PTE0 (N/A)	PTE1 (N/A)	UART1
FRDM-K64F	PTB17 (N/A)	PTB16 (N/A)	UART0
FRDM-KL26Z	PTA2 (J1-4)	PTA1 (J1-2)	LPSCI0
FRDM-KL46Z	PTA2 (J1-4)	PTA1 (J1-2)	UART0
FRDM-KW24	PTE0 (N/A)	PTE1 (N/A)	UART1
MRB-KW01	PTA2 (-)	PTA1 (-)	LPSCI0
TWR-K22F120M	PTE0 (J30)	PTE1 (J29)	UART1
TWR-K64F120M	PTC4 (J15)	PTC3 (J10)	UART1
TWR-K80F150M	PTC4 (J8)	PTC3 (J6)	UART1
TWR-KV31F120M	PTB17 (J23)	PTB16 (J22)	UART0
TWR-KW24D512	PTE0 (J18-2)	PTE1 (J18-5)	UART1
TWR-K21F120M	PTD8	PTD9	UART1
TWR-K21F120M	PTD8	PTD9	UART1
TWR-KM34Z75M	PTI6/UART2_RX	PTI7/UART2_TX	UART2
USB-KW24D512	N/A	N/A	USB CDC Virtual COM
FRDM-KV31F	PTB17 (N/A)	PTB16 (N/A)	UART0
FRDM-KV10Z	PTB17 (N/A)	PTB16 (N/A)	UART0
TWR-KV11Z75M	PTB17 (J505)	PTB16 (J506)	UART0
USB-KW40Z-K22F	N/A	N/A	USB CDC Virtual COM
USB-KW40Z	PTC7 (N/A)	PTC6 (N/A)	UART0

---

## Communication Interface Settings:

## Chapter 14

### Hello World QSPI Demo

#### 14.1 Overview

The Hello World QSPI demo project is a demonstration program that uses the KSDK software. This demo shows how to boot from QSPI region and the QSPI alias region if supported. This example can generate two different demos using a different linker file and a startup file :

- Program boot from QSPI region.
- Program boot from QSPI alias region (If the chip support QSPI alias region).

#### 14.2 Supported Platforms

These Tower System modules and Freescale Freedom platforms are supported by the Hello World QSPI demo:

- TWR-K80F150M

#### 14.3 System Requirement

##### 14.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for a specific device
- Personal Computer

##### 14.3.2 Software requirements

- The project files for booting from the QSPI region are in : <SDK\_Install>/examples/<board>/demo\_apps/hello\_world\_qspi/<toolchain>.
- The project file for booting from the alias region are in: <SDK\_Install>/examples/<board>/demo\_apps/hello\_world\_qspi\_alias/<toolchain>.
- Library dependencies: ksdk\_platform\_lib
- Tool dependencies: Use the blhost and the elftosb tool provided by the ROM team from [www.freescale.com](http://www.freescale.com)



## Getting Started

### 14.4 Getting Started

#### 14.4.1 Hardware settings

This example requires external serial flash powered:

#### TWR-K80F150M

Jumper J30 pin 4 and pin 6 should be connected.

#### 14.4.2 Prepare the example

1. Press the SW2 button (NMI button) continuously and connect a USB cable between the PC host and the OpenSDA USB port on the board. The button should be pressed until openSDA USB port connected.
2. Build the demo project and get the .srec output file.
3. Use elftosb tool to convert srec file to SB file needed by blhost.
  - First a .bd file is needed, open .bd file in <SDK\_Install>/examples/<board>/demo\_apps/hello\_world\_qspi/hello\_world\_qspi.bd. While change to other demo, just change the srec file name in .bd file.
  - In command line, use command "./elftosb.exe -V -c hello\_world\_qspi.bd -o hello\_world\_qspi.-sb" to get a sb file.
4. Prepare QSPI config block for BootROM.
  - If using TWR-K80, just use the qspi\_config\_block.bin located in <SDK\_Install>/examples/<board>/demo\_apps/hello\_world\_qspi/qspi\_config\_block.bin
  - If using different flash chip, the qspi config block should be re-configured in source file located in <SDK\_Install>/examples/src/demo\_apps/hello\_world\_qspi/qspi\_config\_block\_generator.c, users can use GCC/Visual Studio/Code Block to re-generate a .bin file for QSPI configure block.
  - For detailed information of QSPI configure block, see document from BootLoader team.
5. Use blhost to configure bootloader and download code.
  - While using blhost, ".blhost.exe -p COMxx -- receive-sb-file hello\_world\_qspi.sb" ("COMxx" means the virtual COM number of the board.) Notice: -If using UART as communication between blhost, should not open serial terminal, or it may download failed.
6. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
7. Press the reset button on your board.

### 14.4.3 Run the example

The example makes two LEDs light up and these instruction are displayed/shown on the terminal window:

```
Hello World QSPI demo started!
```

Input some characters and the demo displays those characters.

Notice :

1. This example has no any code to change clock settings or system run mode. To change the system or QSPI clock settings, copy the code which changed clock settings or run mode from the QSPI memory to RAM first.
2. For the QSPI alias demo running in Keil, copy the .bss and RW part from the QSPI flash to RAM at startup before calling the main function.



## Chapter 15

### Hardware Timer Demo

This demo application demonstrates using the hardware timer driver.

#### 15.1 Overview

The Hardware Timer project is a demonstration program to show how to use the Hardware Timer driver. A Hardware Timer interrupt is created and fires multiple times until it reaches the requested number.

#### 15.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis SDK Hardware Timer demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

## Getting Started

- USB-KW24D512
- USB-KW40Z-K22F
- USB-KW40Z

## 15.3 System Requirement

### 15.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 15.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/demo_apps/hwtimer_demo/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 15.4 Getting Started

### 15.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on the board or launch the debugger in the IDE to begin running the demo.

For detailed instructions, see the appropriate board User's Guide.

### 15.4.2 Run the demo

1. Press the reset button on your board.
2. "Hwtimer Example" message is displayed on the terminal.
3. A dot is printed when an Hwtimer interrupt occurs until the `HWTIMER_DOTS_PER_LINE * HWTIMER_LINES_COUNT` (defined in `hwtimer_demo.c`) interrupts occur.

4. Finally, the "End" message is displayed.

```
Hwtimer Example
.....
.....
End
```

## 15.5 Customization Options

This demo application is customizable to show different types of hardware timers. TWR-KV11Z75M does not support PIT timer, due to no PIT in KV11 silicon

### 15.5.1 Configure the Hardware Timer Used

Determine which timer the hardware timer driver uses. The ARM core Systick timer is used by default.

```
#define HWTIMER_LL_DEVIF    kSystickDevif
```

### 15.5.2 Configure which clock is used by the hardware timer

Determine which clock source is used by the hardware timer.

```
#define HWTIMER_LL_SRCCLK   kCoreClock
```

### 15.5.3 Configure which instance of the module is used

Determine which instance of the selected hardware module to use. For the Systick timer only '0' is valid. If the PIT is used, use this to select the PIT channel.

```
#define HWTIMER_LL_ID      0
```

### 15.5.4 Hardware Timer Period

Determine the timer period (in microseconds).

```
#define HWTIMER_PERIOD     100000
```



## Chapter 16

# I2C Communication Demo

This demo application demonstrates the I2C demo.

### 16.1 Overview

The I2C communication application demonstrates I2C data communication between two boards. It also features low power wakeup of the slave board by using I2C address matching. First, the I2C slave board enters the low power wait mode. An LED on the I2C slave board is on to indicate that the MCU is in sleep mode and no code is running. Then, the I2C slave board is woken up by the I2C address matching interrupt when the I2C master boards sends the proper address. The LED on the I2C slave board is toggled during the data communication. After power on, the I2C master starts reading data from the I2C slave data buffer. The I2C slave has "sub" addresses to access a specific byte of data on the slave board. The master prints this data out via the serial terminal. The master can then modify the data at a specific "sub" address on the slave board. When the data is received, the I2C slave changes the content at that requested "sub" address. This change is reflected when the master reads the slave data buffer again.

### 16.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK I2C Communication demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M



## Getting Started

- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

## 16.3 System Requirement

### 16.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 16.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/i2c\_comm/<mode>/<toolchain>. Where <mode> is either master or slave.
- Library dependencies: ksdk\_platform\_lib

## 16.4 Getting Started

### 16.4.1 Hardware configuration

This demo requires two separate boards. Make these connections between the two boards by using external wires. In case of TWR-KV11Z75M, also connect pin 2 and 3 on J4 and J11. external wires:

#### FRDM-K22F:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J24 Pin 12	->	I2C0_SCL	J24 Pin 12
I2C0_SDA	J24 Pin 10	->	I2C0_SDA	J24 Pin 10
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-K64F:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 20	->	I2C0_SCL	J2 Pin 20
I2C0_SDA	J2 Pin 18	->	I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-K64F:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J2 Pin 20	->	I2C1_SCL	J2 Pin 20
I2C1_SDA	J2 Pin 18	->	I2C1_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-KL02Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J7 Pin 10	->	I2C0_SCL	J7 Pin 10
I2C0_SDA	J7 Pin 9	->	I2C0_SDA	J7 Pin 9
GND	J7 Pin 7	->	GND	J7 Pin 7

**FRDM-KL03Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 10	->	I2C0_SCL	J2 Pin 10
I2C0_SDA	J2 Pin 9	->	I2C0_SDA	J2 Pin 9
GND	J2 Pin 7	->	GND	J2 Pin 7

**FRDM-KL25Z:**

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high

## Getting Started

baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J10 Pin 12	->	I2C1_SCL	J10 Pin 12
I2C1_SDA	J10 Pin 10	->	I2C1_SDA	J10 Pin 10
GND	J9 Pin 14	->	GND	J9 Pin 14

### FRDM-KL26Z:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 20	->	I2C0_SCL	J2 Pin 20
I2C0_SDA	J2 Pin 18	->	I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

### FRDM-KL27Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J2 Pin 20	->	I2C1_SCL	J2 Pin 20
I2C1_SDA	J2 Pin 18	->	I2C1_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

### FRDM-KL43Z, FRDM-KL43ZKL33, FRDM-KL46Z:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 20	->	I2C0_SCL	J2 Pin 20
I2C0_SDA	J2 Pin 18	->	I2C0_SDA	J2 Pin 18

GND	J2 Pin 14	->	GND	J2 Pin 14
-----	-----------	----	-----	-----------

**FRDM-KW24:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 20	->	I2C0_SCL	J2 Pin 20
I2C0_SDA	J2 Pin 18	->	I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-KW40Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J25 Pin 10	->	I2C1_SCL	J25 Pin 10
I2C1_SDA	J25 Pin 12	->	I2C1_SDA	J25 Pin 12
GND	J24 Pin 14	->	GND	J24 Pin 14

**MRB-KW01:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J15 Pin 13	->	I2C1_SCL	J15 Pin 13
I2C1_SDA	J15 Pin 11	->	I2C1_SDA	J15 Pin 11
GND	J14 Pin 18	->	GND	J14 Pin 18

**TWR-K21D50M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator A7
I2C1_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

## Getting Started

### TWR-K22F120M, TWR-K24F120M, TWR-K60D100M & TWR-KV31F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K64F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	Primary Elevator A75	->	I2C1_SCL	Primary Elevator A75
I2C1_SDA	Primary Elevator A60	->	PTC11/I2C1_SDA	Primary Elevator A60
GND	Primary Elevator A65	->	GND	Primary Elevator A65

### TWR-KL43Z48M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator A7
I2C1_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-KM34Z75M

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTD7/I2C0_SCL	J10 Pin 1	->	PTD7/I2C0_SCL	J10 Pin 1

PTE0/I2C0_SDA	J11 Pin 1	->	PTE0/I2C0_SDA	J11 Pin 1
GND	J25 Pin 26	->	GND	J25 Pin 26

**TWR-KV10Z32:**

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

**TWR-K65F180M, TWR-K80F150M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C0_SCL	Primary Elevator - Pin A7
I2C0_SDA	Primary Elevator - Pin A8	->	I2C0_SDA	Primary Elevator - Pin A8
GND	Primary Elevator A65	->	GND	Primary Elevator A65

**TWR-KW24D512:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A81	->	GND	Primary Elevator A81

## Getting Started

### TWR-K21F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	Primary Elevator B50	->	I2C1_SCL	Primary Elevator B50
I2C1_SDA	Primary Elevator B51	->	I2C1_SDA	Primary Elevator B51
GND	Primary Elevator A65	->	GND	Primary Elevator A65

### FRDM-KV31F:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J1-16	->	I2C0_SCL	J1-16
I2C0_SDA	J2-13	->	I2C0_SDA	J2-13
GND	J2-14	->	GND	J2-14

### FRDM-KV10Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 13	->	I2C0_SCL	J2 Pin 13
I2C0_SDA	J1 Pin 15	->	I2C0_SDA	J1 Pin 15
GND	J2 Pin 14	->	GND	J2 Pin 14

### TWR-KV11Z75M:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location

Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### 16.4.2 Terminal configuration

Configure the PC host serial console as shown:

- 115200 baud rate
- 8 data bits
- No parity
- One stop bit
- No flow control

### 16.4.3 Run the demo

1. Connect the I2C slave board to the master board using the connections listed above.
2. Power on the I2C slave board.
3. Download and run the `i2c_comm_slave` project to the I2C slave board.
4. The terminal of the I2C slave board prints out a "=====`I2C Slave`====" message.
5. Power on the I2C master board.
6. Download and run the `i2c_comm_mstr` project to the I2C master board.
7. The terminal of the I2C master board prints out a "=====`I2C Master`====" message and the data received from the I2C slave.
8. The I2C slave project creates some "sub" addresses to access a specific byte of data on the slave board. The master reads all these "sub" addresses and prints out the data.

Slave Sub Address	Character
[0]	I
[1]	2
[2]	C
[3]	-
[4]	C
[5]	O
[6]	M
[7]	M



## Getting Started

9. To change the I2C slave sub address content, input a new character in the I2C master command line:

```
Input slave sub address and the new character.
Slave Sub Address: 5
Input New Character: F
```

10. The master then displays the updated content on the terminal output.

Slave Sub Address	Character
[0]	I
[1]	2
[2]	C
[3]	-
[4]	C
[5]	F
[6]	M
[7]	M

## Chapter 17

### I2C Demo with RTOS

This demo application demonstrates the I2C demo on different RTOS.

#### 17.1 Overview

This I2C application demonstrates the SDK Peripheral drivers working on different RTOS. The application acts as both the I2C master and the slave device on different I2C buses, such as the I2C Master on the I2C0 bus and the I2C Slave on the I2C1 bus. It can run on a single board or on two different boards. When connecting the two I2C buses on one board, the master sends the command using the I2C0 bus to the slave using the I2C1 bus. When connecting the I2C0 bus to the I2C1 bus on the other board, the application running on the first board is a master and sends a command to the other board which acts as a slave. This means that the first board can send a command and get a response from the other board by using the I2C bus.

The basic purpose of this demo is:

1. Read the Kinetis chip UID (low 32bits) from the slave board
2. Read the Kinetis chip internal temperature from the slave board
3. Control the RED/GREEN/BLUE color LEDs on the slave board

The application creates three different tasks to handle events concurrently:

1. Master task: responds to the user interface interaction, runs as a I2C master, and acts as a simple UI. It accepts user's commands to read the basic chip UID, chip temperature and control the on board LED, and power mode on the slave.
2. Slave task: responds to the command received from the I2C master and returns the result to the master.
3. ADC sample task: responds to getting the chip temperature in a period.
4. For the bare metal version, the master and slave tasks are separated into two separate projects.

#### 17.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- $\mu$ C/OS-II
- $\mu$ C/OS-III
- Bare Metal (no RTOS)

#### 17.3 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK I2C demo with RTOS.

The Bare Metal (no RTOS) demo Supported Platforms:

## Supported Platforms

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KV11Z75M

The FreeRTOS,  $\mu$ C/OS-II,  $\mu$ C/OS-III demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV31F
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KL43Z48M

The MQX demo Supported Platforms:

- FRDM-K22F

- FRDM-K64F
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KV31F
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KL43Z48M

## 17.4 System Requirement

### 17.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 17.4.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/i2c\_rtos/<rtos>/<toolchain>. Where <rtos> is the chosen RTOS configuration.
- Library dependencies:
  - Baremetal, FreeRTOS, uC/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

## 17.5 Getting Started

The I2C RTOS application is designed to work on one single board or two different boards (default: master uses I2C0 slave uses I2C1 except special cases (check symbols I2C\_RTOS\_MASTER\_INSTANCE and I2C\_RTOS\_SLAVE\_INSTANCE)). Note that the bare-metal version only supports two boards.

### 17.5.1 Build with different RTOS support

Before running this application, build it with the RTOS you want to use. The projects for different RTOSes are differentiated by the workspace file name in the format of i2c\_rtos\_<rtos>.eww. For example, in IAR, the i2c\_rtos\_ucosii.eww workspace file is the  $\mu$ C/OS-II version of this application. After opening

## Getting Started

the appropriate workspace, build the `ksdk_<rtos>_lib` project and build the application project. A binary named `i2c_<rtos>.out` is generated.

### 17.5.2 Hardware configuration

Make the connections between the listed signals by using the external wires. In case of TWR-KV11Z75M, also connect pin 2 and 3 on J4 and J11.

#### Freescale Freedom FRDM-K22F

FRDM-K22F Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J24 - Pin 12	->	I2C1_SCL	J1 - Pin 13
I2C0_SDA	J24 - Pin 10	->	I2C1_SDA	J2 - Pin 7

FRDM-K22F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J24 - Pin 12	->	I2C1_SCL	J1 - Pin 13
I2C0_SDA	J24 - Pin 10	->	I2C1_SDA	J2 - Pin 7
GND	TP21	->	GND	TP21

#### Freescale Freedom FRDM-K64F

FRDM-K64F Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 - Pin 20	->	I2C1_SCL	J4 - Pin 12
I2C0_SDA	J2 - Pin 18	->	I2C1_SDA	J4 - Pin 10

FRDM-K64F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 - Pin 20	->	I2C1_SCL	J4 - Pin 12
I2C0_SDA	J2 - Pin 18	->	I2C1_SDA	J4 - Pin 10

GND	J2 - Pin 14	->	GND	J2 - Pin 14
-----	-------------	----	-----	-------------

FRDM-K64F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 - Pin 20	->	I2C1_SCL	J4 - Pin 12
I2C0_SDA	J2 - Pin 18	->	I2C1_SDA	J4 - Pin 10
GND	J2 - Pin 14	->	GND	J2 - Pin 14

### FreescalE Freedom FRDM-KL02Z

FRDM-KL02Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J7 Pin 10	->	I2C0_SCL	J7 Pin 10
I2C0_SDA	J7 Pin 9	->	I2C0_SDA	J7 Pin 9
GND	J7 Pin 7	->	GND	J7 Pin 7

### FreescalE Freedom FRDM-KL25Z

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

FRDM-KL25Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J10 - Pin 6	->	I2C1_SCL	J10 - Pin 12
I2C0_SDA	J10 - Pin 8	->	I2C1_SDA	J10 - Pin 10

FRDM-KL25Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J10 Pin 6	->	I2C1_SCL	J10 Pin 12
I2C0_SDA	J10 Pin 8	->	I2C1_SDA	J10 Pin 10
GND	J9 Pin 14	->	GND	J9 Pin 14

## Getting Started

### Freescale Freedom FRDM-KL26Z

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

FRDM-KL26Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 - Pin 6	->	I2C1_SCL	J2 - Pin 20
I2C0_SDA	J4 - Pin 8	->	I2C1_SDA	J2 - Pin 18

FRDM-KL26Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 - Pin 6	->	I2C1_SCL	J2 - Pin 20
I2C0_SDA	J4 - Pin 8	->	I2C1_SDA	J2 - Pin 18
GND	J2 - Pin 14	->	GND	J2 - Pin 14

### Freescale Freedom FRDM-KL27Z

FRDM-KL27Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 20	->	I2C1_SCL	J4 Pin 12
I2C0_SDA	J4 Pin 18	->	I2C1_SDA	J4 Pin 10

FRDM-KL27Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 20	->	I2C1_SCL	J4 Pin 12
I2C0_SDA	J4 Pin 18	->	I2C1_SDA	J4 Pin 10
GND	J2 Pin 14	->	GND	J2 Pin 14

### Freescale Freedom FRDM-KL43Z

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high

baurate. In this case, user need to use external pull-up resistors.

FRDM-KL43Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 2	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 4	->	I2C1_SDA	J2 Pin 18

FRDM-KL43Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 2	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 4	->	I2C1_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

### Freescale Freedom FRDM-KL43Z

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

FRDM-KL43Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 2	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 4	->	I2C1_SDA	J2 Pin 18

FRDM-KL43Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 2	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 4	->	I2C1_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

### Freescale Freedom FRDM-KL46Z

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.



## Getting Started

baurate. In this case, user need to use external pull-up resistors.

FRDM-KL46Z Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 6	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 8	->	I2C1_SDA	J2 Pin 18

FRDM-KL46Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J4 Pin 6	->	I2C1_SCL	J2 Pin 20
I2C0_SDA	J4 Pin 8	->	I2C1_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

## Freescale Freedom FRDM-KW40Z

FRDM-KW40Z has only RED leds available so GREEN and BLUE leds blinking is simulated by different RED leds.

FRDM-KW40Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTC2/I2C1_SCL	J25 - Pin 10	->	PTC2/I2C1_SCL	J25 - Pin 10
PTC3/I2C1_SDA	J25 - Pin 12	->	PTC3/I2C1_SDA	J25 - Pin 12>
GND	J24 - Pin 14	->	GND	J24 - Pin 14

## Freescale Modular Reference Board MRB-KW01

MRB board doesn't include user controllable LEDs, so the only available commands are: 4 (Read Temperature) and 5 (Read Id).

MRB-KW01 Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J15 - Pin 12	->	I2C1_SCL	J15 - Pin 13
I2C0_SDA	J14 - Pin 8	->	I2C1_SDA	J15 - Pin 11

MRB-KW01 Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J15 - Pin 12	->	I2C1_SCL	J14 - Pin 14
I2C0_SDA	J14 - Pin 8	->	I2C1_SDA	J14 - Pin 12
GND	J14 - Pin 18	->	GND	J14 - Pin 18

### TWR-K21D50M Tower System module

TWR-K21D50M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
PTC10/I2C0_SCL	Primary Elevator - Pin A7	->	PTD2/I2C1_SCL	Primary Elevator - Pin B45
PTC11/I2C0_SDA	Primary Elevator - Pin A8	->	PTD3/I2C1_SDA	Primary Elevator - Pin B44

TWR-K21D50M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTC10/I2C0_SCL	Primary Elevator - Pin A7	->	PTD2/I2C1_SCL	Primary Elevator - Pin B45
PTC11/I2C0_SDA	Primary Elevator - Pin A8	->	PTD3/I2C1_SDA	Primary Elevator - Pin B44
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### TWR-K21F120M Tower System module

TWR-K21F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
PTD2/I2C0_SCL	Primary Elevator B45	->	PTC10/I2C1_SCL	Primary Elevator B50
PTD3/I2C0_SDA	Primary Elevator B44	->	PTC11/I2C1_SDA	Primary Elevator B51

## Getting Started

TWR-K21F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
PTD2/I2C0_SCL	Primary Elevator B45	->	PTC10/I2C1_SCL	Primary Elevator B50
PTD3/I2C0_SDA	Primary Elevator B44	->	PTC11/I2C1_SDA	Primary Elevator B51
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### TWR-K22F120M Tower System module

TWR-K22F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin B50
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B51

TWR-K22F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin B50
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B51
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### TWR-K24F120M Tower System module

TWR-K24F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator B50

I2C0_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator B51
----------	------------------------	----	----------	-------------------------

TWR-K24F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator B50
I2C0_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator B51
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K60D100M Tower System module

TWR-K60D100M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator A75
I2C0_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator B71

TWR-K60D100M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C1_SCL	Primary Elevator A75
I2C0_SDA	Primary Elevator A8	->	I2C1_SDA	Primary Elevator B71
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K64F120M Tower System module

TWR-K64F120M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location

## Getting Started

I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin A75
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B71

TWR-K64F120M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin A75
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B71
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

## TWR-K65F180M Tower System module

TWR-K65F180M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin B11
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B22

TWR-K65F180M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin B11
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B22
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

## TWR-K80F150M Tower System module

TWR-K65F180M Single Board				
---------------------------	--	--	--	--

Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin A75
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B71

TWR-K65F180M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator - Pin A7	->	I2C1_SCL	Primary Elevator - Pin A75
I2C0_SDA	Primary Elevator - Pin A8	->	I2C1_SDA	Primary Elevator - Pin B71
GND	Primary Elevator - Pin A65	->	GND	Primary Elevator - Pin A65

### TWR-KL43Z48M Tower System module

TWR-KL43Z48M Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A40	->	I2C1_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A39	->	I2C1_SDA	Primary Elevator A8

TWR-KL43Z48M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A40	->	I2C1_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A39	->	I2C1_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

## Getting Started

### FRDM-KV31F Tower System module

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

FRDM-KV31F Single Board				
Master		Connects To	Slave	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J1-16	->	I2C1_SCL	J1-02
I2C0_SDA	J2-13	->	I2C1_SDA	J1-04

FRDM-KV31F Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J1-16	->	I2C1_SCL	J1-02
I2C0_SDA	J2-13	->	I2C1_SDA	J1-04
GND	J2-14	->	GND	J2-14

### FRDM-KV10Z:

FRDM-KL46Z Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 13	->	I2C0_SCL	J2 Pin 13
I2C0_SDA	J1 Pin 15	->	I2C0_SDA	J1 Pin 15
GND	J2 Pin 14	->	GND	J2 Pin 14

### TWR-KV11Z75M Tower System module

KV11 derivatives have only one I2C peripheral so only connection between two boards is possible. The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

TWR-KV11Z75M Two Boards				
Master (Board #1)		Connects To	Slave (Board #2)	
Pin Name	Board Location		Pin Name	Board Location

PTC6/I2C0_SCL	J24 - Pin 19	->	PTC6/I2C0_SCL	J24 - Pin 19
PTC7/I2C0_SDA	J24 - Pin 20	->	PTC7/I2C1_SDA	J24 - Pin 20
GND	J24 - pin 1	->	GND	J24 - Pin 1

### 17.5.3 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For more detailed instructions, see a Kinetis SDK User’s Guide for your board.

### 17.6 Run the demo

This menu displays in the terminal window:

```
Available Commands:
LED Red Toggle (1)   - Red Light toggles on/off
LED Green Toggle (2) - Green Light toggles on/off
LED Blue Toggle (3)  - Blue Light toggles on/off
Read Temperature (4) - Get temperature of client (It is necessary to set voltage reference exactly to 3.3
                    V to see correct temperature.)
Read Id      (5)     - Read client unique ID
```

Enter your choice (1 - 5):

You can select to toggle the RGB LED, read the temperature of the client board, and read the client unique ID.

Note that a different colored LED may turn on if the selected color is not available on that board.



---

## Run the demo

## Chapter 18

### iRTC Comp 1 Hz Demo

This demo application demonstrates the iRTC 1Hz output through XBAR with fine compensation.

#### 18.1 Overview

The iRTC 1Hz output with compensation project is a demonstration program that uses the KSDK software. It implements the following features:

- Use 32.768K external crystal as both iRTC and system (FLL) clock source.
- Enable IRC 4MHz to MCGIRCLK for iRTC fine compensation.
- Route the iRTC fine 1Hz output to XBAR\_OUT10 pin
- Define the tested ppm by macro, and calculate the compensate Integer and Frac value written to RTC\_COMPEN register.

#### 18.2 Supported Platforms

This Tower System module is supported by the KSDK iRTC 1Hz output with compensation demo.

- TWR-KM34Z75M

#### 18.3 System Requirement

##### 18.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 18.4 Getting Started

##### 18.4.1 Hardware Settings

This project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

## Run the demo

### 18.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the appropriate board User's Guide.

### 18.5 Run the demo

These instructions are displayed/shown on the terminal window:

```
RTC Compensate 1HZ output demo
Compensate with error -100ppm (int:c, frac:60)
```

The 1Hz pulse out is routed to the PTL2 (XBAR0\_OUT10) pin, which can be tested on the J25 Pin-23 on board.

## Chapter 19

# HTTP Server Demo on lwIP TCP/IP Stack

This demo application demonstrates the HTTPServer demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

### 19.1 Overview

This is an HTTPServer set up on lwIP TCP/IP stack with bare metal SDK or different RTOSes. The user uses an Internet browser to send a request for connection. The board acts as an HTTP server and sends a Web page back to the PC.

### 19.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- $\mu$ C/OS-II
- $\mu$ C/OS-III
- Bare Metal (no RTOS)

### 19.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis software development kit HTTPServer demo.

- FRDM-K64F
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

### 19.4 System Requirement

#### 19.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Getting Started

### 19.4.2 Software requirements

- The project files are in:
  - Baremetal: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_https\_server\_demo/https\_server\_bm/<toolchain>
  - RTOS: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_https\_server\_demo/https\_server\_rtos/<rtos>/<toolchain>
- Library dependencies:
  - Baremetal, FreeRTOS, uC/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

## 19.5 Getting Started

See the *lwIP TCP/IP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for more information about the setup and requirements.

### 19.5.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions steps, see a Kinetis SDK User's Guide for your board.

### 19.5.2 Network Configuration

Configure the IP address of PC network adapters as shown: IP address - 192.168.2.100 Subnet Mask - 255.255.255.0

### 19.5.3 Run the demo

1. Download the program to target board, which should be installed in TWR or FRDM.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the PC command window, type in "ping 192.168.2.102" to test whether lwIP stack is running. If successful, four echo request packets are successfully replied.

5. Input "192.168.2.102" in the URL of an Internet browser on a PC. If successful, the web page which the board returns opens in the browser.



## Chapter 20

### Ping Demo on lwIP TCP/IP Stack

This demo application demonstrates the Ping demo on lwIP TCP/IP stack with bare metal SDK or different RTOSes.

#### 20.1 Overview

This is a Ping Demo on the lwIP TCP/IP stack which uses the ICMP protocol. The application on board periodically sends the ICMP echo request to a PC and processes the PC reply. Type the "ping \$board\_-address" in the PC command window to send an ICMP echo request to the board. The lwIP stack sends the ICMP echo reply back to the PC.

#### 20.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- $\mu$ C/OS-II
- $\mu$ C/OS-III
- Bare Metal (no RTOS)

#### 20.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK Ping demo.

- FRDM-K64F
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

#### 20.4 System Requirement

##### 20.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer



## Run the demo

### 20.4.2 Software requirements

- The project files are in:
  - Baremetal: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_ping\_demo/ping\_bm/<toolchain>
  - RTOS: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_ping\_demo/ping\_rtos/<rtos>/<toolchain>
- Library dependencies:
  - Baremetal, FreeRTOS, uC/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

## 20.5 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

### 20.5.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

### 20.5.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

## 20.6 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the terminal. Ping send and ping receive are successful.
5. Type in "ping 192.168.2.102" in PC command window. If the operation is successful, four packets are successful replied.

## Chapter 21

# TCP Echo Demo on lwIP TCP/IP Stack

This demo application demonstrates the TCP Echo demo on lwIP TCP/IP stack with bare metal KSDK or different RTOSes.

### 21.1 Overview

This is a TCP echo demo on the lwIP TCP/IP stack with bare metal KSDK or different RTOSes, which uses the TCP protocol and acts as an echo server. The application on board sends back the TCP packets from the PC, which can be used to test whether the TCP connection is available.

### 21.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- $\mu$ C/OS-II
- $\mu$ C/OS-III
- Bare Metal (no RTOS)

### 21.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK TCP Echo demo.

- FRDM-K64F
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

### 21.4 System Requirement

#### 21.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Run the demo

### 21.4.2 Software requirements

- The project files are in:
  - Baremetal: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_tcpecho\_demo/tcpecho\_bm/<toolchain>
  - RTOS: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_tcpecho\_demo/tcpecho\_rtos/<rtos>/<toolchain>
- Library dependencies:
  - Baremetal, FreeRTOS, uC/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

## 21.5 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

### 21.5.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

### 21.5.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

## 21.6 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the command window on PC, type in "ping 192.168.2.102" to test whether the lwIP is running.
5. If it is running, use an external echo tool to perform the echo request. This tool sends

TCP packets to the board and checks whether the content sent back from board is the same.

A similar tool named "echotool" can be downloaded

from the: <http://bansky.net/echotool/> [example: echotool 192.168.2.102 /p tcp /r 7 /d hello]

6. If the operation is successful, all packets sent back are same as the packets sent to the board.

---

## Run the demo

## Chapter 22

### UDP Echo Demo on lwIP TCP/IP Stack

This demo application demonstrates the UDP Echo demo on lwIP TCP/IP stack with bare metal KSDK or different RTOSes.

#### 22.1 Overview

This is a UDP echo demo on the lwIP TCP/IP stack with bare metal KSDK or different RTOSes, which uses the UDP protocol and acts as an echo server. The application on board sends back the UDP packets from the PC, which can be used to test whether the UDP connection is available.

#### 22.2 Supported RTOS

- Freescale MQX™ RTOS
- FreeRTOS
- $\mu$ C/OS-II
- $\mu$ C/OS-III
- Bare Metal (no RTOS)

#### 22.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK UDP Echo demo.

- FRDM-K64F
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

#### 22.4 System Requirement

##### 22.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Run the demo

### 22.4.2 Software requirements

- The project files are in:
  - Bare Metal: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_udpecho\_demo/udpecho-\_bm/<toolchain>
  - RTOS: <SDK\_Install>/examples/<board>/demo\_apps/lwip/lwip\_udpecho\_demo/udpecho-\_rtos/<rtos>/<toolchain>
- Library dependencies:
  - Bare Metal, FreeRTOS,  $\mu$ C/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

## 22.5 Getting Started

See the *lwIP TCPIP Stack and Kinetis SDK Integration User's Guide* (document KSDKLWIPUG) for instructions and requirements.

### 22.5.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

### 22.5.2 Network Configuration

Configure the IP address of PC network adapters as shown:

- 192.168.2.100

## 22.6 Run the demo

1. Download the program to the target board.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the command window on PC, type in "ping 192.168.2.102" to test whether the lwIP is running.
5. If it is running, use an external echo tool to perform the echo request. This tool sends UDP packets to the board and checks whether the content sent back from board is the same. A similar tool

named "echotool" can be downloaded from the: <http://bansky.net/echotool/> [example: echotool 192.168.2.102 /p udp /r 7 /d hello]

6. If the operation is successful, all packets sent back are the same as the packets sent to the board.



---

## Run the demo

## Chapter 23

### MMAU Filter Demo

#### 23.1 Overview

The Memory Mapped Arithmetic Unit (MMAU) provides acceleration to a set of mathematical operations, including signed/unsigned multiplication and accumulation, division, and square root, and so on. This demo shows a typical use of the Memory Mapped Arithmetic Unit (MMAU) for 4th order lowpass filter computing. The operation of 4th order lowpass filter function is given by the following equation:

$$y(n)=b_0*x(n)+b_1*x(n-1)+b_2*x(n-2)+b_3*x(n-3)+b_4*x(n-4)-a_1*y(n-1)-a_2*y(n-2)-a_3*y(n-3)-a_4*y(n-4)$$

#### 23.2 Supported Platforms

This Tower System module is supported by the MMAU example.

- TWR-KM34Z75M

#### 23.3 System Requirement

##### 23.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 23.4 Getting Started

##### 23.4.1 Hardware settings

The MMAU Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

##### 23.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits

## Getting Started

- No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
  4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 23.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Mmau_filter_demo Begin.

First column is an input signal, second column is an filtered output signal.
  0 --> 0
2166732 --> 360
2753973 --> 3120
1604297 --> 13224
 123267 --> 37264
  12239 --> 79960
1734704 --> 141864
4097830 --> 220856
5326223 --> 316240
4660528 --> 431704
3040692 --> 574288
2258324 --> 750080
3341806 --> 960296
5629024 --> 1201096
7363103 --> 1467192
7274451 --> 1755928
5723831 --> 2068168
4376659 --> 2405248
4701958 --> 2764856
6648280 --> 3139672
8689462 --> 3520160
9199008 --> 3899152
7914891 --> 4274256
6175140 --> 4646056
5711947 --> 5013856
7090722 --> 5372904
9200346 --> 5715656
10253866 --> 6036000
9398102 --> 6332656
7482051 --> 6608672
6291825 --> 6867456
6941379 --> 7108872
8868840 --> 7328872
10342644 --> 7522936
10021506 --> 7690160
8162831 --> 7834256
6390892 --> 7960504
6233630 --> 8071352
7746287 --> 8164600
9461846 --> 8235752
9712938 --> 8282400
8134287 --> 8306680
5992130 --> 8313568
5043834 --> 8306552
5955090 --> 8284592
7700647 --> 8243112
8488467 --> 8178136
```

```

7374730 --> 8089872
5114698 --> 7982520
3482901 --> 7860496
3675087 --> 7724496
5231628 --> 7570944
6452309 --> 7395344
5928792 --> 7196520
3814157 --> 6977928
1685767 --> 6744864
1125013 --> 6500072
2293441 --> 6241728
3788057 --> 5965592
3906151 --> 5669400
2180158 --> 5355528
-200227 --> 5029528
-1458963 --> 4695840
-832815 --> 4354552
741949 --> 4002104
1473959 --> 3635312
331515 --> 3255072
-2027032 --> 2866400
-3845491 --> 2474776
-3851097 --> 2082080
-2400263 --> 1685776
-1156602 --> 1282080
-1591289 --> 870256
-3656810 --> 454176
-5828926 --> 39720
-6479050 --> -369624
-5340656 --> -775008
-3748612 --> -1180296
-3435831 --> -1587688
-4971342 --> -1994856
-7246945 --> -2396160
-8474926 --> -2786856
-7797983 --> -3166504
-6060970 --> -3538512
-5049184 --> -3906232
-5879437 --> -4269112
-7993407 --> -4622392
-9660172 --> -4960608
-9535189 --> -5281752
-7871223 --> -5588344
-6290283 --> -5884448
-6322041 --> -6171320
-8025478 --> -6445624
-9935534 --> -6701808
-10382821 --> -6936512
-8997469 --> -7151032
-7042261 --> -7349632
-6274946 --> -7535216
-7364674 --> -7706264
-9289208 --> -7857792
-10255966 --> -7985472
-9317117 --> -8089208
-7223680 --> -8172936
-5749155 --> -8240840
-6092036 --> -8293384
-7796394 --> -8326744
-9162986 --> -8336152
-8780521 --> -8320128
-6797545 --> -8281800
-4789092 --> -8226120
-4338241 --> -8155472
-5610457 --> -8067648
-7205110 --> -7958000
-7417939 --> -7823832
-5777092 --> -7667080

```

## Getting Started

```
-3468902 --> -7492856
-2269827 --> -7305176
-2946762 --> -7103720
-4566901 --> -6884528
-5338900 --> -6644024
-4227529 --> -6382728
-1887148 --> -6105312
  -73038 --> -5816960
  -60914 --> -5519288
-1498499 --> -5209520
-2723782 --> -4883656
-2263234 --> -4540760
  -160231 --> -4184528
```

Mmau\_filter\_demo End.

## Chapter 24

### MMDVSQ Demo

This demo application demonstrates how to use MMDVSQ driver.

#### 24.1 Overview

The MMDVSQ Demo project is a simple demonstration program to show how to use the MMDVSQ driver. This demo demonstrates the efficiency of division and square root operations and typical C functions.

#### 24.2 Supported Platforms

This demo supports the following Tower System module and Freedom development platforms:

- FRDM-KV10Z
- TWR-KV10Z32
- TWR-KV11Z75M

#### 24.3 System Requirement

##### 24.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 24.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/mmdvsq\_demo/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 24.4 Getting Started

##### 24.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits

## Run the demo

- No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
  4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

## 24.5 Run the demo

This is an example serial terminal output:

```
MMDVSQ Demo start!  
C library calculation takes 622 tickcycles  
MMDVSQ t calculation takes 521 tickcycles  
MMDVSQ Demo end
```

The tickcycles are used as a reference.

## Chapter 25

# Power Manager HAL Demo

### 25.1 Overview

The Power Manager demo application demonstrates different Power Manager modes supported by the Kinetis SoCs. The set of supported low power modes and their transition possibility differ platform to platform. See section: "System Mode Controller" in a Reference Manual for each Kinetis sub-family microcontroller.

### 25.2 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis software development kit Power Manager demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512



## Getting Started

- USB-KW40Z

### 25.3 System Requirement

#### 25.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for a specific device
- Personal Computer

#### 25.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/demo_apps/power_manager_hal_-demo/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 25.4 Getting Started

#### 25.4.1 Hardware Settings

The demo does not require any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

#### 25.4.2 Prepare the Demo

Follow the instructions in *Getting Started with Kinetis Software Development Kit (KSDK)* to:

- Set up hardware connections
- Configure a Terminal session
- Build and download application to targeted devices

Note: The demo is configured to work with the Terminal baudrate at 9600 bps. When running the demo, unplug all debugger devices. For the MRB-KW01, it is necessary to connect on the J8 pins 2-3.

#### 25.4.3 Run the demo

1. Press the reset button on the hardware.
2. A control menu is displayed on the Terminal window. Note that the list on the menu is not the same for all platforms.

It depends on the list of supported low power modes. For example, on the TWR-K64F120M, this menu displays:

### ##### Power Manager Demo

```
Core Clock = 48000000Hz
```

```
SMC mode = kStatRun
```

```
Select the desired operation
```

```
Press A for enter: RUN - Normal RUN mode
```

```
Press B for enter: Wait - Wait mode
```

```
Press C for enter: Stop - Stop mode
```

```
Press D for enter: VLPR - Very Low Power Run mode
```

```
Press E for enter: VLPW - Very Low Power Wait mode
```

```
Press F for enter: VLPS - Very Low Power Stop mode
```

```
Press G for enter: LLS - Low Leakage Stop mode
```

```
Press H for enter: VLLS0 - Very Low Leakage Stop 0 mode
```

```
Press I for enter: VLLS1 - Very Low Leakage Stop 1 mode
```

```
Press J for enter: VLLS3 - Very Low Leakage Stop 3 mode
```

```
Waiting for key to be pressed...
```

1. Enter a command by pressing the corresponding input key. If the user enters an invalid mode transition, the demo displays this message on the terminal window:

```
Cannot go from RUN to VLPW directly.  
Next loop
```

## Getting Started

In most valid mode transitions, the SoC wakes up after receiving the RTC alarm or the GPIO switch trigger. However, in some modes, the SoC only accepts either RTC alarm or the GPIO switch trigger. In that case, the demo prints the following message on the terminal: Note: On the FRDM-KL25Z, FRDM-KL26Z and FRDM-KL46Z, the RTC counter is fed without the 32 Khz (OSC32KCLK) clock. Therefore, the accuracy of RTC alarms is impacted.

```
The board does not support wake up from this mode by RTC due to disabled External
Entering Very Low Leakage Stop 0 mode, press the SW1 button to wake up.
Wake up goes through Reset sequence.
```

### 25.4.4 Supported Low Power Modes By Platform

This table shows the supported modes on different platforms:

Platform	Supported Power Modes	Wakeup Sources
FRDM-K22F	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW2
FRDM-K64F	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW2
FRDM-KL02Z48M	WAIT, STOP, VLPR(1 MHz), VLPW, VLPS, VLLS1, VLLS3, RUN(48MHz)	LPTMR
FRDM-KL03Z48M	WAIT, STOP, VLPR(2 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW2
FRDM-KL25Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, PTD6 J2-17 to VSS J9-14
FRDM-KL26Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW1
FRDM-KL27Z	WAIT, STOP, VLPR(2 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW3
FRDM-KL43Z	WAIT, STOP, VLPR(2 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW3
FRDM-KL46Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW1

FRDM-KV10Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, VLLS0, VLLS1, VLLS3, RUN(75MHz)	RTC, SW3
FRDM-KV31F	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW3
FRDM-KW24	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW1
FRDM-KW40Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(32MHz)	RTC, SW2
MRB-KW01	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS1, VLLS3, RUN(48MHz)	RTC
TWR-K21D50M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW1
TWR-K21F120M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW3
TWR-K22F120M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW1
TWR-K24F120M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW2
TWR-K60D100M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS1, VLLS2, VLLS3, RUN(96MHz)	RTC, SW1
TWR-K64F120M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW1
TWR-K65F180M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz), HSRUN(180MHz)	RTC, SW3
TWR-K80F150M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz), HSRUN(150MHz)	RTC, SW3

## Getting Started

TWR-KL43Z48M	WAIT, STOP, VLPR(2 MHz), VLPW, VLPS, LLS, VLLS1, VLLS3, RUN(48MHz)	RTC, SW2
TWR-KM34Z75M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(72MHz)	RTC, SW1
TWR-KV10Z32	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, VLLS0, VLLS1, VLLS3, RUN(75MHz)	RTC, SW2
TWR-KV31F120M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW1
TWR-KV11Z75M	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, VLLS0, VLLS1, VLLS3, RUN(75MHz)	RTC, SW2
TWR-KW24D512	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW3
USB-KW40Z	WAIT, STOP, VLPR(4 MHz), VLPW, VLPS, LLS3, VLLS1, VLLS2, VLLS3, RUN(21MHz)	RTC

## Chapter 26

# Power Manager RTOS Demo

This demo application demonstrates how to use the Power Manager.

### 26.1 Overview

The Power Manager demo application demonstrates different Power Manager modes supported by the Kinetis SoCs. The set of supported low power modes and their transition possibility differ platform to platform. See section: "System Mode Controller" in a Reference Manual for each Kinetis Sub-family microcontroller.

### 26.2 Supported RTOS

- Freescale MQX RTOS
- FreeRTOS
- C/OS-II
- C/OS-III
- Bare Metal (no RTOS)

### 26.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis software development kit Power Manager demo.

The Bare Metal (no RTOS) demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M

## System Requirements

- TWR-KL43Z48M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z

The FreeRTOS, Freescale MQX RTOS, C/OS-II, C/OS-III demo Supported Platforms:

- FRDM-K22F
- FRDM-K64F
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z

## 26.4 System Requirements

### 26.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for a specific device
- Personal Computer

### 26.4.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/demo_apps/power_manager_rtos_-demo/<configuration>/<toolchain>` where `<configuration>` is either bare metal or a supported RTOS.
- Library dependencies:
  - Bare metal, FreeRTOS, uC/OS: `ksdk_platform_lib`

– MQX RTOS: `mqx_<board>`, `mqx_stdlib_<board>`

## 26.5 Getting Started

### 26.5.1 Hardware Settings

The demo does not require any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

### 26.5.2 Prepare the Demo

Follow the instructions in *Getting Started with Kinetis Software Development Kit (KSDK)* to:

- Set up hardware connections
- Configure a Terminal session
- Build and download application to targeted devices

Note: The demo is configured to work with the Terminal baudrate at 9600 bps. When running the demo, unplug all debugger devices. For the MRB-KW01, it is necessary to connect on the J8 pins 2-3.

### 26.5.3 Run the demo

1. Press the reset button on the hardware.
2. A control menu is displayed on the Terminal window. Note that the list on the menu is not the same for all platforms. It depends on the list of supported low power modes. For example, on the TWR-K64F120M, this menu displays:

#### ##### Power Manager Demo

```
Core Clock = 48000000Hz
```

```
SMC mode = kStatRun
```

```
Select the desired operation
```

```
Press A for enter: RUN - Normal RUN mode
```

```
Press B for enter: Wait - Wait mode
```

```
Press C for enter: Stop - Stop mode
```



## Getting Started

Press D for enter: VLPR - Very Low Power Run mode

Press E for enter: VLPW - Very Low Power Wait mode

Press F for enter: VLPS - Very Low Power Stop mode

Press G for enter: LLS - Low Leakage Stop mode

Press H for enter: VLLS0 - Very Low Leakage Stop 0 mode

Press I for enter: VLLS1 - Very Low Leakage Stop 1 mode

Press J for enter: VLLS3 - Very Low Leakage Stop 3 mode

Waiting for key to be pressed...

1. Enter a command by pressing the corresponding input key. If the user enters an invalid mode transition, the demo displays this message on the terminal window:

```
Cannot go from RUN to VLPW directly.
Next loop
```

In most valid mode transitions, the SoC wakes up after receiving the RTC alarm or the GPIO switch trigger. However, in some modes, the SoC only accepts either RTC alarm or the GPIO switch trigger. In that case, the demo prints the following message on the terminal: Note: On the FRDM-KL25Z and FRDM-KL46Z, the RTC counter is fed without the 32Khz (OSC32KCLK) clock. Therefore the accuracy of RTC alarms is impacted.

The board does not support wake up from this mode by RTC due to disabled External Entering Very Low Leakage Stop 0 mode, press the SW1 button to wake up. Wake up goes through Reset sequence.

### 26.5.4 Supported Low Power Modes By Platform

This table shows the supported modes on different platforms:

Platform	Supported Power Modes	Wakeup Sources
FRDM-K22F	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW2

FRDM-K64F	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW2
FRDM-KL25Z	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, PTD6 J2-17 to VSS J9-14
FRDM-KL27Z	WAIT, STOP, VLPR(2MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW3
FRDM-KL43Z	WAIT, STOP, VLPR(2MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW3
FRDM-KL46Z	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS3, RUN(48MHz)	RTC, SW1
FRDM-KV31F	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW3
FRDM-KW24	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW1
FRDM-KW40Z	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(32MHz)	RTC, SW2
TWR-K21D50M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW1
TWR-K21F120M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW3
TWR-K22F120M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW1
TWR-K24F120M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW2
TWR-K60D100M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS1, VLLS2, VLLS3, RUN(96MHz)	RTC, SW1
TWR-K64F120M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz)	RTC, SW1

## Getting Started

TWR-K65F180M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz), HSRUN(180MHz)	RTC, SW3
TWR-K80F150M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(120MHz), HSRUN(150MHz)	RTC, SW3
TWR-KL43Z48M	WAIT, STOP, VLPR(2MHz), VLPW, VLPS, LLS, VLLS1, VLLS3, RUN(48MHz)	RTC, SW2
TWR-KV31F120M	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS0, VLLS1, VLLS2, VLLS3, RUN(80MHz), HSRUN(120MHz)	RTC, SW1
TWR-KW24D512	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS, VLLS0, VLLS1, VLLS2, VLLS3, RUN(48MHz)	RTC, SW3
USB-KW40Z	WAIT, STOP, VLPR(4MHz), VLPW, VLPS, LLS3, VLLS1, VLLS2, VLLS3, RUN(21MHz)	RTC

## Chapter 27

### RTC Function Demo

This demo application demonstrates how to use the RTC driver.

#### 27.1 Overview

This RTC demo application demonstrates the important features of the RTC Module by using the RTC Peripheral Driver.

It supports these features:

- Calendar
  - Get the current date time with Year, Month, Day, Hour, Minute and Second.
  - Set the current date time with Year, Month, Day, Hour, Minute and Second.
- Alarm
  - Set the alarm based on the current time.
  - Application prints a notification when the alarm expires.
- Seconds interrupt
  - Use second interrupt function to display a digital time blink every second.
- Compensation
  - Configure the compensation with cycles.
  - The 1 Hz RTC clock with compensation configured is output to a pin. Use an oscilloscope to check the compensation result.

#### 27.2 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the KSDK RTC Function demo.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL03Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M

## Getting Started

- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KW24D512
- USB-KW40Z

## 27.3 System Requirement

### 27.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 27.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/rtc\_func/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 27.4 Getting Started

### 27.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control (Note that for the FRDM-KL03 platform, the terminal baud rate should be 9600)
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

Note: For the MRB-KW01, it is necessary to connect on the J8 pins 2-3 and change the CLOCK\_SETUP to 1 (or change the RTC input to OSC32KCLK in a different way).

For detailed instructions, see a Kinetis SDK User's Guide for your board.

## 27.5 Run the demo

This menu is displayed on the serial terminal:

Please choose the sub demo to run:

- 1) Get current date time.
- 2) Set current date time.
- 3) Alarm trigger show.
- 4) Second interrupt show (demo for 20s).
- 5) Set RTC compensation.

Select:

---

## Run the demo

## Chapter 28

### SAI Demo

This demo application demonstrates how to use the SAI drivers.

#### 28.1 Overview

The SAI Demo project is a digital audio demonstration program that uses the KSDK software. It performs audio playback from either a .wav file, stored in Flash, or from the line-in on a TWR-AUDIO-SGTL Tower System module using the KSDK I2S and I2C drivers. On the TWR-K22F120M, TWR-K24F120M, TWR-K64F120M, and the TWR-K80F150M Tower System modules, the project also uses the CMSIS-DSP library to perform a Fast Fourier Transform, and return the fundamental frequency of the line-in audio.

#### 28.2 Supported Hardware

This demo supports the following Freescale Freedom development platforms and Tower System modules:

- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M

#### 28.3 System Requirement

##### 28.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 28.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/sai\_demo/<toolchain>.
- Library dependencies: ksdk\_platform\_lib



## Run the demo

### 28.4 Getting Started

#### 28.4.1 GCC Compiler notes

When building the demo with GCC, ensure that the demo and platform library are built with this option:

```
<code>
    <br>CHOOSE_FLOAT=HARD_FP<br>
</code>
```

Otherwise, the project does not use the Kinetis device's hardware floating point when using the CMSIS--DSP library.

#### 28.4.2 Hardware Settings

These Tower System modules are required to run the sai\_demo:

- TWR-ELEV (except for the TWR-K24F120M)
- TWR-AUDIO-SGTL (except TWR-K24F120M which has a built-in one)

#### 28.4.3 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

### 28.5 Run the demo

To hear the audio playback, connect a set of headphones to the headphone output on the TWR-AUDIO--SGTL card. For input to the codec, connect an audio source to the Line-In on the TWR-AUDIO-SGTL.

When the demo starts, this message is displayed in the terminal output window:

```
Audio Demo!
```

```
Press spacebar to start demo.
```

```
Demo begin...
```

The user can either play back audio from the line-in source, or play a .wav file stored in the Flash. The line-in option plays the audio gathered from the codec line-in for approximately 15 seconds.

```
Select player:
  1. Line-In Playback
  2. Wav File Playback
->1
```

If selecting playback from the line-in source, decide whether to perform an FFT analysis to find the fundamental frequency of the audio input. Finding the fundamental frequency is best suited for pure tones played into the line-in of the TWR-AUDIO-SGTL card.

```
Select filter:
  1. FFT - Find Fundamental Frequency
  2. None
->1
```

The user is prompted to select from a list of headphone output levels:

```
Choose headphone dB level:
  1. +3.0 dB
  2. 0.0 dB
  3. -3.0 dB
  4. -6.0 dB
  5. -12.0 dB
  6. -24.0 dB
  7. -48.0 dB
->5
Frequency is 93 Hz
```

The table shows the terminal display after playback has completed and the FFT option was selected.

These are the options for the .wav file option:

```
Select player:
  1. Line-In Playback
  2. Wav File Playback
->2
Select Wav file:
  1. Audio Demo
->1
Choose headphone dB level:
  1. +3.0 dB
  2. 0.0 dB
  3. -3.0 dB
```

## Run the demo

4. -6.0 dB
5. -12.0 dB
6. -24.0 dB
7. -48.0 dB

->5

The quality of the .wav file PCM data depends on the demo system and the compiler.

This table shows the audio sample rate, channels and bit depth of the .wav file for the various platforms and compilers.

Hardware System	Sample Rate (kHz)				Bit Depth				Channels			
	IAR	ARM	GN-U-G-CC	KDS-GCC	IAR	ARM	GN-U-G-CC	KDS-GCC	IAR	ARM	GN-U-G-CC	KDS-GCC
TW-R--K22-F120-M	44.1	44.1	11.-025	11.-025	16	16	16	16	2	2	2	2
TW-R--K24-F120-M	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2
TW-R--K60-F100-M	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2
TW-R--K64-F120-M	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2
TW-R--K65-F180-M	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2
TW-R--K80-F150-M	44.1	44.1	44.1	44.1	32	32	32	32	2	2	2	2

<b>TWR-K21-F120-M</b>	44.1	44.1	11.-025	11.-025	16	16	16	16	2	2	2	2
-----------------------	------	------	---------	---------	----	----	----	----	---	---	---	---

Quality differences of the .wav playback depend on the size constraints of the target device, the Flash size, and the density of the code generated by the compiler.

Note that all supported platforms play audio from the line-in option with the same quality: 16-bit, 44.1 kHz, 2 channels.

## 28.6 Key Functions

### **void audio\_stream\_init(void)**

Initializes the I2S, I2C, and TWR-AUDIO-SGTL Tower System module for streaming audio from Line-In.

### **void audio\_wav\_init(wave\_file\_t \*newWav)**

Initializes the I2S, I2C, and TWR-AUDIO-SGTL Tower System module for playing back WAV file in Flash.

Parameters

<i>newWav</i>	Pointer to wave file data structure.
---------------	--------------------------------------

### **uint32\_t config\_volume(sgtl\_handler\_t \*handler, sgtl\_module\_t module, uint32\_t volumeCtrl)**

Sets volume from the user input.

Parameters

<i>handler</i>	pointer to codec handler structure.
<i>module</i>	name of module on codec to set the volume for.
<i>volumeCtrl</i>	user input data from terminal menu.

Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

---

## Key Functions

`snd_status_t stream_audio(dsp_types_t dspType, uint8_t volumeCtrl)`

Plays a stream of audio.

### Parameters

<i>dspType</i>	Used to select one DSP function to perform on the data.
<i>volumeCtrl</i>	Value used to set decibel level on codec.

### Returns

Returns soundcard status

### **snd\_status\_t get\_wav\_data(wave\_file\_t \*waveFile)**

Collects data from WAV file header.

### Parameters

<i>waveFile</i>	Data structure of pcm data array.
-----------------	-----------------------------------

### Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

### **snd\_status\_t play\_wav(uint32\_t \*pcmBuffer, uint8\_t volumeCtrl)**

Plays the PCM audio data from the WAV format array.

### Parameters

<i>pcmBuffer</i>	Pointer to data array containing WAV formatted audio data.
<i>volumeCtrl</i>	Value used to set decibel level on codec.

### Returns

status\_t Return kStatus\_Success if function completed successfully, return kStatusFail if function failed.

### **void send\_wav(uint8\_t \*dataBuffer, uint32\_t length, sai\_data\_format\_t \*dataFormat)**

Sends audio data to the sound card.

## Key Functions

### Parameters

<i>pdataBuffer</i>	Pointer to data array containing WAV formatted audio data.
<i>length</i>	length of WAV file to send.
<i>dataFormat</i>	Point to audio_data_format_t for sound card.

### **float32\_t do\_fft(sai\_data\_format\_t \*dataFormat, uint8\_t \*buffer, float32\_t \*fftData, float32\_t \*fftResult)**

Performs frequency analysis and finds fundamental frequency of the PCM data.

### Parameters

<i>dataFormat</i>	Pointer to audio data format structure.
<i>buffer</i>	Pointer to data array to store modulated PCM data.
<i>fftData</i>	Pointer to data array for storing Fast Fourier Transform data.
<i>fftResult</i>	Point to data array for storing real frequency bins from FFT.

### Returns

float32\_t Returns fundamental frequency in Hz.

## Chapter 29

# SLCD basic testing and an Guess Number game

This demo application does SLCD basic testing and demonstrates usage of SLCD APIs in a guess number game.

### 29.1 Overview

The SLCD basic testing and an Guess Number game project is a demonstration program that uses the KSDK software. It implements the following features:

- SLCD basic testing. All numbers and icons are shown on the SLCD screen.
- A guess number game. All numbers are shown on the SLCD screen.
- RNGA module is also used to generate random numbers.

### 29.2 Supported Platforms

This Tower System module is supported by the KSDK SLCD basic testing and a Guess Number game demo.

- TWR-KM34Z75M

### 29.3 Getting Started

#### 29.3.1 Hardware Settings

This project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this demo.

#### 29.3.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the appropriate board User's Guide.



## Communication Interface Settings:

### 29.4 Run the demo

This example shows how to run the demo.

1. Basic Testing The demo performs basic testing on the SLCD first. All numbers and icons are shown one-by-one on the screen.
2. Guess number game Next, the demo asks the user to play a guess number game. The user can input the number (0-9999) in the console and the number is displayed on the SLCD screen. <codeblock>
  - ----- Start basic SLCD test -----
  - ----- SLCD Guess Num Game -----
  - The number input and final number are shown on the SLCD.
  - Check SLCD for these numbers.
  - Let's play:
  - Guess the number I want(0 - 9999), Press 'enter' to end: 5000
  - The input number 5000 is smaller than what I want. Guess again!
  - Guess the number I want(0 - 9999), Press 'enter' to end: 7500
  - The input number 7500 is bigger than what I want. Guess again!
  - Guess the number I want(0 - 9999), Press 'enter' to end: 6125
  - The input number 6125 is smaller than what I want. Guess again!
  - Guess the number I want(0 - 9999), Press 'enter' to end: 6396
  - Great, 6396, you have GOT it!
  - Play again? Input 'Y' or 'N'.
  - y
  - 
  - ----- SLCD Guess Num Game -----
  - The number input and final number are shown on the SLCD.
  - Check SLCD for these numbers.
  - Let's play:
  - Guess the number I want(0 - 9999), Press 'enter' to end:

</codeblock>

### 29.5 Communication Interface Settings:

TWR-KM34Z75M	PTI6/UART2_RX	PTI7/UART2_TX	UART2
--------------	---------------	---------------	-------

## Chapter 30

### SLCD Low Power Demo

This demo application demonstrates how to use SLCD with low power support.

#### 30.1 Overview

This demo application demonstrates how to use SLCD module to drive an external segment LCD and also demonstrates the SLCD's low power features.

#### 30.2 Supported Hardware

These Freescale Freedom development platforms are supported by this demo.

- FRDM-KL43Z

#### 30.3 System Requirement

##### 30.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

#### 30.4 Getting Started

##### 30.4.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions, see the Getting Started with Kinetis SDK document for your board.

---

## Run the demo

### 30.5 Run the demo

After demo is running, the debug terminal prints the demo log and segment board on the Freescale Freedom platform board displays RTC time.

## Chapter 31

### Thermistor Lab Demo

This demo application demonstrates how to use PDB to trigger ADC and measure on-board thermistor.

#### 31.1 Overview

This lab shows how to configure and use the ADC module to sample the differential voltage across on-board thermistors RT1-RT4. If the user touches any on-board thermistor with a finger, the lab application detects a change in the thermistor temperature and starts flashing the corresponding LED pair.

- The lab tutorial demonstrates:
  - how to configure ADC module to read differential inputs
  - how to filter and process ADC results
  - how to use FreeMASTER visualization tool to display sampled results.

#### 31.2 Supported Hardware

This Tower System modules are supported by the Thermistor Lab demo.

-TWR-KV10Z32 -TWR-KV11Z75M

#### 31.3 System Requirement

##### 31.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 31.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/thermistor\_lab/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

#### 31.4 Getting Started

##### 31.4.1 Prepare the Demo

1. Ensure that these jumpers are shorted.

## Getting Started

### TWR-KV10Z32:

J8	2-3	
J11	1-2	3-4
J12	1-2	3-4
J13	1-2	3-4
J14	1-2	3-4

### TWR-KV11Z75M:

J6	1-2	3-4
J7	1-2	3-4
J8	1-2	3-4
J9	1-2	3-4
J13	2-3	

1. Download the program to the target board.
2. Touch 4 on-board thermistor to see LED change.

For detailed instructions, see a Kinetis SDK User's Guide for your board.

### 31.4.2 Demo Code Overview

The lab application configures both ADCs to be triggered by the FlexTimer0 via the PDB. The FlexTimer is configured to generate the 16 KHZ PWM and the channel1 trigger is used to trigger both ADCs via the PDB. The PDB is configured to generate four delayed trigger signals to both ADCs per FlexTimer0 Channel 1 trigger and, as a result, 4 ADCs samples are converted per each FlexTimer channel trigger. The ADC is configured to be in a 16-bit differential and ping-pong mode.

When an ADC conversion is complete, an interrupt is generated by the ADC module and an interrupt service routine is executed. The interrupt service routine ADCn\_ISR() calls the ADCn\_Task which executes these tasks:

reads ADC results registers. filters ADC results with low-pass FIR filter. differentiates filtered results to detect a change in a voltage across the thermistor. detects a negative/positive slope of a voltage change to determine which LED is turned on/off. executes a software timer, whose time out period is 100 ms and resets every 400 ms. The software timer is used to generate a time base for LEDs flashing.

### 31.4.2.1 ADC Differential Mode of Operation

To measure a voltage across the thermistor, configure the ADC for a differential mode of operation. In a differential mode, the ADC measures a difference between two analogous inputs. The ADC enables selecting input pairs which are treated as differential inputs.

#### Detection of a Change of Thermistor Voltage

If a user places a finger on a thermistor, its temperature increases. The temperature rise results in a voltage decrease across the resistor. If the user removes the finger, the temperature decreases and the voltage goes up.

A simple differentiators are used to detect a voltage change. The filtered thermistor voltage is stored in a buffer. The buffer size is defined by the `BUFF_SIZE`. The differentiator calculates a difference between an actual voltage sample and a sample delayed by `i_delay` pointer, which points to the buffer.

```
delta_rt1 = rt1_filt -rt1_filt_buff[i_delay];
```

If the voltage across the thermistor decreases, the differentiator returns a negative value. If the voltage increases, the differentiator returns a positive value. If there is no change in voltage, the deviator output returns zero. The bigger the slope of voltage increase/decrease, the more positive/negative value the differentiator returns. The lab application uses this information to detect if the finger is placed on the particular thermistor or if the finger was removed. Placing/removing a finger on the thermistor is characterized by a certain slope (rate) of voltage decrease/increase. The application defines positive and negative thresholds for each thermistor. If a difference output exceeds threshold limits (for at least three consequent samples), an action is taken and a corresponding LED starts to flash.



## Chapter 32

# Heating, Ventilating, and Air Conditioning on lwIP TCP/IP Stack

This demo application demonstrates the Heating, Ventilating, and Air Conditioning demo on lwIP TCP/IP stack with different RTOSes.

### 32.1 Overview

This is simulation of HVAC system with web server using lwIP TCP/IP stack on different RTOSes. The user uses an Internet browser to send a request for connection, to set up HVAC system on board. The board acts as an HTTP server and sends a Web page back to the PC. The user also can directly set up desired temperature by pressing switches on board and observe LEDs status.

### 32.2 Supported RTOS

- Freescale MQX RTOS
- FreeRTOS
- C/OS-II
- C/OS-III

### 32.3 Supported Hardware

These Freescale Freedom development platforms and Tower System modules are supported by the Kinetis SDK web\_hvac demo.

- FRDM-K64F
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

### 32.4 System Requirement

#### 32.4.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer



## Getting Started

### 32.4.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/web\_hvac/<rtos>/<toolchain>. Where <rtos> is one of the supported RTOSes.
- Library dependencies:
  - Baremetal, FreeRTOS, uC/OS: ksdk\_platform\_lib
  - MQX RTOS: mqx\_<board>, mqx\_stdlib\_<board>

### 32.4.3 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/demo\_apps/web\_hvac/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 32.5 Getting Started

### 32.5.1 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with the following settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.

For detailed instructions steps, see a Kinetis SDK User's Guide for your board.

### 32.5.2 Network Configuration

Configure the IP address of PC network adapters as shown: IP address - 192.168.2.100 Subnet Mask - 255.255.255.0

### 32.5.3 Run the demo

1. Download the program to the target board, which should be installed in Tower System or Freescale Freedom.
2. Connect the Ethernet cable between the PC and the board.
3. When successfully connected, reset the board to run the demo.
4. Open the PC command window, type in "ping 192.168.2.102" to test whether lwIP stack is running.

5. Input "192.168.2.102" in the URL of an Internet browser on a PC. If successful, the web page which the board returns opens in the browser.
6. In the browser, click on "HVAC Status" option to observe the current information on the target board.
7. In the browser, Selected "Change Settings" option, input new setting then click "Set" button, the browser loads the status page. If successful, the desired temperature changes to a new setting and the actual temperature increases/decreases until it reaches desired temperature:
  - Change the desired temperature to a greater value and HVAC mode to "Heat", the actual temperature increases until it meet configured desired temperature.
  - Change the desired temperature to a lower value and HVAC mode to "Cool", the actual temperature decreases until it meets the configured desired temperature
8. On the other hand, the desired temperature can be changed by pressing the switches on board. The LEDs (if they exist) on the board represent HVAC system's state:
  - LED1: Simulate the Fan's state
  - LED2: System in the Heat mode
  - LED3: System in the Cool mode
  - LED4: Simulate the heart beat, increase real temperature (i.e., by hair dryer) to see the LED4 go faster and decrease temperature to see it slow down.



## Chapter 33

### ADC16 Example

#### 33.1 Overview

The ADC16 Example project is a demonstration program that uses the KSDK software to measure the internal temperature of the chip. This function uses the user input as a trigger to start the measurement. Use the ADC to read the chip's temperature, press any key in the terminal and print the converted value and temperature to the terminal.

#### 33.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the ADC16 example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

## Getting Started

- USB-KW40Z\_KW40Z

### 33.3 System Requirement

#### 33.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 33.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/adc16/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

### 33.4 Getting Started

#### 33.4.1 Hardware settings

The ADC16 Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 33.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 33.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
press any key to start measure temperature
```

Input any character from the keyboard to start calculating the temperature with the calibrated value and formula listed in the Reference Manual. These instructions are displayed/shown on the terminal window:

```
press any key to start measure temperature
ADC converted value: 14151
Temperature 29
press any key to start measure temperature
```



## Chapter 34 AFE Example

### 34.1 Overview

The AFE Example project is a demonstration program that uses the KSDK software. In this example, the AFE module samples the voltage difference of the EXT\_SD\_ADPO and EXT\_SD\_ADM0 pins.

### 34.2 Supported Platforms

This Tower System module is supported by the AFE example.

- TWR-KM34Z75M

### 34.3 System Requirement

#### 34.3.1 Hardware requirements

- J-Link ARM
- USB A to USB Mini B cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer
- DC Power Supply

### 34.4 Getting Started

#### 34.4.1 Hardware settings

This example requires one board and one DC Power Supply. Connect the DC Power Supply output signals to AFE differential sample pins:

Board	Connects To	DC Power Supply	
EXT_SD_ADPO	->	Power Positive end	
EXT_SD_ADM0	->	Power Negative end	

Make these connections between the board and DC Power Supply by using external wires:

#### TWR-KM34Z75M

Board		Connects To	DC Power Supply	
Pin Name	Board Location		DC Power Supply	connection ends



## Getting Started

Pin 45 of QFP144/- AFE_SDADP0	J31 Pin 2	->	DC Power Supply	Positive end
Pin 46 of QFP144/- AFE_SDADM0	J31 Pin 4	->	DC Power Supply	Negative end

### 34.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 34.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
AFE Example: An 8 MHz external crystal is used as a clock source for AFE in this example.
Single and polling mode is selected.
```

Adjust the output DC value from 0 to 500 mV. For example, increase the output DC value while the program is running. The printed log is displayed in the terminal window as shown below.

```
result0 = 4910994 0x4aef92
result0 = 4928640 0x4b3480
result0 = 5930280 0x5a7d28
result0 = 6031566 0x5c08ce
result0 = 6633264 0x653730
result0 = 6723942 0x669966
result0 = 6948546 0x6a06c2
result0 = 7288512 0x6f36c0
result0 = 7418664 0x713328
result0 = 7620930 0x744942
result0 = 8039334 0x7aaba6
result0 = 8117874 0x7bde72
result0 = 8268936 0x7e2c88
result0 = 8276484 0x7e4a04
result0 = 8280666 0x7e5a5a
result0 = 8294334 0x7e8fbe
```

## Chapter 35 CMP Example

### 35.1 Overview

The CMP Example compares the analog input to the reference DAC output to control an LED. If the analog input is higher than the DAC output, the LED is on. Otherwise, the LED is turned off.

### 35.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the CMP example.

- FRDM-K64F
- FRDM-KL03Z
- FRDM-KV10Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KM34Z75M
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z\_KW40Z

### 35.3 System Requirement

#### 35.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 35.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/cmp/<toolchain>.

## Getting Started

- Library dependencies: ksdk\_platform\_lib

### 35.4 Getting Started

#### 35.4.1 Hardware configuration

In case of TWR-KV11Z75M: 1) Remove jumpers from J4 and J17 and make the connections between J4 pin 2 and J17 pin 3 by using the external wire. 2) SW3 is used instead of SW1.

#### 35.4.2 Hardware settings

The CMP Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example. FRDM-KV10Z: The on-board SW3 button must be connected to PTC2 pin manually. Connect J1-10 with J3-13 by using external wire.

#### 35.4.3 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 35.4.4 Run the example

These instructions are displayed/shown on the terminal window:

```
The demo compares analog input to the reference DAC output to control an LED.
The LED is turned ON/OFF when the analog input is LOWER/HIGHER than the DAC output.
Press SW to see the LED status.
```

```
for TWR-KM34Z75M
Change the potentiometer position to see the LED status.
```

```
The analog input is HIGHER than DAC output!
The analog input is LOWER than DAC output!
The analog input is HIGHER than DAC output!
The analog input is LOWER than DAC output!
```

Press the SW (\*) button on the board and observe the LED toggle. NOTE: For the TWR-K65F180M board, the on-board potentiometer is used instead of the SW button.



## Chapter 36 CMT Example

### 36.1 Overview

The carrier modulator transmitter (CMT) provides the means to generate the protocol timing and carrier signals for a wide variety of encoding schemes. The CMT is intended to be sufficiently programmable to handle the timing requirements of most protocols with minimal CPU intervention. This example uses the CMT peripheral to perform data modulation.

### 36.2 Supported Platforms

This Freescale Freedom development platform is supported by the CMT example.

- TWR-K60D100M
- FRDM-KW40Z

### 36.3 System Requirement

#### 36.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

#### 36.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/cmt/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 36.4 Getting Started

#### 36.4.1 Hardware settings

The CMT Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

## Getting Started

### 36.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Connect a oscilloscope to
  - the pin 2 of the Jumper 2 on the board for TWR-K60D100M
  - the pin 6 of the J25 connector on the board for FRDM-KW40Z
3. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
4. Download the program to the target board.
5. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 36.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
CMT Initialize finished!  
Start carrier modulation ....  
16 bit data carrier modulation finished. Stop carrier modulation!
```

The output waveform of the carrier modulated data can be seen on the oscilloscope.

The example modulates the two bytes: 0x15, 0x24.

Verify the waveform on the oscilloscope:

- waveform data: 1010100000100100.
- bit one is with 10 microsecond high time period
- bit zero is with the 1 microsecond high time period add 9 microsecond low time period.

To easily capture the signal, there are two notifications:

1. For only two bytes to transmit, we should use trigger to capture the output signal.
2. Set the voltage range to 1 volt(k60d100m) or 0.5 volt(kw40z), and adjust the scale to make the smallest time unit to about 40 us.

## Chapter 37 COP Example

### 37.1 Overview

The COP Example project is a demonstration program that uses the KSDK software to enable Watchdog and continuously refreshes the Watchdog to prevent the CPU reset. After pushing the software button, the Watchdog expires after approximately 1 seconds and the chip is reset.

- Combine refresh and reset operation on the WDOG timer.
- Use a SW to start the COP. After pressing the software button, the COP starts to expire.
- Use an LED to indicate the reset process. First, the LED is turned off when the software button is pressed, the LED starts blinking. After reset, the LED is turned off. (\*\*When running this example, we need enable watchdog)

### 37.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the COP example.

- FRDM-KL03Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KW40Z
- TWR-KL43Z48M

### 37.3 System Requirement

#### 37.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 37.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/cop/<toolchain>.
- Library dependencies: ksdk\_platform\_lib



## Getting Started

### 37.4 Getting Started

#### 37.4.1 Hardware settings

The COP Example project does not call for a special hardware configuration. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 37.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 37.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
COP example begin.  
Press SW to begin expiring COP
```

Press the SW (\*) button on the board and the board receives and refreshes the reset operation on COP WDOG timer. These instructions are displayed/shown on the terminal window:

```
Press SW to begin expiring COP  
Board resets after 1 seconds.  
COP reset the chip successfully
```

## Chapter 38 DAC Example

### 38.1 Overview

The DAC Example project is a demonstration program that uses the KSDK software. This function uses the terminal to enter a DAC value and convert this value to a DAC output.

### 38.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the DAC example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL43Z48M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M

### 38.3 System Requirement

#### 38.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable

## Getting Started

- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 38.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/dac/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

## 38.4 Getting Started

### 38.4.1 Hardware settings

The DAC Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 38.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 38.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
DAC Example.  
Enter the value for DAC input from 0 to 65535
```

Input the DAC value and the board converts that value to the DAC output. The converted value can be seen on the oscilloscope. These instructions are displayed/shown on the terminal window:

```
Check oscilloscope to see DAC output of 20000
```

Verify that the voltage is compatible with the DAC level on the oscilloscope.

## Chapter 39 DMA Example

### 39.1 Overview

The direct memory access (DMA) controller performs complex data transfers with minimal intervention from the host processor. This example uses the DMA peripheral to transfer data from the Flash to RAM by using the DMA with different channels.

### 39.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the DMA example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-KM34Z75M
- TWR-KM34Z75M
- TWR-KL43Z48M
- TWR-KV10Z32
- USB-KW40Z\_KW40Z

### 39.3 System Requirement

#### 39.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Getting Started

### 39.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/dma/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 39.4 Getting Started

### 39.4.1 Hardware settings

The DMA Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 39.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on the board or launch the debugger in the IDE to begin running the example.

### 39.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
DMA EXAMPLE
Requesting channel 0 to transfer data from address 0x37ec to 0x1ffffe018

Starting transfer data ...
  Transferred with DMA channel No.0: successful
Press any key to start transferring data with another channel
```

Type characters from the keyboard and the board transfers data by using a different channel (number of supported channels depends on each DMA instance). These instructions are displayed/shown on the terminal window:

```
Requesting channel 1 to transfer data from address 0x37ec to 0x1ffffe018

Starting transfer data ...
  Transferred with DMA channel No.1: successful
```

Press any key to start transferring data with another channel  
Requesting channel 2 to transfer data from address 0x37ec to 0x1ffffe018

Starting transfer data ...

Transferred with DMA channel No.2: successful

Press any key to start transferring data with another channel

Requesting channel 3 to transfer data from address 0x37ec to 0x1ffffe018

Starting transfer data ...

Transferred with DMA channel No.3: successful

Press any key to start transferring data with another channel



## Chapter 40

### DSPI Example with other methods

#### 40.1 Overview

The DSPI Example project is a demonstration program that uses the KSDK software. This example provides 5 examples with 5 modes: DSPI polling, non-blocking, blocking, DMA blocking, DMA non blocking, and DSPI loopback.

- DSPI board to board:
  - Transfers data through instance 0 of SPI interface. SPI0 pins of the master board are connected to the SPI0 pins of the slave board.
  - It is important to ensure all SPI board-to-board connections are kept as short as possible and that a solid ground wire is connected between the boards. Preferably this ground connection should be as close as possible to the SPI signals on each board. A poor board-to-board connection compromises data signal integrity causing failures in the example.
  - Master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The slave sends back the received buffer from the master.  
(\* (Power up slave first)
- DSPI master loop-back:
  - Transfer data through instance 0 of SPI interface. The MISO pin and MOSI pin are connected.
  - Sends an array out through the MISO pin and compares it with the received buffer from the MOSI pin.
  -

#### 40.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the DSPI example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M



## Getting Started

- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

## 40.3 System Requirement

### 40.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 40.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/dspi/<use_case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 40.4 Getting Started

### 40.4.1 Hardware settings

- DSPI master loopback:
  - Transfers data through the instance 0 of the SPI interface. The MISO pin and MOSI pin are connected.
- DSPI board to board:
  - Transfers data through the instance 0 of the SPI interface. SPI0 pins of the master board are connected to the SPI0 pins of the slave board.

### FRDM-K22F :

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J1 pin 11	->	MISO	J1 pin 16
MOSI	J1 pin 16	->	MOSI	J11 pin 11
SCK	J1 pin 15	->	SCK	J1 pin 15
PCSO0	J24 pin 9	->	PCSO0	J24 pin 9
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KW24 :**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J2 pin 10	->	MISO	J2 pin 8
MOSI	J2 pin 8	->	MOSI	J2 pin 10
SCK	J2 pin 12	->	SCK	J2 pin 12
PCSO0	J2 pin 6	->	PCSO0	J2 pin 6
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KW40 :**

Ensure that J7 is disconnected and the SPI does not interfere with the serial connection to the external Flash chip.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J1 pin 10	->	MISO	J1 pin 8
MOSI	J1 pin 8	->	MOSI	J1 pin 10
SCK	J1 pin 12	->	SCK	J1 pin 12
PCSO0	J1 pin 6	->	PCSO0	J1 pin 6
GND	J1 pin 14	->	GND	J1 pin 14

**FRDM-K64F:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J2 pin 10	->	MISO	J2 pin 8
MOSI	J2 pin 8	->	MOSI	J2 pin 10
SCK	J2 pin 12	->	SCK	J2 pin 12
PCSO0	J2 pin 6	->	PCSO0	J2 pin 6
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KV31F :**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J2 pin 10	->	MISO	J2 pin 8

## Getting Started

MOSI	J2 pin 8	->	MOSI	J2 pin 10
SCK	J2 pin 12	->	SCK	J2 pin 12
PCSO0	J1 pin 15	->	PCSO0	J1 pin 15
GND	J2 pin 14	->	GND	J2 pin 14

### TWR-K21F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator A11	->	MISO	J20 pin 21
MOSI	J20 pin 21	->	MOSI	Primary Elevator A11
SCK	J20 pin 19	->	SCK	J20 pin 19
PCSO0	J20 pin 17	->	PCSO0	J20 pin 17
GND	Primary Elevator B2	->	GND	Primary Elevator B2

### TWR-K21D50M & TWR-K22F120M & TWR-K24F120M & TWR-K64F120M & TWR-KV10Z32 & TWR-KV31F120M & TWR-KW24D512:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator B44	->	MISO	Primary Elevator B45
MOSI	Primary Elevator B45	->	MOSI	Primary Elevator B44
SCK	Primary Elevator B48	->	SCK	Primary Elevator B48
PCSO0	Primary Elevator B46	->	PCSO0	Primary Elevator B46
GND	Primary Elevator B2	->	GND	Primary Elevator B2

### TWR-K60D100M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location

MISO	Primary Elevator A77	->	MISO	Primary Elevator A76
MOSI	Primary Elevator A76	->	MOSI	Primary Elevator A77
SCK	Primary Elevator B64	->	SCK	Primary Elevator B64
PCSO0	Primary Elevator A63	->	PCSO0	Primary Elevator A63
GND	Primary Elevator B2	->	GND	Primary Elevator B2

**TWR-K65F180M & TWR-K80F150M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator B44	->	MISO	Primary Elevator B45
MOSI	Primary Elevator B45	->	MOSI	Primary Elevator B44
SCK	Primary Elevator B48	->	SCK	Primary Elevator B48
PCSO0	Primary Elevator B46	->	PCSO0	Primary Elevator B46
GND	Primary Elevator B2	->	GND	Primary Elevator B2

**FRDM-KV10Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
SPI0_SIN	J2 pin 10	->	SPI0_SOUT	J2 pin 2
SPI0_SOUT	J2 pin 2	->	SPI0_SIN	J2 pin 10
SPI0_CLK	J2 pin 12	->	SCK	J2 pin 12
SPI0_SC0	J3 pin 9	->	PCSO0	J3 pin 9
GND	J2 pin 14	->	GND	J2 pin 14

**TWR-KV11Z75M:**

Master Board	Connects To	Slave Board
--------------	-------------	-------------

## Getting Started

Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator B44	->	MISO	Primary Elevator B45
MOSI	Primary Elevator B45	->	MOSI	Primary Elevator B44
SCK	Primary Elevator B48	->	SCK	Primary Elevator B48
PCSO0	Primary Elevator B46	->	PCSO0	Primary Elevator B46
GND	Primary Elevator B2	->	GND	Primary Elevator B2

### 40.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 40.4.3 Run the example

#### DSPI blocking Master-Slave

Note: Set up the slave first and the slave board displays this message on the terminal:

```
DSPI board to board blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Slave example is running...
```

The master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The master board prints this message on the terminal:

```
DSPI board to board blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Transfer at baudrate 468750

Master transmit:
```

```

01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
DSPI Master Sends/ Receives successfully
Press any key to run again

```

The slave board receives and prints this message on terminal:

```

Slave receive:
01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Slave example is running...

```

### DSPI non-blocking Master-Slave

Set up the slave first and the slave board displays this message on the terminal:

```

DSPI board to board non-blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Slave example is running...

```

The master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The master board prints this message on the terminal:

```

DSPI board to board non-blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Transfer at baudrate 468750

Master transmit:
01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
DSPI Master Sends/ Receives successfully
Press any key to run again

```

The slave board receives and prints this message on the terminal:

```

Slave receive:
01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Slave example is running...

```

### DSPI eDMA blocking Master-Slave

Set up the slave first and the slave board displays this message on the terminal:

## Getting Started

```

DSPI board to board EDMA blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Slave example is running...

```

The master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The master board print this message on the terminal:

```

DSPI board to board eDMA-blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Transfer at baudrate 468750

Master transmit:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
DSPI Master Sends/ Receives successfully
Press any key to run again

```

The slave board receives and print on terminal:

```

Slave receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Slave example is running...

```

## DSPI eDMA non-blocking Master-Slave

Set up the slave first and the slave board displays this message on the terminal:

```

DSPI board to board EDMA non-blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Slave example is running...

```

The master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The master board prints this message on the terminal:

```

DSPI board to board eDMA-non-blocking example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Transfer at baudrate 468750

Master transmit:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
DSPI Master Sends/ Receives successfully
Press any key to run again

```

The slave board receives and prints this message on terminal:

```
Slave receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Slave example is running...
```

### DSPI polling Master-Slave

Set up the slave first and the slave board displays this message on the terminal:

```
DSPI board to board polling example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Slave example is running...
```

The master sends an array to the slave and receives the array back from the slave. It also compares whether the two buffers are the same. The master board displays this message on the terminal:

```
DSPI board to board polling example
This example run on instance 0
Be sure DSPI0-DSPI0 are connected
Transfer at baudrate 468750

Master transmit:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
DSPI Master Sends/ Receives successfully
Press any key to run again
```

The slave board receives and prints this message on the terminal:

```
Slave receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Slave example is running...
```

### DSPI Loopback

These instructions are displayed/shown on the terminal window:

```
DSPI master self loopback example
This example run on instance 0
Be sure MISO-to-MOSI are connected
Transfer at baudrate 468750

Master transmit:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20
Master receive:
 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F 10
 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F 20

DSPI Sends/ Receives successfully
Press any key to run again
```





## Chapter 41 EDMA Example

### 41.1 Overview

The enhanced direct memory access (eDMA) controller is a second-generation performing complex data transfers with minimal intervention from a host processor. This example uses the eDMA peripheral to transfer data from the Flash to RAM using the eDMA with different channels.

### 41.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the EDMA example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV31F
- FRDM-KW24
- FRDM-KV10Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

### 41.3 System Requirement

#### 41.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Getting Started

### 41.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/edma/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

## 41.4 Getting Started

### 41.4.1 Hardware settings

The EDMA Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 41.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 41.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
EDMA transfer from memory to memory
```

```
Starting EDMA channel No. 0 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.0: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 1 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.1: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 2 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.2: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 3 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.3: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 4 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.4: successful
```

Press any key to start transfer with other channel

```
Starting EDMA channel No. 5 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.5: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 6 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.6: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 7 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.7: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 8 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.8: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 9 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.9: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 10 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.10: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 11 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.11: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 12 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.12: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 13 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.13: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 14 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.14: successful
Press any key to start transfer with other channel
```

```
Starting EDMA channel No. 15 to transfer data from addr 0x1fff0000 to addr 0x1fff0028
Transferred with eDMA channel No.15: successful
Press any key to start transfer with other channel
```

This example shows how to transfer data from Flash to RAM on each channel that are supported by the eDMA instance.



## Chapter 42

### EWM Example

#### 42.1 Overview

The EWM Example project is a demonstration program that uses the KSDK software. This function uses EWM as a Watchdog for an external circuit when the counter reaches a high value. First, the EWM keeps refreshing. When the software button is pressed, the EWM expires and an interrupt occurs.

#### 42.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the EWM example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

#### 42.3 System Requirement

##### 42.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Getting Started

### 42.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/ewm/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 42.4 Getting Started

### 42.4.1 Hardware settings

The EWM Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 42.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 42.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
EWM example
Press SW to expire EWM
```

Press the SW (\*) button on the board to reset the counter and enable the interrupt for the next run. These instruction are displayed/shown on the terminal window:

```
EWM interrupt has occurred
Press SW to allow the EWM to expire
```

## Chapter 43

### FLASH Example

#### 43.1 Overview

The Flash Example project is a demonstration program that uses the KSDK software to access Flash memory. The example provide following features:

- Check flash information
- Erase a sector and verify
- Program a sector and verify

#### 43.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the FLASH example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M



## Getting Started

- TWR-KW24D512
- USB-KW40Z\_KW40Z

### 43.3 System Requirement

#### 43.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 43.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/flash/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

### 43.4 Getting Started

#### 43.4.1 Hardware settings

The FLASH Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 43.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 43.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Flash Example Start
Flash Information:
Total Flash Size: 1024 KB, Hex: (0x100000)
Flash Sector Size: 4 KB, Hex: (0x1000)
There is no D-Flash (FlexNVM) on this Device.
There is no Enhanced EEPROM (EEE) on this Device.
Flash is UNSECURE!

Erase a sector of flash
successfully Erased Sector 0xfa000 -> 0xfb000

Program a buffer to a sector of flash
successfully Programmed and Verified Location 0xfa000 -> 0xfa080

Flash Example End
```

for - TWR-KM34Z75M These instructions are displayed/shown on the terminal window:

```
Flash Example Start
Flash Information:
Total Flash Size: 256 KB, Hex: (0x40000)
Flash Sector Size: 2 KB, Hex: (0x800)
There is no D-Flash (FlexNVM) on this Device.
There is no Enhanced EEPROM (EEE) on this Device.
Flash is UNSECURE!

Erase a sector of flash
Successfully Erased Sector 0x3d000 -> 0x3d800

Program a buffer to a sector of flash
Successfully Programmed and Verified Location 0x3d000 -> 0x3d080

Flash Example End
```



## Chapter 44 FlexCAN Example

### 44.1 Overview

This FlexCAN example application demonstrates the SDK Peripheral drivers working with different methods. FlexCAN network and FlexCAN loop-back are the two provided examples:

- CAN network: transfers data through the CAN interface. On node 1, the user inputs characters by using the UART debug terminal and sends the data with the FlexCAN interface. On the other node, the FlexCAN receives the data and prints it to the UART terminal.
- CAN loop-back: transfers data through the CAN loop-back interface. On one node, one 8-byte buffer stream transmitter output is internally sent back to the receiver input.

The board transfers and receives characters through the FlexCAN-UART interface. Type the characters on the keyboard and the board receives and displays them on the terminal screen. Look for instructions output to the terminal.

### 44.2 Supported Platforms

These Tower System modules are supported by the FlexCAN example:

- TWR-K21F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KV11Z75M

### 44.3 System Requirement

#### 44.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 44.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/flexcan/<use_case>/<toolchain>`.

## Getting Started

- Library dependencies: ksdk\_platform\_lib

### 44.4 Getting Started

#### 44.4.1 Hardware settings

TWR-SER Tower System module configuration (only FlexCAN network example)

- Short J5(1-2), J5(3-4), J5(5-6), J5(7-8), and J5(9-10) to enable CAN connection.
- Connect the two TWR-SER modules through the CAN port (J7).

Although not required, the recommendation is to leave the development board jumper settings and configurations in default state when running this example.

#### 44.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 44.4.3 Run the example

##### 44.4.3.1 FlexCAN loopback

These instructions are displayed/shown on the terminal window:

```
Running the FlexCAN loopback example.
*****FLEXCAN LOOPBACK EXAMPLE*****
Message format: Standard (11 bit id)
Message buffer 8 used for Rx.
Message buffer 9 used for Tx.
Interrupt Mode: Enabled
Operation Mode: TX and RX --> Normal

FlexCAN MB receive configuration
FlexCAN send configuration
Data transmit: 0a 0b 0c 0d 0e 0f 10 11
DLC=8, mb_idx=8
RX MB data: 0x0a 0b 0c 0d 0e 0f 10 11
ID: 0x123Press any key to run again!
```

### 44.4.3.2 FlexCAN network

After connecting the two boards, these instructions display on each terminal window. One board must be chosen as node A and the other board as node B. Data is sent continuously between the node A and the node B.

This message displays on the node A terminal:

```
*****FlexCAN : SCI2CAN demo *****
Message format: Standard (11 bit id)
Message buffer 8 used for Rx.
Message buffer 9 used for Tx.
OSJTAG Port used for Serial Console.
Interrupt Mode: Enabled
Operation Mode: TX and RX --> Normal

Select local nodes as A or B:
Node:A
Data from Node B. Data from Node B. Data from Node B.
```

This message displays on the node B terminal:

```
*****FlexCAN : SCI2CAN demo *****
Message format: Standard (11 bit id)
Message buffer 8 used for Rx.
Message buffer 9 used for Tx.
OSJTAG Port used for Serial Console.
Interrupt Mode: Enabled
Operation Mode: TX and RX --> Normal

Select local nodes as A or B:
Node:B
Data from Node A
```



## Chapter 45

### FlexIO simulated I2C Example with other methods

#### 45.1 Overview

The FlexIO I2C example application demonstrates the FlexIO simulated I2C driver working with different methods. The FlexIO I2C example shows transmit/receive between the FlexIO-simulated I2C and I2C1 using these efficiency methods:

- Using blocking method
- Using non-blocking method

#### 45.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the FlexIO I2C example.

- FRDM-KL27Z
- FRDM-KL43Z
- TWR-KL43Z48M
- TWR-K80F150M

#### 45.3 System Requirement

##### 45.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Personal Computer

##### 45.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/flexio/i2c/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 45.4 Getting Started

##### 45.4.1 Hardware settings

This example requires connecting the FlexIO pins with the I2C1 pins. Connect FlexIO pins to the I2C1 pins. Note that the default uses FlexIO pin5 and pin4:



## Getting Started

FlexIO Pins		Connects To	I2C1 Pins	
FlexIO Pin5		->	I2C1 SDA	
FlexIO Pin4		->	I2C1 SCL	

Make these connections between the FlexIO pins and the I2C1 pins by using external wires:

### TWR-KL43Z48

FlexIO Pins		Connects To	I2C1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PI-N5	Primary Elevator B39	->	I2C1 SDA	Primary Elevator A8
PTD4/FLEXIO_PI-N4	Primary Elevator B59	->	I2C1 SCL	Primary Elevator A7

### FRDM-KL43Z48M

FlexIO Pins		Connects To	I2C1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PI-N5	J2-12	->	I2C1 SDA	J2-18
PTD4/FLEXIO_PI-N4	J2-6	->	I2C1 SCL	J2-20

### FRDM-KL27Z48M

FlexIO Pins		Connects To	I2C1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PI-N5	J1-11	->	I2C1 SDA	J2-18
PTD4/FLEXIO_PI-N4	J1-9	->	I2C1 SCL	J2-20

### TWR-K80F150M

FlexIO Pins		Connects To	LPUART Pins	
Pin Name	Board Location		Pin Name	Board Location

PTB11/FLEXIO_P-IN5	B69	->	I2C1 SDA	B51
PTB10/FLEXIO_P-IN4	B70	->	I2C1 SCL	B50

### 45.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. For TWR-KL43Z48M, insert the Tower System module into TWR-ELEV.
3. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
4. Download the program to the target board.
5. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 45.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```

+++++++ FLEXIO I2C Master Send/Receive Example Start ++++++

-----Non-blocking&Blocking example-----
1. FlexIO simulated I2C master write a buffer to I2C1
2. I2C1 acts as slave and receives data from FlexIO simulated I2C Master.
3. Compare rxBuff and txBuff to see result.
4. FlexIO simulated I2C master read a buffer from I2C1
5. I2C1 send the buffer and FlexIO simulated I2C master receives the buffer.
6. Compare rxBuff and txBuff to see result.

=====

Press any key to start transfer:

```

Type a character on the keyboard and the FlexIO simulated I2C sends a buffer to the I2C1. It also compares the received buffer on the I2C1 side with the txBuff and checks whether the result is successful. Then, the I2C1 sends a buffer to the FlexIO simulated I2C, compares the receive buffer in the FlexIO simulated I2C side to the txBuff, and checks whether the result is successful.

```

-----Non-blocking example-----

FlexIO simulated I2C master to I2C standard slave write transfer succeeded!!

FlexIO simulated I2C master to I2C standard slave read transfer succeeded!!

-----Blocking example-----

```

## Getting Started

```
FlexIO simulated I2C master to I2C standard slave write transfer succeeded!!
```

```
FlexIO simulated I2C master to I2C standard slave read transfer succeeded!!
```

```
...
```

## Chapter 46

### Flexio I2S Example with other methods

#### 46.1 Overview

The FlexIO I2S example project is a demonstration program that uses the KSDK software. This example plays back a period of sound stored in the Flash. This example involves four methods:

- Using the master interrupt
- Using the master DMA
- Using the slave interrupt and slave DMA

#### 46.2 Supported Platforms

These Tower System modules are supported by the FlexIO I2S example:

- TWR-KL43Z48M
- TWR-K80F150M

#### 46.3 System Requirement

##### 46.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- TWR-SGTL5000 board
- Headphone
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

##### 46.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/flexio/i2s/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 46.4 Getting Started

##### 46.4.1 Hardware settings

This example requires connecting the FLEXIO pins with the SAI pins so that the I2S signals can route to the TWR-SGTL5000 Tower System module. Connect FlexIO pins to the SAI pins. Note that the default

## Getting Started

uses the FlexIO pin0 ~ pin3:

Flexio Pins		Connects To	SAI Pins	
Flexio Pin0		->	SAI TxData	
Flexio Pin1		->	SAI RxData	
Flexio Pin2		->	SAI SCLK	
Flexio Pin3		->	SAI FS	

Make these connections between the FlexIO pins and SAI pins by using external wires:

### TWR-KL43Z48

Flexio Pins		Connects To	SAI Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD4/FLEXIO_PIN4 (*)	Primary Elevator B9	->	SAI SCLK (*)	Primary Elevator A22
PTD5/FLEXIO_PIN5 (*)	Primary Elevator B7	->	SAI Fs (*)	Primary Elevator A23
PTD0/FLEXIO_PIN0	Primary Elevator B46	->	SAI TxData	Primary Elevator A25
PTD1/FLEXIO_PIN1	Primary Elevator B48	->	SAI TxData	Primary Elevator A24

### TWR-K80F150M

Flexio Pins		Connects To	SAI Pins	
Pin Name	Board Location		Pin Name	Board Location
PTB10/FLEXIO_PIN4 (*)	Primary Elevator B70	->	SAI SCLK (*)	Primary Elevator A22
PTB11/FLEXIO_PIN5 (*)	Primary Elevator B69	->	SAI Fs (*)	Primary Elevator A23
PTB0/FLEXIO_PIN0	Primary Elevator A38	->	SAI TxData	Primary Elevator A25
PTB1/FLEXIO_PIN1	Primary Elevator A37	->	SAI RxData	Primary Elevator A24

### 46.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Insert all boards into TWR-ELEV.
3. Insert headphones into J7 port on the TWR-SGTL5000 Tower System module.
4. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
5. Download the program to the target board.
6. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 46.4.3 Run the example

These instruction are repeatedly displayed/shown on the terminal window:

```
Master Interrupt testing passed!
```

```
Master DMA testing passed!
```

```
Slave Interrupt testing passed!
```

```
Slave DMA testing passed!
```

Users can hear the sine wave sound in the headphones. <note> Because the FlexIO does not have the MCLK, the example has to use the MCLK in the TWR-SGTL5000 Tower System module to make the codec work correctly. The clock, which is not a part of the FlexIO clock source, is not accurate. This issue causes the clock mismatch between the FlexIO and the sgtl5000 codec. As a result, when the FlexIO i2s is the master, it has a certain amount of noise.



## Chapter 47

### FlexIO IRDA Example

This example application demonstrates FlexIO timer to encode and decode IRDA pulse.

#### 47.1 Overview

This example uses FlexIO UART driver and FlexIO timers to send and receive IRDA signals. Data is first sent via FlexIO-simulated UART, then the simulated UART TX signal is routed into one FlexIO timer and encoded into IRDA pulse. On the receiving side, the IRDA pulse is first routed into one FlexIO timer, the timer decodes it into UART RX signal, then FlexIO UART driver receives the decoded signal.

#### 47.2 Supported Platforms

This Freescale Freedom development platform is supported by the KSDK FlexIO IRDA example.

- FRDM-KL43Z

#### 47.3 System Requirement

##### 47.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multilink universal
- Mini/micro USB cable
- USB A to micro AB cable
- Personal Computer

#### 47.4 Getting Started

##### 47.4.1 Hardware Settings

The FlexIO IRDA project does not call for any special hardware configurations in default loop-back mode. For non loop-back mode or using CMP0 trig mode, connect the FlexIO and CMP0 pins according to the following settings:

##### FRDM-KL43Z:

CMP0 Trig mode

- fsl\_flexio\_irda.h define IRDA\_RX\_CMP0\_TRIG to 1
- main.h define LOOPBACK\_TEST to 0



## Getting Started

FlexIO		Connects To	CMP0	
Pin Name	Board Location		Pin Name	Board Location
PTD7	J2-10	->	PTC6	J1-9

Non loop-back mode (this mode loops-back externally for an easy demo test)

- fsl\_flexio\_irda.h define IRDA\_RX\_CMP0\_TRIG to 0
- main.h define LOOPBACK\_TEST to 0

FlexIO		Connects To	FlexIO	
Pin Name	Board Location		Pin Name	Board Location
PTD6	J2-8	->	PTD7	J2-10

The user can check UART and IRDA waveform at the following pins.

Pin Name	Board Location	Function	Comments
PTD4	J2-6	FlexIO simulated UART TX	Optional OFF(define FLEXIO_UART_TX_PINEN to 0)
PTD5	J2-12	FlexIO simulated UART RX	No waveform in loop-back mode
PTD6	J2-8	IRDA pulse input for FlexIO timer to decode into UART	Non loop-back mode only
PTD7	J2-10	IRDA pulse output encoded by FlexIO timer	
PTE0	J2-18	CMP0 output	Can check CMP0 output in CMP0 trig mode

### 47.4.2 Prepare the Demo

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the demo.
5. Program ends with a while (1) loop to get the user input from the terminal window one character at

a time and send the input character via IRDA. The character is also echoed on the terminal window. For detailed instructions, see the appropriate board-specific document.

## 47.5 Run the demo

This example shows the following information on the terminal window:

```
Start FlexIO UART/IRDA demo
```

```
Non-blocking Send/Receive Demo
String data is : Hello World
Binary data is : 0x48656c6c6f20576f726c640
```

```
Blocking Send Demo
String data is : Hello
Binary data is : 0x48656c6c6f
```

```
Blocking Receive Demo
String data is : He
Binary data is : 0x4865
```

```
Last demo: Input one char at a time from the terminal.
It is transmitted via the FlexIO IRDA driver and echoed on the terminal.
abcdefghijklmn (This is the example echo user input for one character at a time).
```

### 47.5.1 Customization Options

- In `main.h`
  - The `IRDA_RX_CMP0_TRIG`(default to 0) definition determines whether to use the CMP0 as the FlexIO trig.
  - The `LOOPBACK_TEST`(default to 1) definition determines whether the loop back FlexIO signals internally.
  - The `FLEXIO_UART_RX_PINEN`(default to 1) definition determines whether the FlexIO-simulated UART RX signals present on PTD5.
  - The `FLEXIO_UART_TX_PINEN`(default to 1) definition determines whether the FlexIO-simulated UART TX signals present on PTD4.
- In `fsl_flexio_irda.h`
  - The `IRDA_RXPIN_REVERSE`(default to 0) definition determines whether the FlexIO IRDA decoding timer uses a reversed input or not.
  - The `IRDA_TXPIN_REVERSE`(default to 0) definition determines whether the FlexIO IRDA encoding timer reverses the output pulse or not.
  - Note: `IRDA_RXPIN_REVERSE` and `IRDA_TXPIN_REVERSE` must be the same for the demo test.

---

## Run the demo

## Chapter 48

### FlexIO-simulated SPI Example with other methods

#### 48.1 Overview

The FlexIO SPI example application demonstrates the FlexIO-simulated SPI driver working with different methods. The FlexIO SPI example shows the transmit/receive between the FlexIO-simulated SPI and SPI1 using these methods:

##### master

- Using interrupts
- Using the DMA

##### slave

- Using the interrupts
- Using the DMA

#### 48.2 Supported Platforms

These Tower System modules and Freescale Freedom platforms are supported by the FlexIO SPI example:

- FRDM-KL27Z
- TWR-KL43Z48M
- TWR-K80F150M

#### 48.3 System Requirement

##### 48.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Personal Computer

##### 48.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/flexio/spi/<mode>/<toolchain>
- Library dependencies: ksdk\_platform\_lib

## Getting Started

### 48.4 Getting Started

#### 48.4.1 Hardware settings

This example requires connecting FlexIO pins with the SPI1 pins. Connect FlexIO pins to the SPI1 pins. Note that the default uses the FlexIO pin0~pin3:

FlexIO Pins	Connects To	SPI1 Pins	
FlexIO Pin0	->	SPI1 MOSI/MISO	
FlexIO Pin1	->	SPI1 MISO/MOSI	
FlexIO Pin2	->	SPI1 SCK	
FlexIO Pin3	->	SPI1 CSn	

Make these connections between the FlexIO Pins and the SPI1 pins by using external wires:

#### master example

##### TWR-KL43Z48M

FlexIO Pins		Connects To	SPI1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD0/FLEXIO_PI-N0	Primary Elevator B46	->	SPI1 MOSI	Primary Elevator B10
PTD4/FLEXIO_PI-N1	Primary Elevator B48	->	SPI1 MISO	Primary Elevator B11
PTD2/FLEXIO_PI-N2	Primary Elevator B45	->	SPI1 SCK	Primary Elevator B39
PTD4/FLEXIO_PI-N3	Primary Elevator B44	->	SPI1 CSn	Primary Elevator B59

##### FRDM-KL27Z48M

FlexIO Pins		Connects To	SPI1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD0/FLEXIO_PI-N0	J1-1	->	SPI1 MOSI	J2-18
PTD1/FLEXIO_PI-N1	J1-3	->	SPI1 MISO	J2-20
PTD2/FLEXIO_PI-N2	J1-5	->	SPI1 SCK	J1-11

PTD3/FLEXIO_PI-N3	J1-7	->	SPI1 CSn	J1-9
-------------------	------	----	----------	------

**TWR-K80F150M**

FlexIO Pins		Connects To	DSPIO Pins	
Pin Name	Board Location		Pin Name	Board Location
PTB0/FLEXIO_PIN0	Primary Elevator A38	->	DSPIO SDI	Primary Elevator B44
PTB1/FLEXIO_PIN1	Primary Elevator A37	->	DSPIO SDO	Primary Elevator B45
PTB10/FLEXIO_PIN4	Primary Elevator B70	->	DSPIO SCK	Primary Elevator B48
PTB11/FLEXIO_PIN5	Primary Elevator B69	->	DSPIO PCS0	Primary Elevator B46

**slave example**
**TWR-KL43Z48M**

FlexIO Pins		Connects To	SPI1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD0/FLEXIO_PIN0	Primary Elevator B46	->	SPI1 MISO	Primary Elevator B11
PTD4/FLEXIO_PIN1	Primary Elevator B48	->	SPI1 MOSI	Primary Elevator B10
PTD2/FLEXIO_PIN2	Primary Elevator B45	->	SPI1 SCK	Primary Elevator B39
PTD4/FLEXIO_PIN3	Primary Elevator B44	->	SPI1 CSn	Primary Elevator B59

**FRDM-KL27Z48M**

FlexIO Pins		Connects To	SPI1 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD0/FLEXIO_PIN0	J1-1	->	SPI1 MOSI	J2-20
PTD1/FLEXIO_PIN1	J1-3	->	SPI1 MISO	J2-18

## Getting Started

PTD2/FLEXIO_PIN2	J1-5	->	SPI1 SCK	J1-11
PTD3/FLEXIO_PIN3	J1-7	->	SPI1 CSn	J1-9

## TWR-K80F150M

FlexIO Pins		Connects To	DSPI0 Pins	
Pin Name	Board Location		Pin Name	Board Location
PTB0/FLEXIO_PIN0	Primary Elevator A38	->	DSPI0 SDI	Primary Elevator B44
PTB1/FLEXIO_PIN1	Primary Elevator A37	->	DSPI0 SDO	Primary Elevator B45
PTB10/FLEXIO_PIN4	Primary Elevator B70	->	DSPI0 SCK	Primary Elevator B48
PTB11/FLEXIO_PIN5	Primary Elevator B69	->	DSPI0 PCS0	Primary Elevator B46

### 48.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. For TWR-KL43Z48M, insert the Tower System module into TWR-ELEV.
3. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
4. Download the program to the target board.
5. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 48.4.3 Run the example

#### master example

These instructions are displayed/shown on the terminal window:

```

+++++++ FLEXIO SPI Send/Receive Example Start ++++++
1. FlexIO-simulated SPI master starts transfer with the masterWriteBuff and masterReadBuff.
2. SPI1 acts as slave also transfer with the slaveWriteBuff and slaveReadBuff.

```

3. Compare the masterWriteBuff and the slaveReadBuff and the slaveWriteBuff and the masterReadBuff to see results.

```
=====
```

Press any key to start the transfer:

Type a character on the keyboard and the FlexIO-simulated SPI master starts the transfer with the SPI slave, compares the masterWriteBuff and slaveReadBuff, the slaveWriteBuff and the masterReadBuff to check whether the transfer is successful.

```
FlexIO simulated SPI master to SPI slave bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave transfer DMA bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave transfer DMA bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave transfer DMA bidirectional transfer succeed!!
FlexIO simulated SPI master to SPI slave bidirectional transfer succeed!!
...
```

### slave example

These instructions are displayed/shown on the terminal window:

```
+++++++ FLEXIO SPI Send/Receive Example Start ++++++
1. SPI1 acts as master starts transfer with masterWriteBuff and masterReadBuff.
2. FlexIO simulated SPI slave also transfer with slaveWriteBuff and slaveReadBuff.
3. Compare masterWriteBuff and slaveReadBuff, slaveWriteBuff and masterReadBuff to see result.
=====
```

Press any key to start transfer:

Type a character on the keyboard and the SPI1 master starts the transfer with the FlexIO- simulated SPI slave, compares the masterWriteBuff and the slaveReadBuff, the slaveWriteBuff and the masterReadBuff to check whether the transfer is successful.

```
SPI master to FlexIO simulated SPI slave bidirectional transfer succeeded!!
SPI master to FlexIO simulated SPI slave DMA bidirectional transfer succeeded!!
SPI master to FlexIO simulated SPI slave bidirectional transfer succeeded!!
SPI master to FlexIO simulated SPI slave DMA bidirectional transfer succeeded!!
SPI master to FlexIO simulated SPI slave bidirectional transfer succeeded!!
SPI master to FlexIO simulated SPI slave DMA bidirectional transfer succeeded!!
...
```





## Chapter 49

# FlexIO-simulated UART Example with other methods

### 49.1 Overview

The FlexIO UART example application demonstrates the FlexIO-simulated UART driver working with different methods. The FlexIO UART example shows the transmit/receive between the FlexIO-simulated UART and the LPUART using interrupts and DMA:

- flexio\_uart\_example using interrupts
- flexio\_uart\_dma\_example using DMA

### 49.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the FlexIO UART example.

- FRDM-KL27Z
- FRDM-KL43Z
- TWR-KL43Z48M
- TWR-K80F150M

### 49.3 System Requirement

#### 49.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Personal Computer

#### 49.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/flexio/uart/<use_case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## Getting Started

### 49.4 Getting Started

#### 49.4.1 Hardware settings

This example requires connecting the FLEXIO pins with the LPUART pins. Connect the FlexIO pins to the LPUART pins. Note that the default uses the FlexIO pin5 and pin4:

FlexIO Pins		Connects To	LPUART Pins	
FlexIO Pin5		->	LPUART Rx	
FlexIO Pin4		->	LPUART Tx	

Make these connections between the FlexIO pins and LPUART pins by using external wires:

#### FRDM-KL43Z

FlexIO Pins		Connects To	LPUART Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PIN5	J2-12	->	LPUART1 Rx	J2-20
PTD4/FLEXIO_PIN4	J2-6	->	LPUART1 Tx	J2-18

#### FRDM-KL27Z

FlexIO Pins		Connects To	LPUART Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PIN5	J1-11	->	LPUART1 Rx	J3-3
PTD4/FLEXIO_PIN4	J1-9	->	LPUART1 Tx	J3-1

#### TWR-K80F150M

Because LPUART1 is used as debug console so LPUART0 is used in the example

FlexIO Pins		Connects To	LPUART Pins	
Pin Name	Board Location		Pin Name	Board Location
PTB11/FLEXIO_PIN5	B69	->	LPUART0 Rx	A41
PTB10/FLEXIO_PIN4	B70	->	LPUART0 Tx	A42

## TWR-KL43Z48

FlexIO Pins		Connects To	LPUART Pins	
Pin Name	Board Location		Pin Name	Board Location
PTD5/FLEXIO_PI-N5	Primary Elevator B39	->	LPUART1 Rx	TWR-KL43Z48M J15-14
PTD0/FLEXIO_PI-N4	Primary Elevator B59	->	LPUART1 Tx	Primary Elevator B47

### 49.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Insert the Tower System module into the TWR-ELEV.
3. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
4. Download the program to the target board.
5. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 49.4.3 Run the example

#### 49.4.3.1 FLEXIO\_UART interrupt way

These instructions are displayed/shown on the terminal window:

```

+++++++ FLEXIO UART Send/Receive Example Start ++++++
1. FlexIO simulated UART send a buffer
2. LPUART1 receives data from FlexIO simulated UART.
3. Compare rxBuff and txBuff to see result.
4. LPUART1 send a buffer
5. FlexIO simulated UART receives data from LPUART1.
6. Compare rxBuff and txBuff to see result.
=====
Press any key to start transfer:

```

Type a character from the keyboard and the FlexIO simulated UART sends a buffer to the LPUART1, compares the receive buffer in the LPUART1 side with the txBuff and checks whether the result is successful. Then, the LPUART1 sends a buffer to the FlexIO simulated UART, compares the received buffer in the FlexIO-simulated UART side with the txBuff and checks whether the result is successful.

## Getting Started

```
FlexIO simulated UART receive from FlexIO LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
...
```

For other boards:

```
Transfer from FlexIO simulated UART to LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
Transfer from FlexIO simulated UART to LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
Transfer from FlexIO simulated UART to LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
Transfer from FlexIO simulated UART to LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
Transfer from FlexIO simulated UART to LPUART1 successfully
FlexIO simulated UART receive from FlexIO LPUART1 successfully
...
```

### 49.4.3.2 FLEXIO\_UART interrupt way

These instructions are displayed/shown on the terminal window:

```
+++++++ FLEXIO UART Send/Receive DMA Example Start ++++++
```

1. FlexIO simulated UART send a buffer using DMA
2. LPUART1 receives data from FlexIO simulated UART.
3. Compare rxBuff and txBuff to see result.
4. LPUART1 send a buffer
5. FlexIO simulated UART receives data from LPUART1 using DMA.
6. Compare rxBuff and txBuff to see result.

```
=====
Press any key to start transfer:
```

Type a character from the keyboard and the FlexIO-simulated UART sends a buffer to the LPUART1, compares the received buffer in the LPUART1 side with the txBuff, checks whether the result is successful. Then, the LPUART1 sends a buffer to the FlexIO-simulated UART, compares the received buffer in the FlexIO-simulated UART side with the txBuff and checks whether the result is successful.

```
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
...
```

For other boards:

```
Transfer from FlexIO simulated UART to LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
Transfer from FlexIO simulated UART to LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
Transfer from FlexIO simulated UART to LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
Transfer from FlexIO simulated UART to LPUART using DMA successfully
FlexIO simulated UART receive from FlexIO LPUART using DMA successfully
...
```

## Chapter 50 FTM Example

### 50.1 Overview

The FTM Example project is a demonstration program that uses the KSDK software to generate a square pulse PWM to control the LED brightness.

- FTM generates a PWM with the increasing and decreasing duty cycle.
- LED brightness is increasing and then dimming. This is a continuous process.

### 50.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the FTM example.

- FRDM-K22F
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

<note>The TWR-K65F180M Tower System module does not have a suitable LED. The PWM signal is connected to the elevator board connector B25.</note>

### 50.3 System Requirement

#### 50.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device

## Getting Started

- Personal Computer

### 50.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/ftm/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 50.4 Getting Started

### 50.4.1 Hardware settings

The FTM Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 50.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 50.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Welcome to FTM example  
See the change of LED brightness
```

After that, the LED brightness is increasing and then dimming. This is a continuous process.

## Chapter 51 GPIO Example

### 51.1 Overview

The GPIO Example project is a demonstration program that uses the KSDK software to manipulate the general-purpose outputs. The example is supported by the set, clear, and toggle write-only registers for each port output data register. The example uses the software button to control/toggle the LED.

### 51.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the GPIO example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL03Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z\_KW40Z



## Getting Started

### 51.3 System Requirement

#### 51.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 51.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/gpio/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 51.4 Getting Started

#### 51.4.1 Hardware settings

The GPIO Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 51.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 51.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
GPIO PD Driver example
```

Press SW to turn on/off a LED1

Press the SW (\*) button on the board and observe the LED toggle, which is controlled by GPIO.



## Chapter 52

### I2C Example with other methods

#### 52.1 Overview

The I2C Example project is a demonstration program that uses the KSDK software. This example provides 4 examples: I2C blocking, non blocking, callback and polling.

- I2C master sends and receives the array to/from the I2C slave and compares whether the two buffers are the same
- I2C slave sends the buffer received from the master then echoes back to the master
- First run the master and then run the slave

#### 52.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the I2C example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32

## Getting Started

- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

## 52.3 System Requirement

### 52.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 52.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/i2c/<use_case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 52.4 Getting Started

### 52.4.1 Hardware settings

This example requires two separate boards. Connect an instance of the I2Cx master to the I2Cx slave. The process is the same as the I2C common instance in the demo project. In case of TWR-KV11Z75M, also connect pin 2 and 3 on J4 and J11.

Master Board	Connects To	Slave Board
SDA	->	SDA
SCL	->	SCL
GND	->	GND

Make these connections between the two boards by using external wires:

#### FRDM-K22F :

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTB2/I2C0_SCL	J24 Pin 12	->	PTB2/I2C0_SCL	J24 Pin 12

PTB3/I2C0_SDA	J24 Pin 10	->	PTB3/I2C0_SDA	J24 Pin 10
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-K64F:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	J2 Pin 20	->	PTE24/I2C0_SCL	J2 Pin 20
PTE25/I2C0_SDA	J2 Pin 18	->	PTE25/I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-KL02Z & FRDM-KL03Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE3/I2C0_SCL	J7 Pin 10	->	PTE3/I2C0_SCL	J7 Pin 10
PTE4/I2C0_SDA	J7 Pin 9	->	PTE4/I2C0_SDA	J7 Pin 9
GND	J7 Pin 7	->	GND	J7 Pin 7

**FRDM-KL25Z:**

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
		->		
		->		
		->		

**FRDM-KL26Z:**

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location

## Getting Started

Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL	J2 Pin 20	->	PTE24/I2C0_SCL	J2 Pin 20
PTE25/I2C0_SDA	J2 Pin 18	->	PTE25/I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

## FRDM-KL27Z

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTD7/I2C1_SCL (*)	J2 Pin 20	->	PTD7/I2C1_SCL (*)	J2 Pin 20
PTD6/I2C1_SDA (*)	J2 Pin 18	->	PTD6/I2C1_SDA (*)	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

## FRDM-KL43Z & FRDM-KL43ZKL33 & FRDM-KL46Z:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTD7/I2C1_SCL (*)	J2 Pin 20	->	PTD7/I2C1_SCL (*)	J2 Pin 20
PTD6/I2C1_SDA (*)	J2 Pin 18	->	PTD6/I2C1_SDA (*)	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

## FRDM-KW24:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 20	->	I2C0_SCL	J2 Pin 20
I2C0_SDA	J2 Pin 18	->	I2C0_SDA	J2 Pin 18
GND	J2 Pin 14	->	GND	J2 Pin 14

**FRDM-KW40Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	J25 Pin 10	->	I2C1_SCL	J25 Pin 10
I2C1_SDA	J25 Pin 12	->	I2C1_SDA	J25 Pin 12
GND	J24 Pin 14	->	GND	J24 Pin 14

**MRB-KW01:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTC1/I2C1_SCL	J15 Pin 13	->	PTC1/I2C1_SCL	J15 Pin 13
PTC2/I2C1_SDA	J15 Pin 11	->	PTC2/I2C1_SDA	J15 Pin 11
GND	J14 Pin 18	->	GND	J14 Pin 18

**TWR-K21D50M & TWR-K22F120M & TWR\_K24F120M & TWR-KV31F120M & TWR-KL43Z48M & TWR-KV31F120M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE24/I2C0_SCL (*)	Primary Elevator A7	->	PTE24/I2C0_SCL (*)	Primary Elevator A7
PTE25/I2C0_SDA (*)	Primary Elevator A8	->	PTE25/I2C0_SDA (*)	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

**TWR-KM34Z75M**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTD7/I2C0_SCL	J10 Pin 1	->	PTD7/I2C0_SCL	J10 Pin 1
PTE0/I2C0_SDA	J11 Pin 1	->	PTE0/I2C0_SDA	J11 Pin 1
GND	J25 Pin 26	->	GND	J25 Pin 26



## Getting Started

### TWR-KV10Z32:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K60D100M & TWR-K64F120M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE10/I2C1_SCL	Primary Elevator A75	->	PTE10/I2C1_SCL	Primary Elevator A75
PTE11/I2C1_SDA	Primary Elevator B71	->	PTE11/I2C1_SDA	Primary Elevator B71
GND	Primary Elevator A6	->	GND	Primary Elevator A6

### TWR-K65F180M & TWR-K80F150M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTE19/I2C0_SCL	Primary Elevator - Pin A7	->	PTE19/I2C0_SCL	Primary Elevator - Pin A7
PTE18/I2C0_SDA	Primary Elevator - Pin A8	->	PTE18/I2C0_SDA	Primary Elevator - Pin A8
GND	Primary Elevator A65	->	GND	Primary Elevator A65

### TWR-KL25Z48M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C1_SCL	Primary Elevator B22	->	I2C1_SCL	Primary Elevator B22
I2C1_SDA	Primary Elevator B10	->	I2C1_SDA	Primary Elevator B10
GND	Primary Elevator B2	->	GND	Primary Elevator B2

**TWR-K21F120M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTC10/I2C1_SCL	Primary Elevator B50	->	PTC10/I2C1_SCL	Primary Elevator B50
PTC11/I2C1_SDA	Primary Elevator B51	->	PTC11/I2C1_SDA	Primary Elevator B51
GND	Primary Elevator A65	->	GND	Primary Elevator A65

**TWR-KW24D512:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A81	->	GND	Primary Elevator A81

**FRDM-KV31F:**

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board	Connects To	Slave Board
--------------	-------------	-------------

## Getting Started

Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J1-16	->	I2C0_SCL	J1-16
I2C0_SDA	J2-13	->	I2C0_SDA	J2-13
GND	J2-14	->	GND	J2-14

### FRDM-KV10Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	J2 Pin 13	->	I2C0_SCL	J2 Pin 13
I2C0_SDA	J1 Pin 15	->	I2C0_SDA	J1 Pin 15
GND	J2 Pin 14	->	GND	J2 Pin 14

### TWR-KV11Z75M:

The board doesn't support external pull-up resistors for I2C pins. So the internal pull-up resistors is enable for I2C pins. However, the resistor is quite huge (~20KOhm - 50KOhm). The I2C may run FAIL in high baurate. In this case, user need to use external pull-up resistors.

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
I2C0_SCL	Primary Elevator A7	->	I2C0_SCL	Primary Elevator A7
I2C0_SDA	Primary Elevator A8	->	I2C0_SDA	Primary Elevator A8
GND	Primary Elevator A6	->	GND	Primary Elevator A6

## 52.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the

example.

### 52.4.3 Run the example

#### 52.4.3.1 I2C blocking

These instructions are displayed/shown on the terminal window:

On Master board:

```
===== I2C MASTER BLOCKING =====
1. Master sends a frame includes CMD(size of data) and data
2. Master receives data from slave.
3. Compare rxBuff and txBuff to see result.
=====
Press any key to start transfer:
```

Type a character on the keyboard and the master board sends to the slave board and receives back from the slave board.

On Master board:

```
Master sends 1 bytes:
 01
Master Sends/ Receives 1 bytes successfully
Master sends 2 bytes:
 01 02
Master Sends/ Receives 2 bytes successfully
Master sends 3 bytes:
 01 02 03
Master Sends/ Receives 3 bytes successfully
Master sends 4 bytes:
 01 02 03 04
Master Sends/ Receives 4 bytes successfully
...
```

On Slave board:

```
===== I2C SLAVE BLOCKING =====
Slave is running ...
Slave received:
 01
Slave received:
 01 02
Slave received:
 01 02 03
Slave received:
 01 02 03 04
Slave received:
 01 02 03 04 05
...
```

#### 52.4.3.2 I2C non-blocking

These instructions are displayed/shown on the terminal window same as above.

## Getting Started

### 52.4.3.3 I2C callback

These instructions are displayed/shown on the terminal window same as above.

### 52.4.3.4 I2C polling

These instructions are displayed/shown on the terminal window same as above.

## Chapter 53 iRTC Example

### 53.1 Overview

The iRTC Example project is a demonstration program that uses the KSDK software to demonstrate the iRTC timer functionality. After a pre-defined time elapse, the iRTC ISR is called to alert users.

### 53.2 Supported Platforms

This Tower System module is supported by the iRTC example.

- TWR-KM34Z75M

### 53.3 System Requirement

#### 53.3.1 Hardware requirements

- J-Link ARM
- USB A to USB Mini B cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 53.4 Getting Started

#### 53.4.1 Hardware settings

The iRTC Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 53.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.

## Getting Started

4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 53.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
RTC Example START:  
  
Alarm Time is 2015/1/21 18:55:33  
  
Current Time is 2015/1/21 18:55:31  
Current Time is 2015/1/21 18:55:32  
Ring, ring, ring  
Current Time is 2015/1/21 18:55:33  
  
RTC Example END.
```

Afterwards, the program enters an infinite loop.

## Chapter 54

# Low Power Serial Communication Interface (LPSCI) Example with Other Methods

### 54.1 Overview

This LPSCI example application demonstrates the SDK Peripheral drivers working with different methods. The LPSCI example shows transmit/receive LPSCI driver with other efficiency methods:

- Using blocking method
- Using non-blocking method
- Using Dma blocking method
- Using Dma non-blocking method
- Using polling method

The board transfers and receives characters through the LPSCI interface. Type characters on the keyboard and the board receives and echoes them on the terminal screen. Look for instructions output to the terminal.

### 54.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the LPSCI example.

- FRDM-KL02Z (\*) (DMA not supported)
- FRDM-KL25Z (\*) (DMA not supported)
- FRDM-KL26Z
- FRDM-KL46Z
- MRB-KW01
- TWR-KL25Z48M (\*) (DMA not supported)

### 54.3 System Requirement

#### 54.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer



## Getting Started

### 54.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/lpisci/<use_case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 54.4 Getting Started

### 54.4.1 Hardware settings

The LPSCI Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 54.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 54.4.3 Run the example

#### 54.4.3.1 LPSCI blocking

These instructions are displayed/shown on the terminal window:

```
+++++ LPSCI Send/Receive Blocking Example +++++
Type characters on the keyboard and the board receives and echoes them to the terminal screen.
```

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

#### 54.4.3.2 LPSCI non-blocking

These instructions are displayed/shown on the terminal window:

```
+++++++ LPSCI Send/Receive Non Blocking Example ++++++
```

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

### 54.4.3.3 LPSCI DMA blocking

These instructions are displayed/shown on the terminal window:

```
+++++++ LPSCI-DMA Blocking Example ++++++
```

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

### 54.4.3.4 LPSCI DMA non-blocking

These instructions are displayed/shown on the terminal window:

```
+++++++ LPSCI-DMA Non Blocking Example ++++++
```

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

### 54.4.3.5 LPSCI polling

These instructions are displayed/shown on the terminal window:

```
+++++++ LPSCI Polling Example ++++++
```

Type characters on the keyboard and the board receives and echoes them to the terminal screen.

Type characters on the keyboard and the board receives and echoes them to the terminal screen.



## Chapter 55

### LPTMR Example

#### 55.1 Overview

The LPTMR (Low Power Timer) project is a demonstration program to show how to use the LPTMR driver. It triggers an LPTMR interrupt once every second and prints out the number of interrupts that have occurred since the program started running.

#### 55.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the LPTMR example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z\_KW40Z

## Getting Started

### 55.3 System Requirement

#### 55.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 55.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/lptmr/<toolchain>.
- Library dependencies: kSDK\_platform\_lib

### 55.4 Getting Started

#### 55.4.1 Hardware settings

The LPTMR Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 55.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 55.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Low Power Timer Example
```

```
LPTMR interrupt No.1  
LPTMR interrupt No.2  
LPTMR interrupt No.3
```

An LPTMR interrupt is triggered once every second. The LED blinks and prints out the number of interrupts that have occurred since the program started running.



## Chapter 56

# Low Power Universal Asynchronous Receiver/Transmitter (LPUART) Example with other methods

### 56.1 Overview

This LPUART example application demonstrates the SDK Peripheral drivers working with different methods. The LPUART example shows transmit/receive LPUART driver with these efficiency methods:

- Using blocking method
- Using non-blocking method
- Using DMA blocking method
- Using DMA non-blocking method
- Using polling method

Transfer data between the board and the PC. The board transfers and receives characters through the LPUART interface. Type characters on the keyboard and the board receives and echoes them to the terminal screen. Look for instructions output to the terminal.

### 56.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the LPUART example.

- FRDM-KL03Z (\*) (EDMA not support)
- FRDM-KL27Z
- FRDM-KL43Z (\*) (EDMA not support)
- FRDM-KW40Z
- TWR-K80F150M
- TWR-KM34Z75M
- USB-KW40Z

### 56.3 System Requirement

#### 56.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for a specific device
- Personal Computer

For TWR-KM34Z75M



## Getting Started

- J-Link ARM
- USB A to USB Mini B cable
- Hardware (Tower System/base board, ...) for a specific device
- Personal Computer
- USB-UART(TTL) conversion board

### 56.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/lpuart/<use\_case>/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 56.4 Getting Started

### 56.4.1 Hardware settings

The LPUART Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

For - TWR-KM34Z75M

### 56.4.2 Hardware settings

This example requires an extra USB-TTL(3.3V) transform board connected to the PC USB port.

TWR-KM34Z75M	Connects To	USB-TTL board
TxD	->	RxD
RxD	->	TxD
GND	->	GND

Make these connections between the two boards by using external wires:

#### TWR-KM34Z75M

TWR-KM34Z75M		Connects To	USB-TTL board	
Pin Name	Board Location		Pin Name	Board Location
PTJ5/LPUART0_-TX	J14 Pin 1	->	RxD	RxD
PTJ6/LPUART0_-RX	J16 Pin 1	->	TxD	TxD

GND	J25 Pin 26	->	GND	GND
-----	------------	----	-----	-----

### 56.4.3 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 56.4.4 Run the example

For - TWR-KM34Z75M

1. Connect RxD,TxD,GND between Tower board and USB-TTL board.
2. Connect the USB-TTL board to PC host.
3. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
4. Download the program to the target board.
5. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 56.4.5 Run the example

#### 56.4.5.1 FLEXIO\_UART interrupt way

These instructions are displayed/shown on the terminal window:

```

+++++++ LPUART Send/Receive Blocking Example ++++++
Type characters on the keyboard and the board receives and echoes them on the terminal screen.

```

Type characters on the keyboard and the board receives and echoes them on the terminal screen.

## Getting Started

### 56.4.5.2 LPUART non-blocking

These instructions are displayed/shown on the terminal window:

```

+++++ LPUART Send/Receive Non Blocking Example +++++
Type characters on the keyboard and the board receives and echoes them on the terminal screen.
    
```

Type characters on the keyboard and the board receives and echoes them on the terminal screen.

### 56.4.5.3 LPUART DMA blocking

These instructions are displayed/shown on the terminal window:

```

+++++ LPUART-DMA Send/Receive Blocking Example +++++
Type characters on the keyboard and the board receives and echoes them on the terminal screen.
    
```

Type characters on the keyboard and the board receives and echoes them on the terminal screen.

### 56.4.5.4 LPUART DMA non-blocking

These instructions are displayed/shown on the terminal window:

```

+++++ LPUART-DMA Send/Receive Non Blocking Example +++++
Type characters on the keyboard and the board receives and echoes them on the terminal screen.
    
```

Type characters on the keyboard and the board receives and echoes them on the terminal screen.

### 56.4.5.5 LPUART polling

These instructions are displayed/shown on the terminal window:

```

+++++ LPUART Send/Receive Polling Example +++++
Type characters on the keyboard and the board receives and echoes them on the terminal screen.
    
```

Type characters on the keyboard and the board receives and echoes them on the terminal screen.

## Chapter 57

### LTC AES Example

#### 57.1 Overview

This project is a demonstration program that uses the KSDK software for encryption/decryption sample data using AES-CBC, AES-CCM, and XCBC-MAC algorithm.

#### 57.2 Supported Platforms

These Freescale Freedom development platforms are supported by the LTC\_AES example.

- FRDM-KW40Z
- USB-KW40Z

#### 57.3 System Requirement

##### 57.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

##### 57.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/ltc/ltc\_aes/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 57.4 Getting Started

##### 57.4.1 Hardware settings

The LTC\_AES Example project does not call for any special hardware configurations. The recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

##### 57.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.

## Getting Started

2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 57.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```

..... LTC (AES) DRIVER EXAMPLE .....

Measuring timer is driven 60 MHz. (tick = 16 picoSeconds)
Testing input string:
    Once upon a midnight dreary,
        while I pondered weak and weary,
    Over many a quaint and curious volume of forgotten lore,
    While I nodded,
        nearly napping,
        suddenly there came a tapping,
    As of some one gently rapping,
        rapping at my chamber doorIts some visitor,
        I muttered,
        tapping at my chamber doorOnly this,
        and nothing more.

----- AES-CBC method -----
AES CBC Encryption of 320 bytes.
AES CBC encryption finished in 5359 ticks / 89 µs

AES CBC Decryption of 320 bytes.
AES CBC decryption finished in 5151 ticks / 85 µs
Decrypted string :
    Once upon a midnight dreary,
        while I pondered weak and weary,
    Over many a quaint and curious volume of forgotten lore,
    While I nodded,
        nearly napping,
        suddenly there came a tapping,
    As of some one gently rapping,
        rapping at my chamber doorIts some visitor,
        I muttered,
        tapping at my chamber doorOnly this,
        and nothing more.

----- AES-CCM method -----
AES CCM Encryption of 320 bytes.
    using iv length : 12 bytes
    using aad length : 20 bytes
    using key length : 16 bytes
    using tag length : 8 bytes
AES CCM encryption finished in 6504 ticks / 108 µs

AES CCM decryption of 320 bytes.
AES CCM decryption finished in 6473 ticks / 107 µs

```

```
Decrypted string:  
  Once upon a midnight dreary,  
    while I pondered weak and weary,  
  Over many a quaint and curious volume of forgotten lore,  
  While I nodded,  
    nearly napping,  
  suddenly there came a tapping,  
  As of some one gently rapping,  
  rapping at my chamber doorIts some visitor,  
  I muttered,  
  tapping at my chamber doorOnly this,  
  and nothing more.
```

```
----- AES-XCBC-MAC -----  
AES XCBC-MAC Computing hash of 320 bytes  
Computed hash:  
ac aa c6 e9 c7 46 81 65 38 7b f 15 d9 3f 80 8a  
  
..... THE END OF THE LTC (AES) DRIVER EXAMPLE .....
```



## Chapter 58

### MMAU Example

#### 58.1 Overview

The Memory Mapped Arithmetic Unit (MMAU) provides acceleration to a set of mathematical operations, including signed/unsigned multiplication and accumulation, division and square root. This example uses the MMAU module for sine(x) computing. The sine(x) function is implemented using a 13th order polynomial approximation derived using a [Taylor Series]..

#### 58.2 Supported Platforms

This Tower System module is supported by the MMAU example.

- TWR-KM34Z75M

#### 58.3 System Requirement

##### 58.3.1 Hardware requirements

- J-Link ARM
- USB A to USB Mini B cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 58.4 Getting Started

##### 58.4.1 Hardware settings

The MMAU Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

##### 58.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control



## Getting Started

3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 58.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
MMAU example : start
Sin(pi) = 0 in frac32 format
Sin(0.8*pi) = 1262259216 in frac32 format
Sin(0.6*pi) = 2042378312 in frac32 format
Sin(0.4*pi) = 2042378312 in frac32 format
Sin(0.2*pi) = 1262259216 in frac32 format
Sin(0) = 0 in frac32 format
Sin(-0.2*pi) = -1262259224 in frac32 format
Sin(-0.4*pi) = -2042378320 in frac32 format
Sin(-0.6*pi) = -2042378320 in frac32 format
Sin(-0.8*pi) = -1262259224 in frac32 format
Sin(-pi) = 0 in frac32 format
MMAU example : end
```

Afterwards, the program enters an infinite loop.

## Chapter 59 MPU Example

### 59.1 Overview

MPU Example defines protected/unprotected memory region from the core. A memory region is configured as the non-writable region. If any operation writes to this region, this example provides a prevention alert by outputting a message on terminal. Then, this region becomes accessible and writing to it is successful.

### 59.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the MPU example.

- FRDM-K64F
- TWR-K21F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M

### 59.3 System Requirement

#### 59.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 59.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/mpu/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## Getting Started

### 59.4 Getting Started

#### 59.4.1 Hardware settings

The MPU Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 59.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 59.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
MPU example begin.  
  
Set regionArray to un-writeable.  
Write 0 to regionArray at No.0  
regionArray[0] = 0  
Core access violation and generate busfault!  
Core is granted write access permission!  
regionArray[0] = 0  
Protected regionArray successfully !  
Press any key to continue
```

## Chapter 60 PDB Example

### 60.1 Overview

The PDB Example project is a demonstration program that uses the KSDK software and PDB to generate a constant periodic of time (trigger pulse and interrupt). Each time the PDB expires, an interrupt occurs and counter is increased and prints to the terminal.

### 60.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the PDB example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

### 60.3 System Requirement

#### 60.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

## Getting Started

### 60.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/pdb/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 60.4 Getting Started

### 60.4.1 Hardware settings

The PDB Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 60.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 60.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
PDB example
PDB ISR No.1 occurred !
PDB ISR No.2 occurred !
PDB ISR No.3 occurred !
PDB ISR No.4 occurred !
PDB ISR No.5 occurred !
PDB ISR No.6 occurred !
PDB ISR No.7 occurred !
PDB ISR No.8 occurred !
PDB ISR No.9 occurred !
PDB ISR No.10 occurred !
PDB example finished
Press any key to run example again
```

## Chapter 61 PIT Example

### 61.1 Overview

The PIT Example project is a demonstration program that uses the KSDK software and PIT to cause the LED to blink with different frequencies on multiple channels. Measure the time of the generated pulse with the oscilloscope on the LED1 and the LED2. The LED2 toggles two times faster than the LED1.

### 61.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the PIT example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KV31F
- FRDM-KW24
- FRDM-KW40Z
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KM34Z75M
- TWR-KV31F120M
- TWR-KW24D512
- USB-KW40Z

## Getting Started

### 61.3 System Requirement

#### 61.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 61.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/pit/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 61.4 Getting Started

#### 61.4.1 Hardware settings

The PIT Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 61.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 61.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Starting channel No.0 ...
```

```
Starting channel No.1 ...  
Channel No.0 interrupt is occurred !  
Channel No.0 interrupt is occurred !  
Channel No.1 interrupt is occurred !  
Channel No.0 interrupt is occurred !  
Channel No.0 interrupt is occurred !  
Channel No.1 interrupt is occurred !
```





## Chapter 62

### QSPI Example with other methods

#### 62.1 Overview

The QSPI example project is a demonstration program that uses the KSDK software. This example erase and program external serial flash through QSPI. This example involves three methods:

- QSPI using polling way to program the external serial flash
- QSPI using interrupt way to program the external serial flash
- QSPI using DMA method to program the external serial flash

#### 62.2 Supported Platforms

This Tower System modules are supported by the QSPI example:

- TWR-K80F150M

#### 62.3 System Requirement

##### 62.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for a specific device
- Personal Computer

##### 62.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/qspi/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 62.4 Getting Started

##### 62.4.1 Hardware settings

This example requires external serial flash powered:

##### TWR-K80F150M

Jumper J30 pin4 and pin6 should be connected.

## Getting Started

### 62.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 62.4.3 Run the example

These instruction are displayed/shown on the terminal window:

```
QSPI example started!  
Erase finished!  
Program data finished!  
  
Program through QSPI polling succeeded !  
Erase finished!  
Program data finished!  
  
Program through QSPI Interrupt succeeded !  
Erase finished!  
Program data finished!  
  
Program through QSPI DMA succeed !  
  
Press any key to continue again!
```

## Chapter 63 QuadTmr Example

### 63.1 Overview

The QuadTmr Example project is a demonstration program that uses the KSDK software to demonstrate the QuadTmr timer functionality. While the program is running, the user captures waveforms in the scope.

### 63.2 Supported Platforms

This Tower System module is supported by the QuadTmr example.

- TWR-KM34Z75M

### 63.3 System Requirement

#### 63.3.1 Hardware requirements

- J-Link ARM
- USB A to USB Mini B cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer
- Oscilloscope

### 63.4 Getting Started

#### 63.4.1 Hardware settings

This example requires one board and one oscilloscope. Connect the oscilloscope to the QuadTmr output pin:

Board	Connects To	oscilloscope	
QTMR0_TMR1	->	Positive end	
Ground Test Point	->	Ground end	

Make these connections between the board and oscilloscope by using oscilloscope probes:

#### TWR-KM34Z75M

Board		Connects To	oscilloscope	
Pin Name	Board Location		oscilloscope	connection ends

## Getting Started

PTG0/QTMR0_T-MR1	J25 Pin 20	->	oscilloscope	Positive end
------------------	------------	----	--------------	--------------

### 63.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 63.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
*****QUADTIMER EXAMPLE START*****
*****Delay 3 s for PWM*****

*****Make sure to connect a scope.*****

****A 50% duty cycle PWM wave is observed in the scope.****

*****QUADTIMER EXAMPLE END.*****
```

After that, the program enters an infinite loop.

## Chapter 64

### RNGA Example

#### 64.1 Overview

The RNGA is a digital integrated circuit capable of generating the 32-bit random numbers. The RNGA Example project is a demonstration program that uses the KSDK software to generate random numbers and prints them to the terminal.

#### 64.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the RNGA example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV31F
- FRDM-KW24
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-KM34Z75M
- TWR-KV31F120M
- TWR-KW24D512

#### 64.3 System Requirement

##### 64.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

## Getting Started

### 64.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/rnga/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 64.4 Getting Started

### 64.4.1 Hardware settings

The RNGA Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 64.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 64.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
RNGA Peripheral Driver Example
Generate 10 random numbers
```

```
Generate 10 number:
Get random data No.0: 75128ccd.
Get random data No.1: f3bc5f99.
Get random data No.2: fe50a8bc.
Get random data No.3: 4737e46d.
Get random data No.4: 9f8bb4a8.
Get random data No.5: cadfd781.
Get random data No.6: a8263a08.
Get random data No.7: 3fed8d88.
Get random data No.8: c2826970.
Get random data No.9: 2715eb04.
Press any key to continue
```

## Chapter 65

### RTC Example

#### 65.1 Overview

The RTC Example project is a demonstration program that uses the KSDK software to get/set RTC time and alarm time. The RTC module is configured to use as an alarm clock.

- Set alarm date time; it should be later than the initial date time.
- Start RTC. When the RTC date time matches the alarm date time, an indicated LED should be turned on.

#### 65.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the RTC example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KW24
- FRDM-KW40Z
- MRB-KW01
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KL25Z48M
- TWR-KL43Z48M
- TWR-KW24D512
- USB-KW40Z



## Getting Started

### 65.3 System Requirement

#### 65.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 65.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/rtc/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 65.4 Getting Started

#### 65.4.1 Hardware settings

The RTC Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 65.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 65.4.3 Run the example

Note: On the FRDM-KL25Z, FRDM-KL26Z and FRDM-KL46Z, the RTC counter is fed without the 32 kHz (OSC32KCLK) clock. Therefore, the accuracy of RTC alarms is affected.

These instructions are displayed/shown on the terminal window:

```
RTC example: set up time to wake up an alarm
Current datetime: 2014-12-25 19:00:00
Input the number of second to wait for alarm
The second must be positive value
```

Type characters on the keyboard and the board receives and initializes a second value to start an alarm mode. Alarm occurs on the specified second. Note: On the FRDM-KL26Z and FRDM-KL46Z, the RTC counter is fed without the 32 kHz (OSC32KCLK) clock. Therefore, the accuracy of RTC alarms is affected. These instructions are displayed/shown on the terminal window:

```
Alarm occurs at: 2014-12-25 19:00:21
Alarm occurred !!!! Current datetime: 2014-12-25 19:00:22
Input the number of seconds to wait for the alarm
Seconds must have a positive value
```

After the specific RTC date time matches the alarm date time, an indicated LED should turn on.



## Chapter 66

### SDHC SDCard Example

#### 66.1 Overview

The SDHC SDCard Example application demonstrates the use of SD card driver. It displays the card information followed by a write-read compare test and the erase operation. Provide an example with different modes:

- Detect card inserted
- Read and write single block and multi-blocks to SDCard
- Erase blocks in SDCard

#### 66.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the SDHC SdCard example.

- TWR-K21F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M

#### 66.3 System Requirement

##### 66.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 66.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/sdhc\_sdcard/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## Getting Started

### 66.4 Getting Started

#### 66.4.1 Hardware settings

The SDHC SdCard Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 66.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

#### 66.4.3 Run the example

Insert an SD or a micro-SD card depending on the board connector. Ensure that the card doesn't contain any important content because the demo erases and overwrites some sectors.

These instructions are displayed/shown on the terminal window:

```
SD Card Demo Start!
This demo is going to access data on card
A card is detected
SDCard initialized

----- Card Information -----
Card Type: SDHC
Card Capacity: f GB
Host Clock Max Rate: 120 MHz
Clock Rate: 20 MHz
Manufacturer ID: 0x3
OEM ID: 0x5344
Product name: SD04G
Product serial number: 0x25BD9A0
Product revision: 8.0
Manufacturing data: Dec 2010
CSD Structure: 0x1
taac: f ns
nsac: 0 clks
tran speed: f kbps
ccc: class 0 2 4 5 7 8 10
max read block length: 512 Bytes
c_size: 7562
Erase unit size is one or multiple units of 512 bytes
```

```

The size of write protected group is 2 blocks
R2W_Factor: 2
max write block length: 9
The content is copied
Hard disk-like file system with partition table
SCR Structure: 0x0
SD Spec: 0x2
SD Spec 3.0
SDHC Card(Security Version 2.00)
Card supports 1-bit bus width
Card supports 4-bit bus width
Support set block count command

```

```

!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!! CAUTION !!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
THIS DEMO IS GOING TO ERASE AND WRITE RAW DATA TO THE CARD,
MAKE SURE YOU TAKE BACKUP OF ANY VALUEABLE DATA PRESENT IN THE CARD
BEFORE PROCEEDING.
!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!!
Do you want to proceed? (Enter 'y' IF yes) :

```

User need type 'Y' character from the keyboard. These instructions are displayed/shown on the terminal window:

```

Start write/read/compare demo...
Single block write/read/compare demo passed!
Multi-block write/read/compare demo passed!
Erase blocks demo passed!
SD Card Demo End!

```



## Chapter 67

### SDRAMC Example

#### 67.1 Overview

The synchronous DRAM controller module (SDRAM) provides a seamless integration of SDRAM. This example uses the SDRAMC peripheral to initialize the SDRAM.

#### 67.2 Supported Platforms

These Tower System modules are supported by the SDRAMC example.

- TWR-K65F180M
- TWR-K80F150M

#### 67.3 System Requirement

##### 67.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

##### 67.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/sdramc/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 67.4 Getting Started

##### 67.4.1 Hardware settings

The SDRAMC Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example. For TWR-K80F150M, the OpenSDA UART and the SDRAM have multiplex pins. Therefore, ensure that there is no shunt on J6.



## Getting Started

### 67.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 67.4.3 Run the example

These instructions are displayed/shown on the terminal window for K80 after the J6 and J8 reset after the sdr write/read check:

```
SDRAM Write Data and Read Data Succeed.  
SDRAM Spend xx milliseconds with Cache Write back.  
SDRAM Spend xx milliseconds with Cache Write through.  
SDRAM Spend xx milliseconds with non-cacheable.  
SDRAM Example End.
```

These instructions are displayed/shown on the terminal window for others:

```
SDRAM Example Start!  
SDRAM Memory Write Start, Start Address 0x70000000, Data Length 4096 !  
SDRAM Write finished!  
SDRAM Read Start, Start Address 0x70000000, Data Length 4096 !  
SDRAM Read finished!  
SDRAM Write Data and Read Data Compare Start!  
SDRAM Write Data and Read Data Succeeded.  
SDRAM Example End.
```

## Chapter 68

### SLCD Example

#### 68.1 Overview

SLCD Example defines how to use slcd to display content.

#### 68.2 Supported Platforms

These Freescale Freedom development platforms are supported by the SLCD example.

- FRDM-KL43Z
- FRDM-KL46Z
- TWR-KM34Z75M

#### 68.3 System Requirement

##### 68.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 68.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/slcd/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 68.4 Getting Started

##### 68.4.1 Hardware settings

The MPU Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

##### 68.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.

## Getting Started

2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 68.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
SLCD enters interrupt
```

For TWR-KM34Z75M This example turns on all SLCD segments and blinks several times (No instructions on the terminal window).

## Chapter 69 Smart Card Example

### 69.1 Overview

This example demonstrates the SDK Peripheral drivers working with different methods.

- Using blocking method
- Using non-blocking method

Transfer data between the board and the smart card Zeitcontrol ZC7.5 RevD. The example transfers using both T0 and T1 modes.

### 69.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the smart card example.

- TWR-K21F120M (using TWR-POSCARD, combination of smartcard\_uart and smartcard\_ncn8025 drivers)
- TWR-K80F150M (using on-board micro-SIM socket, combination of smartcard\_emvsim and smartcard\_direct drivers)

### 69.3 System Requirement

#### 69.3.1 Hardware requirements

- J-Link ARM
- PE Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer
- TWR-POSCARD Tower System module (in case of micro SIM interface absence on microprocessor Tower System module)
- smart card Zeitcontrol ZC7.5 RevD

#### 69.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/smartcard/<use\_case>/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## Getting Started

### 69.4 Getting Started

#### 69.4.1 Hardware settings

The smart card example project requires a special hardware configuration when using the TWR-POSCARD. In case of using :

- TWR-POSCARD board requires following important jumper setting of J24(2-3) and J26(1-2), common for all supported boards.
- TWR-K21fF20M Tower System module, TWR-POSCARD jumper settings required: J22 (3-4), J1 (open), J3 (3-5), J7 (2-4, 3-5), J19 (1-2), J18 (open), J2 (3-5)
- TWR-K80F150M Tower System module in combination with the TWR-POSCARD, the following jumper settings are required: J21 (1-2), J22 (1-2, 3-4), J1 (4-6), J3 (4-6), J7 (1-3, 4-6), J19 (), J18 (open), J2 (4-6) on TWR-K80F150M Tower System module 0 ohm resistor R215 has to be removed (this R215 resistor is required to communicate with on board (K80F150M) SIM interface).

#### 69.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.
5. Insert smart card into socket (when using TWR-POSCARD Tower System module, it's the socket under magnetic stripe reader; when using TWR-K80 Tower System modules, it's the socket under micro SD card socket).

#### 69.4.3 Run the example

These instructions are displayed/shown on the terminal window:

##### SMARTCARD blocking

```

SMARTCARD Driver Send Receive blocking functionality example *****

Insert a smart card to test
Card inserted.
Deactivating card...Done!
Resetting/Activating card...Done!
=====
Send receive blocking functionality example in T=0 mode started!

```

```
Smart card EEPROM Start Address = 0xC00000
Smart card EEPROM Size = 32 KBytes

Deactivating card...Done!
Resetting/Activating card...Done!

Send receive blocking functionality example in T=1 mode started!

LRC received correctly
Echo data received correctly!
Command status OK

Send receive blocking functionality example finished!
=====
```

### SMARTCARD non-blocking

```
SMARTCARD Driver Send Receive non-blocking functionality example *****

Card inserted.
Deactivating card...Done!
Resetting/Activating card...Done!
=====
Send receive non-blocking functionality example in T=0 mode started!

Smart card EEPROM Start Address = 0xC00000
Smart card EEPROM Size = 32 KBytes

Deactivating card...Done!
Resetting/Activating card...Done!

Send receive non-blocking functionality example in T=1 mode started!

LRC received correctly
Echo data received correctly!
Command status OK

Send receive non-blocking functionality example finished!
=====
```



## Chapter 70

### SPI Example with other methods

#### 70.1 Overview

The SPI Example project is a demonstration program that uses the KSDK software. This example provides 5 examples SPI board to board with 5 modes: SPI polling, non-blocking, blocking, DMA blocking, DMA non blocking, and SPI loopback.

- SPI board to board:
  - Transfer data through instance 0 of SPI interface, SPI0 pins of master board are connected with SPI0 pins of slave board.
  - Ensure that all SPI board-to-board connections are kept as short as possible and that a solid ground wire is connected between the boards. Preferably this ground connection should be as close as possible to the SPI signals on each board. A poor board-to-board connection compromises data signal integrity causing failures in the example.
  - Master send an array to slave and receive the array back from slave, compare whether the two buffers are the same. Slave send back received buffer from master. Set up the slave first.
- SPI master loopback:
  - Transfer data through instance 0 of SPI interface, MISO pin and MOSI pin are connected
  - Send an array out through MISO pin and compare it with received buffer from MOSI pin

#### 70.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the SPI example.

- FRDM-KL02Z (\*) (DMA not supported)
- FRDM-KL03Z (\*) (DMA not supported)
- FRDM-KL25Z (\*) (DMA not supported)
- FRDM-KL26Z
- FRDM-KL27Z (\*) (DMA not supported)
- FRDM-KL43Z
- FRDM-KL46Z
- MRB-KW01
- TWR-KL25Z48M (\*) (DMA not supported)
- TWR-KL43Z48M
- TWR-KM34Z75M

#### 70.3 System Requirement

##### 70.3.1 Hardware requirements

- J-Link ARM



## Getting Started

- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (Tower System/base board, ...) for specific device
- Personal Computer

### 70.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/spi/<use_-case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

## 70.4 Getting Started

### 70.4.1 Hardware settings

- SPI master loopback:
  - Transfer data through instance 0 of SPI interface, MISO pin and MOSI pin are connected
- SPI board to board:
  - Transfer data through instance 0 of SPI interface, SPI0 pins of master board are connected with SPI0 pins of slave board

<note>For the MRB-KW01: Open J3 to disconnect PTD4(PCS0) with DIO4.</note>

This example requires two separate boards. Connect instance SPI0 master to SPI0 slave:

#### FRDM-KL02Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J7 pin 5	->	MISO	J7 pin 5
MOSI	J7 pin 4	->	MOSI	J7 pin 4
SCK	J7 pin 3	->	SCK	J7 pin 3
PCS0	J7 pin 6	->	PCS0	J7 pin 6
GND	J7 pin 7	->	GND	J7 pin 7

#### FRDM-KL03Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J2 pin 3	->	MISO	J2 pin 3

MOSI	J2 pin 5	->	MOSI	J2 pin 5
SCK	J2 pin 4	->	SCK	J2 pin 4
PCS0	J2 pin 6	->	PCS0	J2 pin 6
GND	J2 pin 7	->	GND	J2 pin 7

**FRDM-KL25Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J1 pin 11	->	MISO	J1 pin 11
MOSI	J1 pin 1	->	MOSI	J1 pin 1
SCK	J1 pin 9	->	SCK	J1 pin 9
PCS0	J1 pin 7	->	PCS0	J1 pin 7
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KL26Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J1 pin 9	->	MISO	J1 pin 9
MOSI	J1 pin 11	->	MOSI	J1 pin 11
SCK	J4 pin 9	->	SCK	J4 pin 9
PCS0	J1 pin 7	->	PCS0	J1 pin 7
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KL27Z:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J2 pin 10	->	MISO	J2 pin 10
MOSI	J2 pin 8	->	MOSI	J2 pin 8
SCK	J2 pin 12	->	SCK	J2 pin 12
PCS0	J2 pin 6	->	PCS0	J2 pin 6
GND	J2 pin 14	->	GND	J2 pin 14

**FRDM-KL43Z:**

## Getting Started

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO		->	MISO	
MOSI		->	MOSI	
SCK		->	SCK	
PCSO		->	PCSO	
GND		->	GND	

### FRDM-KL46Z:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J3 pin 3	->	MISO	J3 pin 3
MOSI	J3 pin 5	->	MOSI	J3 pin 5
SCK	J3 pin 7	->	SCK	J3 pin 7
PCSO	J3 pin 9	->	PCSO	J3 pin 9
GND	J3 pin 14	->	GND	J3 pin 14

### MRB-KW01:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	J15 pin 20	->	MISO	J15 pin 20
MOSI	J15 pin 19	->	MOSI	J15 pin 19
SCK	J15 pin 18	->	SCK	J15 pin 18
PCSO	J14 pin 16	->	PCSO	J14 pin 16
GND	J15 pin 15	->	GND	J15 pin 15

### TWR-KL43Z48M:

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator B44	->	MISO	Primary Elevator B44
MOSI	Primary Elevator B45	->	MOSI	Primary Elevator B45

SCK	Primary Elevator B48	->	SCK	Primary Elevator B48
PCSO	Primary Elevator B46	->	PCSO	Primary Elevator B46
GND	Primary Elevator B2	->	GND	Primary Elevator B2

**TWR-KL25Z48M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
MISO	Primary Elevator B44	->	MISO	Primary Elevator B44
MOSI	Primary Elevator B45	->	MOSI	Primary Elevator B45
SCK	Primary Elevator B48	->	SCK	Primary Elevator B48
PCSO0	Primary Elevator B46	->	PCSO0	Primary Elevator B46
GND	Primary Elevator B2	->	GND	Primary Elevator B2

**TWR-KM34Z75M:**

Master Board		Connects To	Slave Board	
Pin Name	Board Location		Pin Name	Board Location
PTG5/MISO	J13 pin 2	->	PTG5/MISO	J13 pin 2
PTG4/MOSI	J15 pin 1	->	PTG4/MOSI	J15 pin 1
PTG3/SCK	J12 pin 1	->	PTG3/SCK	J12 pin 1
PTG2/PCSO	J9 pin 2	->	PTG2/PCSO	J9 pin 2
GND	J25 Pin 26	->	GND	J25 Pin 26

**70.4.2 Prepare the example**

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit

## Getting Started

- No flow control
3. Download the program to the target board.
  4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 70.4.3 Run the example

#### 70.4.3.1 SPI blocking Master - Slave

Set up the Slave first. The Slave board must be powered up first and then it echoes on the terminal:

```
SPI board-to-board blocking example
This example run on instance 0
Be sure master's SPI0 and slave's SPI0 are connected
Slave example is running...
```

Master sends an array to slave, receives the array back from slave, and compares whether the two buffers are the same. The master board prints to the terminal:

```
SPI board-to-board blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected.

Baud rate in Hz is: 500000

Master transmits:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F

SPI master transfer succeed!

Press any key to run again
```

The slave board receives and prints to the terminal:

```
Slave receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Slave example is running...
```

#### 70.4.3.2 SPI non-blocking Master - Slave

Set up the Slave first and then the slave board echoes on the terminal:

```
SPI board-to-board non-blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected.
Slave example is running...
```

Master sends an array to slave, receives the array back from the slave, and compares whether the two buffers are the same. The master board prints to the terminal:

```
SPI board-to-board non-blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected
```

```
Baud rate in Hz is: 500000
```

```
Master transmits:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
```

```
SPI master transfer succeed!
Press any key to run again
```

The slave board receives and prints to the terminal:

```
Slave receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Slave example is running...
```

### 70.4.3.3 SPI DMA blocking Master - Slave

Set up the Slave first and then the slave board echoes on the terminal:

```
SPI board to board DMA blocking example
This example run on instance 0
Be sure master's SPI0 and slave's SPI0 are connected
Slave example is running...
```

Master sends an array to the slave, receives the array back from the slave, and compares whether the two buffers are the same. The master board prints to the terminal.

```
SPI board-to-board DMA blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected
```

```
Baud rate set to 500000Hz
```

```
Master transmits:
```

## Getting Started

```

00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
SPI master transfer succeed!

```

Press any key to run again

The slave board receives and prints to the terminal:

```

Slave receives:
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Slave example is running...

```

### 70.4.3.4 SPI DMA non-blocking Master - Slave

Set up the Slave first and then the slave board echoes on the terminal:

```

SPI board-to-board DMA non-blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected
Slave example is running...

```

Master sends an array to the slave, receives the array back from the slave, and compares whether the two buffers are the same. The master board prints to the terminal:

```

SPI board to board DMA non blocking example
This example runs on instance 0.
Be sure master's SPI0 and slave's SPI0 are connected

Baud rate set to 500000 Hz
Master transmits:
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
SPI master transfer succeeded!

```

Press any key to run again.

The slave board receives and prints to the terminal:

```

Slave receive:
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Slave example is running...

```

### 70.4.3.5 SPI polling Master - Slave

Set up the slave first and then the slave board echoes to the terminal:

```
SPI board to board polling example
This example run on instance 0
Be sure master's SPI0 and slave's SPI0 are connected
Slave example is running...
```

Master sends an array to the slave, receives the array back from the slave, and compares whether the two buffers are the same. The master board prints to the terminal:

```
SPI board to board polling example
This example run on instance 0
Be sure master's SPI0 and slave's SPI0 are connected

Baud rate in Hz is: 500000

Master transmits:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
SPI master transfer succeed!

Press any key to run again
```

The slave board receives and prints on the terminal:

```
Slave receives:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Slave example is running...
```

### 70.4.3.6 SPI loopback

These instructions are displayed/shown on the terminal window:

```
SPI loopback example
This example runs on instance 0.
Be sure MISO-to-MOSI are connected

Baud rate in Hz is: 500000

Master transmits:
 00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
 10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
 20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
 30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
Master receives:
```



## Getting Started

```
00 01 02 03 04 05 06 07 08 09 0A 0B 0C 0D 0E 0F
10 11 12 13 14 15 16 17 18 19 1A 1B 1C 1D 1E 1F
20 21 22 23 24 25 26 27 28 29 2A 2B 2C 2D 2E 2F
30 31 32 33 34 35 36 37 38 39 3A 3B 3C 3D 3E 3F
SPI master transfer succeed!

Press any key to run again
```

## Chapter 71

### SPI SDCard Example

#### 71.1 Overview

The SPI SDCard Example application demonstrates the use of SD card driver with SPI. This example doesn't support SD card memory that is greater than 2 GB)

- Detect card inserted
- Check card status: lock or unlock (detect by hardware pin)
- Read and write single block and multi-blocks to SDCard
- Erase blocks in SDCard

#### 71.2 Supported Platforms

These Freescale Tower System modules are supported by the SPI SDCard example.

- TWR-K22F120M
- TWR-K24F120M
- TWR-KV31F120M

#### 71.3 System Requirement

##### 71.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, TWR-MEM board...) for specific device
- Personal Computer

##### 71.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/spi\_sdcard/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

#### 71.4 Getting Started

##### 71.4.1 Hardware settings

The SPI SDCard Example project does not require any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in

## Getting Started

default state when running this example. If there is not any built-in SDCard slot on the board, the TWR--MEM Tower System module is required to run this example.

### 71.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 71.4.3 Run the example

Ensure that the card doesn't contain any important content because the demo erases and overwrites some sectors.

These instructions are displayed/shown on the terminal window:

```
SPI SD Card Demo Start!
BaudRate set to 375000Hz
BaudRate set to 20000000Hz
----- Card Information -----
Card Type: SDSC
Card Capacity: 1.97 GB
----- Card CID -----
Manufacturer ID: 0x2
OEM ID: 0x544D
Product name: SA02G
Product revision: 0.5
Product serial number: 0x2080728A
Manufacturing data: Aug 2010
----- Card CSD -----
CSD Structure: 0x0
taac: 2000.00 us
nsac: 0 clks
tran speed: 25000000.00 kbps
ccc: class 0 2 4 5 7 8 10
max read block length: 1024 Bytes
max write block length: 1024 Bytes
Support partial read
Support crossing physical block boundaries reading is allowed
VDD_R_CURR_MIN: 0x7
VDD_R_CURR_MAX: 0x1
VDD_W_CURR_MIN: 0x7
VDD_W_CURR_MAX: 0x3F
c_size_mult: 7
c_size: 3763
Erase unit size is one or multiple units of 512 bytes
The size of write protected group is 2 blocks
```

```
R2W_Factor: 2
Hard disk-like file system with partition table

Start read/write example...
Single block read/write example passed!
Writing 4096 bytes for 100 times in 2502 ms, at 163 kB/s
Reading 4096 bytes for 100 times in 2164 ms, at 189 kB/s
Multi-block read/write example passed!

SPI SD Card Demo End!
```



## Chapter 72

### TPM Example

#### 72.1 Overview

The TPM Example project is a demonstration program that uses the KSDK software to generate square pulse PWM to control a LED brightness.

- TPM generate a PWM with increasing duty cycle and then decreasing
- LED is firstly brighter and then dimmer, continuously

#### 72.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the TPM example.

- FRDM-KL02Z
- FRDM-KL03Z
- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL27Z
- FRDM-KL43Z
- FRDM-KL46Z
- FRDM-KW40Z
- TWR-KL43Z48M
- USB-KW40Z

NOTE: The TWR-K65F180M does not have a suitable LED. The PWM signal is connected to the elevator board connector B52.

#### 72.3 System Requirement

##### 72.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

##### 72.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/tpm/<toolchain>.

## Getting Started

- Library dependencies: ksdk\_platform\_lib

## 72.4 Getting Started

### 72.4.1 Hardware settings

The TPM Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 72.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 72.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
See the change of LED brightness
```

After that, LED bright is first increasing and then LED becomes dimmer, continuously.

## Chapter 73 TSI Example

### 73.1 Overview

The TSI Example project is a demonstration program that uses the KSDK software to demonstrate how to use touch sensor interface. This example turns on LEDs when the board is in a touch state. Otherwise, LEDs are turned it off.

### 73.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the TSI example.

- FRDM-KL25Z
- FRDM-KL26Z
- FRDM-KL46Z
- FRDM-KW40Z
- TWR-K65F180M
- TWR-K80F150M

### 73.3 System Requirement

#### 73.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 73.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/tsi/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

### 73.4 Getting Started

#### 73.4.1 Hardware settings

The TSI Example project does not require any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state



## Getting Started

when running this example.

### 73.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 73.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
Touch Sensing input example  
Touching for turning led on
```

After that, the LED brightness toggles after each touch state change.

## Chapter 74

# Universal Asynchronous Receiver/Transmitter (UART) Example with other methods

### 74.1 Overview

This UART example application demonstrates the KSDK Peripheral drivers with different methods.

- Using blocking method
- Using non-blocking method
- Using DMA blocking method
- Using DMA non-blocking method
- Using polling method

Transfer data between the board and the PC. The board transfers and receives characters the UART interface. Type characters from the keyboard and the board receives and then echoes them to the terminal screen. See instructions output to the terminal.

### 74.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the UART example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KL03Z (\*) (eDMA not supported)
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24 (\*) (eDMA not supported)
- TWR-K21D50M (\*) (eDMA not supported)
- TWR-K21F120M (\*) (eDMA not supported)
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M (\*) (eDMA not supported)
- TWR-K64F120M
- TWR-K65F180M
- TWR-KL43Z48M (\*) (eDMA not supported)
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512 (\*) (eDMA not supported)

## Getting Started

### 74.3 System Requirement

#### 74.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal
- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

#### 74.3.2 Software requirements

- The project files are in: `<SDK_Install>/examples/<board>/driver_examples/uart/<use_case>/<toolchain>`.
- Library dependencies: `ksdk_platform_lib`

### 74.4 Getting Started

#### 74.4.1 Hardware settings

The UART Example project does not require any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

#### 74.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 74.4.3 Run the example

#### 74.4.3.1 UART blocking

These instructions are displayed/shown on the terminal window:

```
+++++ UART Send/Receive Blocking Example +++++
```

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

#### 74.4.3.2 UART non-blocking

These instructions are displayed/shown on the terminal window:

```
+++++ UART Send/Receive Non Blocking Example +++++
```

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

#### 74.4.3.3 UART DMA blocking

These instructions are displayed/shown on the terminal window:

```
+++++ UART-DMA Send/Receive Blocking Example +++++
```

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

#### 74.4.3.4 UART DMA non-blocking

These instructions are displayed/shown on the terminal window:

```
+++++ UART-DMA Send/Receive Non Blocking Example +++++
```

Type characters from keyboard, the board receives and then echoes them to the terminal screen.

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

## Getting Started

### 74.4.3.5 UART polling

These instructions are displayed/shown on the terminal window:

```
+++++ UART Send/Receive Polling Example +++++
```

```
Type the characters on the keyboard and the board receives and then echoes them to terminal screen.
```

Type the characters on the keyboard and the board receives and then echoes them to terminal screen.

## Chapter 75

### WDOG Example

#### 75.1 Overview

The WDOG Example project is a demonstration program that uses the KSDK software to show a simple application that enables Watchdog, then continuously refreshes the watchdog to prevent CPU reset. Upon SW button push, the Watchdog expires after approximately 2 seconds and the chip resets.

- Combine refresh and reset operation on WDOG timer
- Use a SW to start WDOG. When SW is pressed, WDOG begins to expire.
- Use a LED to indicate reset process. At first, LED is turned on, when SW is pressed, LED start blinking and after resetting LED is turned off. And then, LED is turned on after reset is success.

#### 75.2 Supported Platforms

These Freescale Freedom development platforms and Tower System modules are supported by the WDOG example.

- FRDM-K22F
- FRDM-K64F
- FRDM-KV10Z
- FRDM-KV31F
- FRDM-KW24
- TWR-K21D50M
- TWR-K21F120M
- TWR-K22F120M
- TWR-K24F120M
- TWR-K60D100M
- TWR-K64F120M
- TWR-K65F180M
- TWR-K80F150M
- TWR-KM34Z75M
- TWR-KV10Z32
- TWR-KV11Z75M
- TWR-KV31F120M
- TWR-KW24D512

#### 75.3 System Requirement

##### 75.3.1 Hardware requirements

- J-Link ARM
- P&E Micro Multi-link universal

## Getting Started

- Mini/micro USB cable
- USB A to micro AB cable
- Hardware (tower/base board, ...) for specific device
- Personal Computer

### 75.3.2 Software requirements

- The project files are in: <SDK\_Install>/examples/<board>/driver\_examples/wdog/<toolchain>.
- Library dependencies: ksdk\_platform\_lib

## 75.4 Getting Started

### 75.4.1 Hardware settings

The WDOG Example project does not call for any special hardware configurations. Although not required, the recommendation is to leave the development board's jumper settings and configurations in default state when running this example.

### 75.4.2 Prepare the example

1. Connect a USB cable between the PC host and the OpenSDA USB port on the board.
2. Open a serial terminal with these settings:
  - 115200 baud rate
  - 8 data bits
  - No parity
  - One stop bit
  - No flow control
3. Download the program to the target board.
4. Either press the reset button on your board or launch the debugger in your IDE to begin running the example.

### 75.4.3 Run the example

These instructions are displayed/shown on the terminal window:

```
WDOG example
```

```
Press SW to expire watchdog  
WDOG reset occurred  
Press SW to expire watchdog  
WDOG reset occurred  
Press SW to expire watchdog
```

After that, user need press the SW (\*) button on board and observe a LED toggle for showing that the watchdog is about to expire.

## Chapter 76 Revision History

This table summarizes revisions to this document.

### Revision history

Revision number	Date	Substantive changes
0	09/2015	Initial release





**How to Reach Us:**

**Home Page:**

[freescale.com](http://freescale.com)

**Web Support:**

[freescale.com/support](http://freescale.com/support)

Information in this document is provided solely to enable system and software implementers to use Freescale products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits based on the information in this document.

Freescale reserves the right to make changes without further notice to any products herein. Freescale makes no warranty, representation, or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale data sheets and/or specifications can and do vary in different applications, and actual performance may vary over time. All operating parameters, including "typicals," must be validated for each customer application by customer's technical experts. Freescale does not convey any license under its patent rights nor the rights of others. Freescale sells products pursuant to standard terms and conditions of sale, which can be found at the following address:

[freescale.com/SalesTermsandConditions](http://freescale.com/SalesTermsandConditions).

Freescale, the Freescale logo, Kinetis, Processor Expert are trademarks of Freescale Semiconductor, Inc., Reg. U.S. Pat. & Tm. Off. Tower is a trademark of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. ARM, ARM Powered logo, Keil, and Cortex are registered trademarks of ARM Limited (or its subsidiaries) in the EU and/or elsewhere. All rights reserved.

© 2015 Freescale Semiconductor, Inc.

