





**FRDM-HB2000FEVM**



All settings jumper position  
1-2 for operation with MCU and  
2-3 for manual operation.



				
ICAP Classification:		CP:	IUC: X	PUB:
Drawing Title:				
<b>FRDM-HB2000FEVM</b>				
Page Title:				
<b>Board Schematic</b>				
Size C	Document Number	SCH-28930 PDF: SPF-28930		Rev A
Date:	Friday, May 06, 2016	Sheet	1 of 1	