

AN12918

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

Rev. 14.0 — 17 September 2025

Application note

Document information

Information	Content
Keywords	Transmit (TX) power levels, TX power table, Wi-Fi channel list, data structure, CLI command
Abstract	Describes how to configure the Wi-Fi TX power table and Wi-Fi channel list in the product software.



1 Introduction

The Wi-Fi TX power table defines the target transmit power levels for all operating conditions of the product. The transmit power levels are determined based on regulatory compliance, IEEE 802.11 requirements, and product design constraints. The general goal is to adjust the power table to achieve the highest transmit power level within these constraints.

The target power level is defined at the antenna connector and set per Wi-Fi channel, bandwidth, and modulation.

The Wi-Fi channel list defines the channels allowed for the product. The channel list must be adjusted for the regulatory domain and country-specific requirements. For example, a product certified for use in Europe, can operate on channels 1-13 in the 2.4 GHz band, whereas operation in the USA is restricted to channels 1-11.

The channel selection during the product operation requires the radio to scan the channel list. Two scan types can be selected.

1.1 Scope

This application note describes how to configure the Wi-Fi TX power table and Wi-Fi channel list in product software.

It includes information on the APIs, data structures, and CLI commands that can be used to update the power table and channel list. It is recommended to review the basic product software architecture before using this document.

1.2 Supported products

- IW416
- 88W8987
- IW610
- IW611
- IW612
- AW611¹

¹ AW611 module support is available only in i.MX RT1180 EVKA.

2 TX power tables

2.1 TX power table in OTP

The Wi-Fi TX power table may optionally be programmed into the OTP memory on the radio.

If the power table is already programmed in the OTP memory and the Region Enforcement bit is set, then you cannot update the power table using the API defined in this document. Please note:

- The `get` command (which reads the power table) will return the power table defined in OTP.
- The `set` command (which sets the power table) will not update the power table and it will not report an error.

2.2 TX power table configuration

The TX power tables can be edited to customize the transmission power levels for each wireless channel, based on the system requirements and regulatory domain rules. The steps to configure the channel and power level are explained in this section.

The TX power levels are set using `wlan_set_txpwrlimit` API, and queried using `wlan_get_txpwrlimit` API. The functions use the following data structures:

- `tx_pwrlimit_2g_cfg` (power levels in 2.4 GHz band)
- `tx_pwrlimit_5g_cfg` (power levels in 5 GHz band)

Both data structures are defined in the following files:

- For AzureWave modules:
`<sdk_path>/components/wifi_bt_module/AzureWave/tx_pwr_limits/wlan_txpwrlimit_cfg_WW.h`
- For Murata modules:
`<sdk_path>/components/wifi_bt_module/Murata/tx_pwr_limits/wlan_txpwrlimit_cfg_murata_<MODULE_NAME>_WW.h`

The information within these structures allows the user to specify transmit power levels for specific:

- band
- channels
- data rate
- bandwidth

See below an example of `tx_pwrlimit_2g_cfg` and `tx_pwrlimit_5g_cfg` data structures.

Refer to `<sdk_path>/middleware/wifi_nxp/wlcmgr/wlan_tests.c` for an example of how the data structures are populated and used in the APIs for TX power configuration.

```

static wlan_txpwrlimit_t
tx_pwrlimit_2g_cfg =
{
    .subband = (wifi_SubBand_t)0x00,
    .num_chans = 1,
    .txpwrlimit_config[0] =
    {
        .num_mod_grps = 7,
        .chan_desc =
        {
            .start_freq = 2407,
            .chan_width = 20,
            .chan_num = 1,
        },
        .txpwrlimit_entry = {{0, 15}, {1, 15}, {2, 15}, {3, 14}, {4, 14}, {5, 14}, {6, 13}},
    },
};
#ifdef CONFIG_5GHz_SUPPORT
static wlan_txpwrlimit_t tx_pwrlimit_5g_cfg =
{
    .subband = (wifi_SubBand_t)0x00,
    .num_chans = 4,
    .txpwrlimit_config[0] =
    {
        .num_mod_grps = 9,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 36,
        },
        .txpwrlimit_entry = {{1, 16}, {2, 16}, {3, 15}, {4, 15}, {5, 15}, {6, 14}, {7, 14}, {8, 14}, {9, 13}},
    },
    .txpwrlimit_config[1] =
    {
        .num_mod_grps = 9,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 100,
        },
        .txpwrlimit_entry = {{1, 16}, {2, 16}, {3, 15}, {4, 15}, {5, 15}, {6, 14}, {7, 14}, {8, 14}, {9, 13}},
    },
    .txpwrlimit_config[2] =
    {
        .num_mod_grps = 9,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 149,
        },
        .txpwrlimit_entry = {{1, 16}, {2, 16}, {3, 15}, {4, 15}, {5, 15}, {6, 14}, {7, 14}, {8, 14}, {9, 13}},
    },
    .txpwrlimit_config[3] =
    {
        .num_mod_grps = 9,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 183,
        },
        .txpwrlimit_entry = {{1, 0}, {2, 0}, {3, 0}, {4, 0}, {5, 0}, {6, 0}, {7, 0}, {8, 0}, {9, 0}},
    },
};
#endif

```

The main parameters in the `tx_pwrlimit_2g_cfg` and `tx_pwrlimit_5g_cfg` data structures are defined in [Table 1](#).

Table 1. Main parameters in txpwrlimit data structures

Parameter	Description
num_chans	Number of wireless channels configured in this structure. Up to 13 channels for 2.4 GHz and up to 39 channel for 5 GHz are supported.
num_mod_groups	Number of rate groups to configure the power level for
chan_num	Channel number
start_freq	Starting frequency for a channel
chan_width	Channel bandwidth in MHz (remains 20 MHz)
txpwrlimit_entry	Specifies the power levels corresponding to rate groups
txpwrlimit_config	Configuration entry

The example sets TX power table for channel 1 for the 2.4 GHz band, and for channels 36, 100, 149 and 183 for the 5 GHz band. Each channel within the structure is associated with a configuration entry (parameter `txpwrlimit_config`). The configuration entry includes the channel number, the frequency, and the parameter `txpwrlimit_entry`. The `txpwrlimit_entry` parameter sets the TX power table.

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

The TX power table includes all the target power levels organized by RF channel and rate group index. To reduce the size of the power table, multiple data rates are grouped into a single rate group. For example, 24 Mbit/s and 36 Mbit/s legacy OFDM rates are combined in a single rate group and have the same target power level. See [Table 2](#).

Table 2. Rate group information

Rate group	Description
0	CCK modulation (data rates: 1, 2, 5.5, 11 Mbit/s)
1	OFDM modulation (data rates: 6, 9, 12, 18 Mbit/s)
2	OFDM modulation (data rates: 24, 36 Mbit/s)
3	OFDM modulation (data rates: 48, 54 Mbit/s)
4	Channel bandwidth 20 MHz, 1 spatial stream, MCS: 0,1,2
5	Channel bandwidth 20 MHz, 1 spatial stream, MCS: 3,4
6	Channel bandwidth 20 MHz, 1 spatial stream, MCS: 5,6,7
7	Channel bandwidth 40 MHz, 1 spatial stream, MCS: 0,1,2
8	Channel bandwidth 40 MHz, 1 spatial stream, MCS: 3,4
9	Channel bandwidth 40 MHz, 1 spatial stream, MCS: 5,6,7
10	Channel bandwidth 20 MHz, 1 spatial stream, MCS: 8 ^[1]
11	Channel bandwidth 40 MHz, 1 spatial stream, MCS: 8,9 ^[1]
12	Channel bandwidth 80 MHz, 1 spatial stream, MCS: 0,1,2 ^[1]
13	Channel bandwidth 80 MHz, 1 spatial stream, MCS: 3,4 ^[1]
14	Channel bandwidth 80 MHz, 1 spatial stream, MCS: 5,6,7 ^[1]
15	Channel bandwidth 80 MHz, 1 spatial stream, MCS: 8,9 ^[1]
16	Channel bandwidth 20 MHz, 1 spatial stream, HE MCS: 8, 9 ^[2]
17	Channel bandwidth 80 MHz, 1 spatial stream, HE MCS: 10, 11 ^[2]
17	Channel bandwidth 20 MHz, 1 spatial stream, HE MCS: 10, 11 ^[2]
18	Channel bandwidth 40 MHz, 1 spatial stream, HE MCS: 10, 11 ^[2]
19	Channel bandwidth 80 MHz, 1 spatial stream, HE MCS: 10, 11 ^[2]

[1] 802.11ac supports these modulation groups.

[2] 802.11ax supports these modulation groups.

For example, a channel OFDM modulation at 54 Mbit/s rate refers to the rate group **3**.

Example of the data structure `tx_pwrlimit_2g_cfg`:

```
.txpwrlimit_config[1] =
{
    .num_mod_grps = 10,
    .chan_desc =
    {
        .start_freq = 2407,
        .chan_width = 20,
        .chan_num = 2,
    },
    .txpwrlimit_entry = {{0, 17}, {1, 18}, {2, 17}, {3, 14}, {4, 18}, {5, 16}, {6, 14}, {7, 18}, {8,
16}, {9, 14}},
},
```

In the example above, the power table for the rate group 3 is set to 14 dBm. The value can be edited. Notice that the number of elements in `txpwrlimit_entry` reflects the number specified by the parameter `num_mod_grps`.

Example with the data structure `tx_pwrlimit_5g_cfg`:

```
static wlan_txpwrlimit_t tx_pwrlimit_5g_cfg =
{
    .subband = (wifi_SubBand_t)0x00,
    .num_chans = 4,
    .txpwrlimit_config[0] =
    {
        .num_mod_grps = 9,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 36,
        },
        .txpwrlimit_entry = {{1, 16}, {2, 16}, {3, 15}, {4, 14}, {5, 15}, {6, 14}, {7, 14}, {8, 14}, {9,
13}},
    },
},
```

The example sets channel 36, channel bandwidth 20 MHz, rate group 4, and TX power of 14 dBm.

For the change of TX power table to take effect, rebuild and load the SDK to the platform.

The following is an example for 5 GHz and 80 MHz bandwidth.

```
static wlan_txpwrlimit_t tx_pwrlimit_5g_cfg =
{
    .subband = (wifi_SubBand_t)0x00,
    .num_chans = 4,
    .txpwrlimit_config[0] =
    {
        .num_mod_grps = 15,
        .chan_desc =
        {
            .start_freq = 5000,
            .chan_width = 20,
            .chan_num = 36,
        },
        .txpwrlimit_entry = {{0, 18}, {1, 18}, {2, 16}, {3, 14},
{4, 18}, {5, 16}, {6, 14}, {7, 18}, {8, 16}, {9, 14},
{10, 16}, {11, 16}, {12, 16}, {13, 16}, {14, 16}},
    },
},
```

Note: In the example above, `chan_width` value remains 20 MHz but `num_mod_grps` value is updated for 80 MHz, and the pair for 40/80 MHz bandwidth is added to `txpwrlimit_entry` array.

2.3 Customization of TX power table configuration

Note: When using a module provided by a third party, consult the module vendor for guidance on the transmit power limitations that were used for regulatory compliance. Setting the TX power to levels beyond what the module is certified to support voids the modular certification on the device.

When the board boots up, the default regulatory region is set to world wide (WW), and the default power level is set to 8 dBm for all channels.

You can change the TX power levels either using the API calls or using the Command Line Interface.

The next sections detail the two methods.

2.3.1 Customization using API calls

The data structures of the API can be defined in the file <sdk_root>/middleware/wifi_nxp/wlcmgr/wlan_tests.c. To set the TX power to the desired level, follow the steps in [Section 2.2 "TX power table configuration"](#).

Use the driver APIs with the required arguments to set the TX power table:

```
int wlan_set_txpwrlimit (wlan_txpwrlimit_t * txpwrlimit)
```

Table 3. Command parameters

Parameter	Description
[in] txpwrlimit	A pointer to wlan_txpwrlimit_t structure to supply TX Power Table configuration. Read more in Section 2.2 "TX power table configuration" .

Returns:

WM_SUCCESS: the call is successful

WM_FAIL: the call failed

Example:

The following example sets TX power limit for 5 GHz bandwidth. The data structure tx_pwrlimit_5g_cfg is passed as parameter.

```
ret = wlan_set_txpwrlimit(&tx_pwrlimit_5g_cfg);
if (WM_SUCCESS != ret)
    PRINTF("Unable to set 5G TX PWR Limit configuration\r\n");
```

The current implementation provides a return status, that can be used to check whether the function call is successful or not.

Use the following function to **get** the TX power table information:

```
int wlan_get_txpwrlimit (wifi_SubBand_t subband, wifi_txpwrlimit_t * txpwrlimit)
```

Table 4. Command parameters

Parameter	Description
[in] subband	Input parameter with the sub-band information detailed in Table 5 .
[Out] txpwrlimit	A pointer to wlan_txpwrlimit_t structure used to supply TX power limit configuration. Read more in Section 2.2 "TX power table configuration" .

Returns:

WM_SUCCESS: the call is successful

WM_FAIL: the call failed

Example:

The following example gets TX power limit for a sub-band.

```
int ret = wlan_get_txpwrlimit(subband, &txpwrlimit);
if (WM_SUCCESS != ret)
{
    PRINTF("Unable to get Tx PWR Limit configuration\r\n");
}
else
{
    PRINTF("Get txpwrlimit: sub_band=%x \r\n", txpwrlimit.subband);
    for (i = 0; i < txpwrlimit.num_chans; i++)
    {
        PRINTF("StartFreq: %d\r\n",
txpwrlimit.txpwrlimit_config[i].chan_desc.start_freq);
        PRINTF("ChanWidth: %d\r\n",
txpwrlimit.txpwrlimit_config[i].chan_desc.chan_width);
        PRINTF("ChanNum:   %d\r\n", txpwrlimit.txpwrlimit_config[i].chan_desc.chan_num);
        PRINTF("Pwr:");
        for (j = 0; j < txpwrlimit.txpwrlimit_config[i].num_mod_grps; j++)
        {
            if (j == (txpwrlimit.txpwrlimit_config[i].num_mod_grps - 1))
                PRINTF("%d,%d", txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].mod_group,
txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].tx_power);
            else
                PRINTF("%d,%d,", txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].mod_group,
txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].tx_power);
        }
        PRINTF("\r\n");
    }
}
```

As input, this function takes the sub-band and the pointer to the wlan_txpwrlimit_t type structure (which corresponds to tx_pwrlimit_2g_cfg for 2.4 GHz and tx_pwrlimit_5g_cfg for 5 GHz band). The output includes:

- sub-band
- starting frequency
- channel width
- channel number
- power levels

The following is an example of system output:

```
# wlan-get-txpwrlimit 00
-----
Get txpwrlimit: sub_band=0
StartFreq: 2407
ChanWidth: 20
ChanNum: 1
Pwr:0,15,1,15,2,15,3,14,4,14,5,14,6,13
```

Returns:

WM_SUCCESS: the call is successful

WM_FAIL: the call failed

Table 5. Sub-band definitions

Sub-band	Description
0x00	2G sub-band (2.4 GHz: channels 1-14)
0x10	5G sub-band0 (5 GHz: channels 36, 40, 44, 48, 52, 56, 60, 64)
0x11	5G sub-band1 ((5 GHz: channels 100, 104, 108, 112, 116, 120, 124, 128, 132, 136, 140, 144)
0x12	5G sub-band2 (5 GHz: channels 149, 153, 157, 161, 165, 172)
0x13	5G sub-band3 (5G: channels 183, 184, 185, 187, 188, 189, 192, 196; 5G: channel 7 ,8, 11, 12, 16, 34)

2.3.2 Customization using the command line interface

The *wifi_cert* sample application is available only for i.MX RT1060. The sample application supports the *set/get* TX power limit commands. This section explains how to add the *set/get* TX power limit commands using *wifi_cli* sample application.

- Edit the file `<sdk_root>/middleware/wifi_nxp/wlcmgr/wlan_tests.c` in the SDK, and add the following line:

```
{"wlan-set-txpwrlimit", NULL, test_wlan_set_txpwrlimit},
```

The example below shows the added line in **bold**.

```
static struct cli_command tests[] = {  
    .  
    .  
    .  
    {"wlan-set-txpwrlimit", NULL, test_wlan_set_txpwrlimit},  
}
```

- Check that the two structures `tx_pwrlimit_2g_cfg` and `tx_pwrlimit_5g_cfg` are correctly set. Refer to [Section 2.2 "TX power table configuration"](#).
- Define the handler for the CLI command `wlan-set-txpwrlimit` to set TX power table.

```
static void test_wlan_set_txpwrlimit(int argc, char **argv)  
{  
    int rv = wlan_set_txpwrlimit(&tx_pwrlimit_2g_cfg);  
    if (rv != WM_SUCCESS)  
        PRINTF("Unable to set 2G TX PWR Limit configuration\r\n");  
    else  
        PRINTF("Successfully configured 2G TX PWR Limit\r\n");  
    #ifdef CONFIG_5GHz_SUPPORT  
        rv = wlan_set_txpwrlimit(&tx_pwrlimit_5g_cfg);  
        if (rv != WM_SUCCESS)  
            PRINTF("Unable to set 5G TX PWR Limit configuration\r\n");  
        else  
            PRINTF("Successfully configured 5G TX PWR Limit\r\n");  
    #endif  
}
```

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

Run the following command from the command line interface.

```
# wlan-set-txpwrlimit
```

Check that the output is as shown below:

```
Successfully configured 2G TX PWR Limit
Successfully configured 5G TX PWR Limit
```

The current SDK implementation does not include the CLI commands to **get** the TX power levels.

To add the `get` command:

- Edit the file `<sdk_root>/middleware/wifi_nxp/wlcmgr/wlan_tests.c`.
- Find the tests structure and add the following line:

```
{"wlan-get-txpwrlimit", "<subband>", test_wlan_get_txpwrlimit},
```

The example below shows the added line in **bold**.

```
static struct cli_command tests[] = {
    .
    .
    .
    {"wlan-get-txpwrlimit", "<subband>", test_wlan_get_txpwrlimit},
};
```

- Edit the command usage function that defines the instructions printed when the help command is executed:

```
static void dump_wlan_get_txpwrlimit_usage()
{
    PRINTF("Usage:\r\n");
    PRINTF("wlan-get-txpwrlimit <subband> \r\n");
    PRINTF("\r\n");
    PRINTF("\t Where subband is: \r\n");
    PRINTF("\t 0x00 2G subband (2.4G: channel 1-14)\r\n");
#ifdef CONFIG_5GHz_SUPPORT
    PRINTF("\t 0x10 5G subband0 (5G: channel 36,40,44,48,\r\n");
    PRINTF("\t 52,56,60,64)\r\n");
    PRINTF("\t 0x11 5G subband1 (5G: channel 100,104,108,112,\r\n");
    PRINTF("\t 116,120,124,128,\r\n");
    PRINTF("\t 132,136,140,144)\r\n");
    PRINTF("\t 0x12 5G subband2 (5G: channel 149,153,157,161,165,172)\r\n");
    PRINTF("\t 0x13 5G subband3 (5G: channel 183,184,185,187,188,\r\n");
    PRINTF("\t 189, 192,196;\r\n");
    PRINTF("\t 5G: channel 7,8,11,12,16,34)\r\n");
#endif
}
```

- Define the handler for the CLI command `wlan-get-txpwrlimit` to get TX power limit:

```
static void test_wlan_get_txpwrlimit(int argc, char **argv)
{
    wifi_SubBand_t subband;
    wlan_txpwrlimit_t txpwrlimit;
    int i, j;
    if (argc != 2)
    {
        dump_wlan_get_txpwrlimit_usage();
        return;
    }
    subband = (wifi_SubBand_t)strtol(argv[1], NULL, 16);

    if (subband != SubBand_2_4_GHz
#ifdef CONFIG_5GHz_SUPPORT
        && subband != SubBand_5_GHz_0 && subband != SubBand_5_GHz_1 && subband !=
        SubBand_5_GHz_2 &&
        subband != SubBand_5_GHz_3
#endif
    )
    {
        dump_wlan_get_txpwrlimit_usage();
        return;
    }

    int rv = wlan_get_txpwrlimit(subband, &txpwrlimit);
    if (rv != WM_SUCCESS)
        PRINTF("Unable to get TX PWR Limit configuration\r\n");
    else
    {
        PRINTF("Get txpwrlimit: sub_band=%x \r\n", txpwrlimit.subband);
        for (i = 0; i < 1; i++)
        {
            PRINTF("StartFreq: %d\r\n", txpwrlimit.txpwrlimit_config[i].chan_desc.start_freq);
            PRINTF("ChanWidth: %d\r\n", txpwrlimit.txpwrlimit_config[i].chan_desc.chan_width);
            PRINTF("ChanNum: %d\r\n", txpwrlimit.txpwrlimit_config[i].chan_desc.chan_num);
            PRINTF("Pwr:");
            for (j = 0; j < txpwrlimit.txpwrlimit_config[i].num_mod_grps; j++)
            {
                if (j == (txpwrlimit.txpwrlimit_config[i].num_mod_grps - 1))
                    PRINTF("%d,%d", txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].mod_group,
                        txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].tx_power);
                else
                    PRINTF("%d,%d,", txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].mod_group,
                        txpwrlimit.txpwrlimit_config[i].txpwrlimit_entry[j].tx_power);
            }
            PRINTF("\r\n");
        }
    }
}
```

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

- Rebuild the SDK and run the command `wlan-get-txpwrlimit`.

The three code samples below show examples of `wlan-get-txpwrlimit` command outputs.

```
# wlan-get-txpwrlimit 00
Get txpwrlimit: sub_band=0
StartFreq: 2407
ChanWidth: 20
ChanNum: 1
Pwr:0,15,1,15,2,15,3,14,4,14,5,14,6,13
```

```
# wlan-get-txpwrlimit 10
Get txpwrlimit: sub_band=10
StartFreq: 5000
ChanWidth: 20
ChanNum: 36
Pwr:1,16,2,16,3,15,4,15,5,15,6,14,7,14,8,14,9,13
```

```
# wlan-get-txpwrlimit 12
Get txpwrlimit: sub_band=12
StartFreq: 5000
ChanWidth: 20
ChanNum: 149
Pwr:1,16,2,16,3,15,4,15,5,15,6,14,7,14,8,14,9,13
```

2.3.3 Customization using the region-specific TX power limit file

By default, the regulatory region is set to worldwide (WW). The default power level is set to 8 dBm for all channels. The TX power limit files are specific to the module vendor. For example:

For AzureWave modules: `<sdk_path>/components/wifi_bt_module/AzureWave/tx_pwr_limits/wlan_txpwrlimit_cfg_WW.h`

For Murata modules: `<sdk_path>/components/wifi_bt_module/Murata/tx_pwr_limits/wlan_txpwrlimit_cfg_murata_<MODULE_NAME>_WW.h`

To set TX power for another region, follow the steps below.

Step 1 – Get the region-specific files from the module vendor.

Ask your module vendor for the region-specific files and place the file in the SDK at the path mentioned above. Ensure that the file name includes the region. For example, if the region is the USA, name the file as “`wlan_txpwrlimit_cfg_murata_2EL_US_RU_Tx_power.h`”.

Step 2 – Define the region code in the new TX power file.

```
#define WLAN_REGION_CODE "US"
```

Step 3 – Include the TX power .h file in the `wifi_bt_module_config.h` file at `<SDK_PATH>/components/wifi_bt_module/incl/wifi_bt_module_config.h`.

```
#define WIFI_BT_TX_PWR_LIMITS "wlan_txpwrlimit_cfg_murata_2EL_US_RU_Tx_power.h"
```

Step 4 – Update the `wifi_config.h` file.

Path to the file: `evk<RT-platform>wifi_<example>\source\wifi_config.h`.

Disable `CONFIG_COMPRESS_TX_PWTBL` and `CONFIG_COMPRESS_RU_TX_PWTBL`:

```
#define CONFIG_COMPRESS_TX_PWTBL 0
#define CONFIG_COMPRESS_RU_TX_PWTBL 0
```

Step 5 – Rebuild and flash the application.

3 Channel list and scan type

To set/get the channel list and scan type, use the command line interface in the *wifi_cert* sample application. The default channel list and scan configuration are described in [Table 6](#).

Table 6. Default channel list and scan configuration

Bandwidth (GHz)	Channels	Scan
2.4	1-11	Active
2.4	12-14	Passive
5	36-48	Active
5	52-64	Passive
5	100-144	Passive
5	149-165	Passive

During a passive scan, the client radio listens for the beacons sent by an AP on each channel. The passive scan lasts longer than the active scan. During an active scan, the client radio transmits a probe request and listens for a probe response from an AP.

The channel list and scan type are set using `wlan_set_chanlist` API. The function uses `chanlist_2g_cfg` and `chanlist_5g_cfg` data structures. Both structures are defined in `<sdk_root>/middleware/wifi_nxp/wlcmgr/wlan_txpwrlimit_cfg_WW.h`.

`chanlist_2g_cfg` is used for 2.4 GHz band (see below) and `chanlist_5g_cfg` is used for 5 GHz.

```
static wlan_chanlist_t chanlist_2g_cfg = {
    2,
    [0] =
    {
        .chan_num           = 1,
        .chan_freq          = 2412,
        .passive_scan_or_radar_detect = false,
    },
    [1] =
    {
        .chan_num           = 12,
        .chan_freq          = 2467,
        .passive_scan_or_radar_detect = true,
    },
};
```


Table 7. Command parameters

Parameter	Description
num_chan	A number of channels showed in the list. The number must be the same as the number of chan_info elements.
channel_num	Number of the channel
chan_freq	Frequency of the channel
passive_scan_or_radar_detect	<p>Informs the driver whether the channel is a passive channel (Band B/G) or a DFS channel (Band A) for the radar detection. If set to "True", only passive scanning is done for the channel.</p> <p>True: Passive Scan/DFS channel</p> <p>False: Active scanning</p>

The following code sample shows chanlist_5g_cfg data structure (for 5 GHz band):

```
static wlan_chanlist_t chanlist_5g_cfg = {
    2,
    [0] =
        {
            .chan_num           = 36,
            .chan_freq          = 5180,
            .passive_scan_or_radar_detect = false,
        },
    [1] =
        {
            .chan_num           = 100,
            .chan_freq          = 5500,
            .passive_scan_or_radar_detect = true,
        },
};
```

Two channel scan configurations are defined (num_chans parameter is set to 2):

- channel 36, frequency 5180, using active scan
- channel 100, frequency 5500, using passive scan

There are two ways to set/get the scan type:

- using the API
- using the command line

The following sections describe both methods.

3.1 Customization using API calls

Use the driver APIs with the required arguments to perform the set operation wlan_set_chanlist.

```
int wlan_set_chanlist(wlan_chanlist_t *chanlist)
```

Table 8. Command parameters

Parameter	Description
[in] chanlist	A pointer to wlan_chanlist_t structure to supply the channel list configuration. This structure is explained below.

The function which sets the channel list and is defined in the file <sdk_root>/middleware/wifi_nxp/wlcmgr/wlan.c.

Returns:

WM_SUCCESS: the call is successful

WM_FAIL: the call failed

The following is an example of use of wlan_set_chanlist; the function takes the aforementioned structures wlan_chanlist_t as input parameter.

For 2.4 GHz:

```
ret = wlan_set_chanlist(&chanlist_2g_cfg);
if (ret != WM_SUCCESS)
    PRINTF("Cannot set Channel List 2G\r\n");
else
    PRINTF("Successfully set 2G Channel List\r\n");
```

For 5 GHz:

```
ret = wlan_set_chanlist(&chanlist_5g_cfg);
if (ret != WM_SUCCESS)
    PRINTF("Cannot set Channel List 5G\r\n");
else
    PRINTF("Successfully set 5G Channel List\r\n");
```

As shown in the sample codes, the implementation provides a return status for the function to check whether the function call is successful or not.

Use the driver APIs with the required arguments to perform the get operation wlan_get_chanlist.

```
int wlan_get_chanlist(wlan_chanlist_t *chanlist)
```

Table 9. Command parameters

Parameter	Description
[out] chanlist	A pointer to wlan_chanlist_t structure to get the channel list configuration.

The function which sets the channel list and is defined in file located in <sdk_root>/middleware/wifi_nxp/wlcmgr/wlan.c.

Returns:

WM_SUCCESS: the call is successful

WM_FAIL: the call failed

Note: The channels that are configured using this API should be from the list of channels under World Wide Safe Mode (WWSM).

The following is an example of use of wlan_get_chanlist; the function takes the aforementioned structures wlan_chanlist_t as output parameter.

```
wlan_chanlist_t chanlist;
memset(&chanlist, 0x00, sizeof(wlan_chanlist_t));
int rv = wlan_get_chanlist(&chanlist);
if (rv != WM_SUCCESS)
    PRINTF("Unable to get channel list configuration\r\n");
else {
    int i;
    PRINTF("-----\r\n");
    PRINTF("Number of channels configured: %d\r\n", chanlist.num_chans);
    PRINTF("\r\n");
    for (i = 0; i < chanlist.num_chans; i++){
        PRINTF("ChanNum: %d\t", chanlist.chan_info[i].chan_num);
        PRINTF("ChanFreq: %d\t", chanlist.chan_info[i].chan_freq);
        PRINTF("%s", chanlist.chan_info[i].passive_scan_or_radar_detect ? "Passive" :
"Active");
        PRINTF("\r\n");
    }
}
```

As shown in the sample codes, the implementation provides a return status for the function to check whether the function call is successful or not.

3.2 Customization using the command line interface

By default, the current implementation does not include the CLI commands to set the scan type. This section shows the steps needed to add such feature.

- Edit the file: `<sdk root>/middleware/wifi_nxp/wlcmgr/wlan_tests.c`
- Add the following command:

```
{"wlan-set-chanlist", NULL, test_wlan_set_chanlist},
```

The example below shows the added line in **bold**.

```
static struct cli_command tests[] = {  
.  
.  
.  
{"wlan-set-chanlist", NULL, test_wlan_set_chanlist},  
};
```

- Define the channel list structure with the required values for 2G and 5G, as shown below

For 2.4 GHz

```
static wlan_chanlist_t chanlist_2g_cfg = {  
2,  
[0] =  
{  
    .chan_num          = 1,  
    .chan_freq         = 2412,  
    .passive_scan_or_radar_detect = false,  
},  
[1] =  
{  
    .chan_num          = 12,  
    .chan_freq         = 2467,  
    .passive_scan_or_radar_detect = true,  
},  
};
```

For 5 GHz

```
#ifdef CONFIG_5GHz_SUPPORT
static wlan_chanlist_t chanlist_5g_cfg = {
    2,
    [0] =
    {
        .chan_num          = 36,
        .chan_freq         = 5180,
        .passive_scan_or_radar_detect = false,
    },
    [1] =
    {
        .chan_num          = 100,
        .chan_freq         = 5500,
        .passive_scan_or_radar_detect = true,
    },
};
#endif
```

- Define the handler function that is triggered when the user executes the command `wlan-set-chanlist`

```
static void test_wlan_set_chanlist(int argc, char **argv)
{
    int ret = WM_SUCCESS;

    ret = wlan_set_chanlist(&chanlist_2g_cfg);
    if (ret != WM_SUCCESS)
        PRINTF("Cannot set Channel List 2G\r\n");
    else
        PRINTF("Successfully set 2G Channel List\r\n");

#ifdef CONFIG_5GHz_SUPPORT
    ret = wlan_set_chanlist(&chanlist_5g_cfg);
    if (ret != WM_SUCCESS)
        PRINTF("Cannot set Channel List 5G\r\n");
    else
        PRINTF("Successfully set 5G Channel List\r\n");
#endif
}
```

- Rebuild the SDK and run the command `wlan-set-chanlist` and read the output.

```
# wlan-set-chanlist
Successfully set 2G Channel List
Successfully set 5G Channel List
```

This code sample confirms that the channel list and scan information have been set.

To **verify** the channel list setting, you need to create the `wlan-get-chanlist` command by following the procedure detailed hereafter.

- Edit the file `<sdk_root>/middleware/wifi_nxp/wlcmgr/wlan_tests.c`
- Find the tests structure and add the following line:

```
{"wlan-get-chanlist", NULL, test_wlan_get_chanlist},
```

The example below shows the added line in bold.

```
static struct cli_command tests[] = {
    .
    .
    .
    {"wlan-get-chanlist", NULL, test_wlan_get_chanlist},
};
```

- Define the handler for wlan-get-chanlist command

```
static void test_wlan_get_chanlist(int argc, char **argv)
{
    wlan_chanlist_t chanlist;
    memset(&chanlist, 0x00, sizeof(wlan_chanlist_t));
    int rv = wlan_get_chanlist(&chanlist);
    if (rv != WM_SUCCESS)
        PRINTF("Unable to get channel list configuration\r\n");
    else {
        int i;
        PRINTF("-----\r\n");
        PRINTF("Number of channels configured: %d\r\n", chanlist.num_chans);
        PRINTF("\r\n");
        for (i = 0; i < chanlist.num_chans; i++){
            PRINTF("ChanNum: %d\t", chanlist.chan_info[i].chan_num);
            PRINTF("ChanFreq: %d\t", chanlist.chan_info[i].chan_freq);
            PRINTF("%s", chanlist.chan_info[i].passive_scan_or_radar_detect ? "Passive" :
"Active");
            PRINTF("\r\n");
        }
    }
}
```

- Rebuild the SDK and run the command wlan-get-chanlist. The output will be similar to the one shown below.

```
# wlan-get-chanlist
-----
Number of channels configured: 4
ChanNum: 1      ChanFreq: 2412  Active
ChanNum: 12     ChanFreq: 2467  Passive
ChanNum: 36     ChanFreq: 5180  Active
ChanNum: 100    ChanFreq: 5500  Passive
```

3.3 Customization using the region-specific TX power limit file

Refer to [Section 2.3.3](#).

4 Abbreviations

Table 10. Abbreviations

Abbreviation	Definition
AP	access point
CLI	command line interface
CRDA	central regulatory domain agent
EEPROM	electrically erasable programmable read-only memory
FW	firmware
IE	information element
OTP	one time programmable
WLAN	wireless local area network

5 Note about the source code in the document

The example code shown in this document has the following copyright and BSD-3-Clause license:

Copyright 2020-2025 NXP Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notice, this list of conditions and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notice, this list of conditions and the following disclaimer in the documentation and/or other materials must be provided with the distribution.
3. Neither the name of the copyright holder nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE COPYRIGHT HOLDERS AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE COPYRIGHT HOLDER OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

6 Revision history

Revision history

Document ID	Date	Description
AN12918 v.14.0	17 September 2025	<ul style="list-style-type: none"> Section 2.2 "TX power table configuration": added the rate groups 17, 18 and 19 in Table 2.
AN12918 v.13.0	9 June 2025	<ul style="list-style-type: none"> Section 1.2 "Supported products": removed 88W8801. Added IW610. Section 2.2 "TX power table configuration": corrected the description of the code sample showing an example with the data structure <code>tx_pwrlimit_5g_cfg</code>. Section 2.3.1 "Customization using API calls": updated the first sentence. Section 2.3.3 "Customization using the region-specific TX power limit file": added. Section 3 "Channel list and scan type": updated the first paragraph. Section 3.3 "Customization using the region-specific TX power limit file": added.
AN12918 v.12.0	6 January 2025	<ul style="list-style-type: none"> Section 1.2 "Supported products": updated the note about AW611 support. Section 2.2 "TX power table configuration": updated the code samples.
AN12918 v.11.0	26 June 2024	<ul style="list-style-type: none"> Section 1.2 "Supported products": added IW611 and AW611.
AN12918 v.10.0	9 January 2024	<ul style="list-style-type: none"> Section 1.2 "Supported products": replaced IW612 with IW61x and removed the footnote.
AN12918 v.9.0	13 October 2023	<ul style="list-style-type: none"> Table 2 "Rate group information": added the last two rows.
AN12918 v.8.0	29 June 2023	<ul style="list-style-type: none"> Section 1.2 "Supported products": added IW612 Table 10 "Abbreviations": removed TRPC Section 5 "Note about the source code in the document": added
AN12918 v.7.0	5 January 2023	<ul style="list-style-type: none"> Section 2.2 "TX power table configuration": added the path to the header files for Murata and AzureWave modules Replaced all <code>/wifi/</code> occurrences with <code>/wifi_nxp/</code> in the path to files or directories
AN12918 v.6.0	15 September 2022	<ul style="list-style-type: none"> Section 1.2 "Supported products": removed 88W8977 device Section 2.1 "TX power table in OTP": removed the paragraph about 88W8977 device
AN12918 v.5.0	6 July 2022	<ul style="list-style-type: none"> Section 2.2 "TX power table configuration": changed the format of the configuration file in the code samples Section 3 "Channel list and scan type" changed the format of the configuration file in the code samples Table 6 "Default channel list and scan configuration": replaced 12-13 with 12-14 as range of channels for passive scan in 2.4 GHz bandwidth Section 3.2 "Customization using the command line interface": changed the format of the configuration file in the code samples

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

Revision history...continued

Document ID	Date	Description
AN12918 v.4.0	10 January 2022	<ul style="list-style-type: none"> Section 2.2 "TX power table configuration": <ul style="list-style-type: none"> . Renamed <code>txpowerlimit_2g_cfg</code> as <code>tx_pwrlimit_2g_cfg</code> . Renamed <code>txpowerlimit_5g_cfg</code> as <code>tx_pwrlimit_5g_cfg</code> . Renamed <code>wlan_txpwrlimit_cfg.c</code> as <code>wlan_txpwrlimit_cfg_WW.h</code> . Updated the path to <code>wlan_txpwrlimit_cfg_WW.h</code> file . Table 2 "Rate group information": added the groups 10 to 15 Section 2.3 "Customization of TX power table configuration": added a note and a reference to the regulatory region in the introduction Section 2.3.1 "Customization using API calls": <ul style="list-style-type: none"> . Renamed <code>txpowerlimit_2g_cfg</code> as <code>tx_pwrlimit_2g_cfg</code> . Renamed <code>txpowerlimit_5g_cfg</code> as <code>tx_pwrlimit_5g_cfg</code> Section 2.3.2 "Customization using the command line interface": <ul style="list-style-type: none"> . Renamed <code>txpowerlimit_2g_cfg</code> as <code>tx_pwrlimit_2g_cfg</code> . Renamed <code>txpowerlimit_5g_cfg</code> as <code>tx_pwrlimit_5g_cfg</code> Section 3 "Channel list and scan type": <ul style="list-style-type: none"> . Renamed <code>wlan_txpwrlimit_cfg.c</code> as <code>wlan_txpwrlimit_cfg_WW.h</code>
AN12918 v.3.0	12 June 2021	<ul style="list-style-type: none"> Section 1.2 "Supported products": extended the scope to 88W8987 Section 2.1 "TX power table in OTP": updated Section 2.3.2 "Customization using the command line interface": improved the format of the examples Section 3.2 "Customization using the command line interface": improved the format of the examples
AN12918 v.2.0	13 January 2021	Extended the scope to IW416 device: <ul style="list-style-type: none"> Section 1.2 "Supported products": updated Section 2.2 "TX power table configuration": updated Section 3.2 "Customization using the command line interface": updated
AN12918 v.1.0	17 July 2020	Initial version

Legal information

Definitions

Draft — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Terms and conditions of commercial sale — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at <https://www.nxp.com/profile/terms>, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Suitability for use in non-automotive qualified products — Unless this document expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

HTML publications — An HTML version, if available, of this document is provided as a courtesy. Definitive information is contained in the applicable document in PDF format. If there is a discrepancy between the HTML document and the PDF document, the PDF document has priority.

Translations — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

Security — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at PSIRT@nxp.com) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

NXP B.V. — NXP B.V. is not an operating company and it does not distribute or sell products.

Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

NXP — wordmark and logo are trademarks of NXP B.V.

Wi-Fi TX Power Table and Channel Scan Management for i.MX Platforms Running FreeRTOS

Amazon Web Services, AWS, the Powered by AWS logo, and FreeRTOS
— are trademarks of Amazon.com, Inc. or its affiliates.

Tables

Tab. 1.	Main parameters in txpwrlimit data structures	5	Tab. 6.	Default channel list and scan configuration	16
Tab. 2.	Rate group information	6	Tab. 7.	Command parameters	17
Tab. 3.	Command parameters	8	Tab. 8.	Command parameters	18
Tab. 4.	Command parameters	9	Tab. 9.	Command parameters	19
Tab. 5.	Sub-band definitions	10	Tab. 10.	Abbreviations	23

Contents

1	Introduction	2
1.1	Scope	2
1.2	Supported products	2
2	TX power tables	3
2.1	TX power table in OTP	3
2.2	TX power table configuration	3
2.3	Customization of TX power table configuration	8
2.3.1	Customization using API calls	8
2.3.2	Customization using the command line interface	11
2.3.3	Customization using the region-specific TX power limit file	15
3	Channel list and scan type	16
3.1	Customization using API calls	18
3.2	Customization using the command line interface	20
3.3	Customization using the region-specific TX power limit file	22
4	Abbreviations	23
5	Note about the source code in the document	24
6	Revision history	25
	Legal information	27

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.