AN14634

Kconfig Memory Optimizer Rev. 2.0 — 1 September 2025

Application note

Document information

Information	Content
Keywords	Kconfig memory optimizer, host memory saving, i.MX RT1060 EVKC, IW416, 88W8987, IW610, IW612, FRDM-MCXN947, FRDM-IW416, macros, flash memory, SRAM
Abstract	Explains how to configure host memory saving on IW416, 88W8987, IW610, or IW612.



Kconfig Memory Optimizer

1 About this document

The MCUXpresso SDK provides options to reduce the host memory usage with build-time configuration parameters referred to as Kconfig memory optimizer. The configuration parameters are used to reduce the use of the flash memory and SRAM. This document explains how to enable the host memory saving configurations within the Wi-Fi and Bluetooth drivers of NXP wireless devices.

1.1 Supported devices

The document applies to the following NXP host platforms and wireless devices:

- i.MX RT1060 EVKC + IW416 module (Murata 1XK)
- i.MX RT1060 EVKC + 88W8987 module (Murata 1ZM)
- i.MX RT1060 EVKC + IW612 module (Murata 2EL)
- i.MX RT1060 EVKC + IW610 module (Murata 2LL)
- FRDM-MCXN947 + FRDM-IW416 (AW-AM510)

Note: The document includes the host memory usage numbers for i.MX RT1060 EVKC and FRDM-MCXN947 using IW416 module and SDK 25.06.00.

1.2 Prerequisites

This document assumes that you are familiar with MCUXpresso SDK and the flashing of examples onto the i.MX RT1060 EVKC + Murata 1XK (IW416 module) and FRDM-MCXN947 + FRDM-IW416. For more information, see <u>ref.[1]</u>.

Kconfig Memory Optimizer

2 Host memory saving options for Wi-Fi

The standalone FRDM-MCXN947 board has a low memory footprint. When FRDM-IW416 is attached to FRDM-MCXN947, the configurations for host memory saving are enabled by default (set to 1) with the Kconfig memory optimizer. But when IW416 module (Murata 1XK) is connected to i.MX RT1060 EVKC, the configurations for host memory saving are disabled by default (set to 0) and must be enabled.

Kconfig Memory Optimizer

2.1 i.MX RT1060 EVKC + IW416 module (Murata 1XK)

This section explains how to reduce the host memory usage on i.MX RT1060 EVKC + IW416 module (Murata 1XK).

<u>Table 1</u> shows the average memory usage when the Kconfig macros are enabled or disabled.

Table 1. Memory usage of i.MX RT1060 EVKC + IW416 module (Murata 1XK)

Kconfig macros	Flash usage (kB)	SRAM usage (kB)
All disabled	820	420
All enabled	796	411

The default values of Kconfig macros are set in the file wifi_config_default.h file located in <SDK_PATH>/ middleware/wifi_nxp/incl/ directory. By default, the macros are disabled (set to 0).

To reduce the use of the flash and SRAM, change the settings of the Kconfig macros listed in the file wifi_config.h located in reduce the config.h located in the wifi config.h loc

Table 2 lists the Kconfig macros and respective memory usage.

Table 2. i.MX RT Kconfig macros and respective memory usage

Kconfig macro	Description	Memory usage	
		Flash (kB)	SRAM (kB)
CONFIG_WIFI_SLIM_ROAM	Disables CONFIG_ROAMING, CONFIG_11R	815	420
CONFIG_WIFI_SLIM_STA	Disables CONFIG_CLOUD_KEEP_ALIVE CONFIG_WIFI_EU_CRYPTO CONFIG_TX_AMPDU_PROT_MODE CONFIG_WNM_PS CONFIG_TURBO_MODE CONFIG_AUTO_RECONNECT CONFIG_DRIVER_OWE CONFIG_OWE CONFIG_OWE CONFIG_WIFI_FORCE_RTS CONFIG_WIFI_FRAG_THRESHOLD CONFIG_COMBO_SCAN CONFIG_SCAN_CHANNEL_GAP	801	411
CONFIG_WIFI_SLIM_UAP	Disables CONFIG_UAP_STA_MAC_ADDR_ FILTER CONFIG_WIFI_MAX_CLIENTS_CNT	819	420
CONFIG_FREERTOS_LOW_MEMORY_ FOOTPRINT	If the macro is enabled, the heap memory usage is reduced by 10 kB (70 kB to 60 kB)	820	420
CONFIG_LWIP_LOW_MEM_FOOTPRINT	Curtails IwIP stack parameters, reduces data throughput, and disables data net-stats	820	420
Nonblocking firmware download mechanism	Disables CONFIG_FW_DNLD_ASYNC	820	420

Kconfig Memory Optimizer

2.2 FRDM-MCXN947 + FRDM-IW416

This section explains how to reduce the host memory usage on FRDM-MCXN947 + FRDM-IW416.

Table 3 shows the memory usage when the all Kconfig macros are enabled or disabled.

Table 3. Total memory usage of FRDM-MCXN947 and FRDM-IW416

Kconfig macros	Flash usage (kB)	SRAM usage (kB)
All disabled	629	190
All enabled	612	182

Table 4 lists the Kconfig macros and respective memory usage.

To reduce the use of the flash and SRAM, set to "1" the Kconfig macros (set to "1") in the file *wifi_config.h* located in *<path-to-SDK_Wi-Fi_Example>* directory.

Table 4. FRDM-MCXN947 and FRDM-IW416 Kconfig macros and respective memory usage

Kconfig macros	Description	Memory usage	
		Flash (kB)	SRAM (kB)
CONFIG_WIFI_SLIM_ROAM	Disables CONFIG_ROAMING, CONFIG_11R	626	190
CONFIG_WIFI_SLIM_STA	Disables CONFIG_CLOUD_KEEP_ALIVE CONFIG_WIFI_EU_CRYPTO CONFIG_TX_AMPDU_PROT_MODE CONFIG_WNM_PS CONFIG_TURBO_MODE CONFIG_AUTO_RECONNECT CONFIG_DRIVER_OWE CONFIG_OWE CONFIG_WIFI_FORCE_RTS CONFIG_WIFI_FRAG_THRESHOLD CONFIG_COMBO_SCAN CONFIG_SCAN_CHANNEL_GAP	615	182
CONFIG_WIFI_SLIM_UAP	Disables CONFIG_UAP_STA_MAC_ADDR_ FILTER CONFIG_WIFI_MAX_CLIENTS_CNT	629	190
CONFIG_FREERTOS_LOW_MEMORY_ FOOTPRINT	If the macro is enabled, the heap memory usage is reduced by 10 kB (70 kB to 60 kB)	629	190
CONFIG_LWIP_LOW_MEM_FOOTPRINT	Curtails lwIP stack parameters, reduces data throughput, disables data net-stats	629	190
Nonblocking firmware download mechanism	Disables CONFIG_FW_DNLD_ASYNC	629	190

Kconfig Memory Optimizer

3 Host memory saving options for Bluetooth LE

The wifi_cli_over_ble_wu application is used to reduce memory usage of i.MX RT1060 EVKC and FRDM-MCXN947. By default, wifi_cli_over_ble_wu application is enabled with minimal Bluetooth LE features (central, peripheral, and only one device connection).

The wifi_cli_over_ble_wu application is located in the latest SDK under:

- <RT1060_SDK>\boards\evkcmimxrt1060\edgefast_bluetooth_examples for i.MX RT1060 EVKC
- <FRDM_SDK>\boards\frdmmcxn947\edgefast_bluetooth_examples> for FRDM-MCXN947

Kconfig Memory Optimizer

4 Firmware download option

By default, the SDK downloads the combo firmware for Wi-Fi and Bluetooth. The size of the combo firmware is larger than the size of the standalone Wi-Fi firmware or Bluetooth firmware. To enable the download of the standalone Wi-Fi or Bluetooth firmware, set the following macros to 1 in *SDK_Wi-Fi_Example_PATH>/wifi_config.h file*.

- CONFIG_WIFI_IND_DNLD
- CONFIG_BT_IND_DNLD

Note: <u>Table 5</u> shows the memory usage when using wifi_cli application.

Table 5. Memory usage for FRDM-MCXN947 + FRDM-IW416

Macro	Description	Memory usage	
		Flash (kB)	SRAM (kB)
CONFIG_WIFI_IND_DNLD	Download Wi-Fi firmware only	612	182
CONFIG_BT_IND_DNLD	Download Bluetooth firmware only	733	182

Kconfig Memory Optimizer

5 Abbreviations

Table 6. Abbreviations

Abbreviation	Definition
LWIP	Lightweight IP
SDK	Software development kit
SRAM	Static random access memory

6 References

[1] GitHub – nxp-mcuxpresso/mcusdk-manifests (link)

7 Revision history

Table 7. Revision history

Document ID	Release date	Description
AN14634 v.2.0	1 September 2025	Section 4 "Firmware download option": updated the note.
AN14634 v.1.0	12 August 2025	Initial version

Kconfig Memory Optimizer

Legal information

Definitions

Draft — A draft status on a document indicates that the content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included in a draft version of a document and shall have no liability for the consequences of use of such information.

Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors.

In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory.

Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable for the specified use without further testing or modification.

Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products.

NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Terms and conditions of commercial sale — NXP Semiconductors products are sold subject to the general terms and conditions of commercial sale, as published at https://www.nxp.com/profile/terms, unless otherwise agreed in a valid written individual agreement. In case an individual agreement is concluded only the terms and conditions of the respective agreement shall apply. NXP Semiconductors hereby expressly objects to applying the customer's general terms and conditions with regard to the purchase of NXP Semiconductors products by customer.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Suitability for use in non-automotive qualified products — Unless this document expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of non-automotive qualified products in automotive equipment or applications.

In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

HTML publications — An HTML version, if available, of this document is provided as a courtesy. Definitive information is contained in the applicable document in PDF format. If there is a discrepancy between the HTML document and the PDF document, the PDF document has priority.

Translations — A non-English (translated) version of a document, including the legal information in that document, is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

Security — Customer understands that all NXP products may be subject to unidentified vulnerabilities or may support established security standards or specifications with known limitations. Customer is responsible for the design and operation of its applications and products throughout their lifecycles to reduce the effect of these vulnerabilities on customer's applications and products. Customer's responsibility also extends to other open and/or proprietary technologies supported by NXP products for use in customer's applications. NXP accepts no liability for any vulnerability. Customer should regularly check security updates from NXP and follow up appropriately. Customer shall select products with security features that best meet rules, regulations, and standards of the intended application and make the ultimate design decisions regarding its products and is solely responsible for compliance with all legal, regulatory, and security related requirements concerning its products, regardless of any information or support that may be provided by NXP.

NXP has a Product Security Incident Response Team (PSIRT) (reachable at PSIRT@nxp.com) that manages the investigation, reporting, and solution release to security vulnerabilities of NXP products.

NXP B.V. — NXP B.V. is not an operating company and it does not distribute or sell products.

Trademarks

Notice: All referenced brands, product names, service names, and trademarks are the property of their respective owners.

NXP — wordmark and logo are trademarks of NXP B.V.

AN14634

Kconfig Memory Optimizer

Amazon Web Services, AWS, the Powered by AWS logo, and FreeRTOS—are trademarks of Amazon.com, Inc. or its affiliates.

Bluetooth — the Bluetooth wordmark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by NXP Semiconductors is under license.

Kconfig Memory Optimizer

Tables

Tab. 1.	Memory usage of i.MX RT1060 EVKC + IW416 module (Murata 1XK)4	Tab. 4.	FRDM-MCXN947 and FRDM-IW416 Kconfig macros and respective memory	
Tab. 2.			usage	5
	memory usage 4	Tab. 5.		
Tab. 3.	Total memory usage of FRDM-MCXN947		FRDM-IW416	7
	and FRDM-IW4165	Tab. 6.	Abbreviations	8
		Tab. 7.	Revision history	8

Kconfig Memory Optimizer

Contents

1	About this document	2
1.1	Supported devices	2
1.2	Prerequisites	2
2	Host memory saving options for Wi-Fi	
2.1	i.MX RT1060 EVKC + IW416 module	
	(Murata 1XK)	4
2.2	FRDM-MCXN947 + FRDM-IW416	
3	Host memory saving options for	
	Bluetooth LÉ	6
4	Firmware download option	
5	Abbreviations	
6	References	
7	Revision history	
-	I egal information	

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.